





Translation of original operating instructions for ZEMO pedelecs with BOSCH Intuvia on-board computer

SU-E FS 12, ZE 10, ZE 5F, ZE 5F Plus, ZE 5R, ZE 5R Plus

21-17-3234...21-17-3237, 22-15-2057...22-15-2062

Contents

1	About th	nese operating instructions	
	1.1	Manufacturer	11
	1.2	Laws, standards and directives	11
	1.3	Language	11
	1.4	For your information	1 1
	1.4.1	Warnings	11
	1.4.2	Markups	1 1
	1.5	Aim of the operating instructions	12
	1.6	Type number and model	13
	1.7	Frame number	13
	1.8	Identifying the operating instructions	13
2	Safety		
	2.1	Residual risk	14
	2.1.1	Risk of fire and explosion	14
	2.1.2	Electric shock	16
	2.1.2.1	Damage	16
	2.1.2.2	Water penetration	16
	2.1.2.3	Condensation	16
	2.1.3	Risk of a crash	16
	2.1.3.1	Incorrect quick release setting	16
	2.1.3.2	Incorrect tightening torque	16
	2.1.3.3	Incorrect component	16
	2.1.4	Risk of amputation	16
	2.1.5	Key breaking off	16
	2.2	Toxic substances	17
	2.2.1	Carcinogenic substances	17
	2.2.1	Toxic substances	17
	2.2.2	Irritants and corrosive substances	17
	2.2.3		18
	2.3	Requirements for the pedelec rider	18
	2.4	Vulnerable groups	18
		Personal protective equipment	
	2.6	Safety guards	18
	2.7	Safety markings and safety instructions	19
	2.8	What to do in an emergency	19
	2.8.1	Dangerous situation in road traffic	19
	2.8.2	Leaked brake fluid	19
	2.8.3	Battery vapour emission	20
	2.8.4	Battery fire	20
	2.8.5 2.8.6	Oil and lubricant leaks from the rear frame damper Oil and lubricant leaks from the fork	20 20
3	Descrip	tion	
•	-		0.4
	3.1	Proper use	21
	3.1.1	Improper use	22
	3.1.2	Permitted total weight (PTW)	23
	3.1.3	Environmental requirements	24
	3.2	Nameplate	26
	3.3	Components	27
	3.3.1	Overview	27
	3.3.2	Chassis	28
	3.3.2.1	Frame	28
	3.3.2.2	Steering system	28
	3.3.2.3	Steering headset	28
	3.3.2.4	Stem	28

3.3.2.5	Handlebars	29
3.3.2.6	Fork	29
3.3.3	Suspension	30
3.3.3.1	Rigid fork	30
3.3.3.2	Suspension fork	30
3.3.4	Wheel	34
3.3.4.1	Tyres	34
3.3.4.2	Tube-type tyre	34
3.3.5	Braking system	37
3.3.5.1	Mechanical brake	37
3.3.5.2	Hydraulic brake	37
3.3.5.3	Disc brake	38
3.3.6	Saddle	39
3.3.7	Seat post	39
3.3.7.1	Patent seat post	39
3.3.7.2	Suspension seat post	40
3.3.8	Mechanical drive system	41
3.3.8.1	Chain drive layout	41
3.3.8.2	Belt drive layout	41
3.3.9	Electric drive system	42
3.3.9.1	Motor	42
3.3.9.2	Rechargeable battery	42
3.3.9.3	Frame battery	43
3.3.9.4	Pannier rack battery	43
3.3.9.5	Integrated battery	44
3.3.9.6	Charger	44
3.3.10	Lighting	44
3.3.11	On-board computer	45
3.3.11.1	USB port	45 45
3.3.12 3.4	Control panel	46
3.4 3.4.1	Description of controls and screens Handlebars	46
3.4.1	On-board computer	47
3.4.2.1	Riding light indicator	47
3.4.2.2	Level of assistance indicator	47
3.4.2.3	Charge level indicator (on-board computer)	48
3.4.2.4	Indicator for motor power used	48
3.4.2.5	Gear recommendation indicator	48
3.4.2.6	Tachometer indicator	48
3.4.2.7	Function display	48
3.4.2.8	Journey information	49
3.4.2.9	Additional journey information	49
3.4.2.10	System settings and data	50
3.4.2.11	Additional system settings	50
3.4.2.12	System message	51
3.4.3	Control panel	52
3.4.4	Gear shift	53
3.4.4.1	SHIMANO derailleur gears	53
3.4.5	Handbrake	54
3.4.6	Fork lock	55
3.4.6.1	SR Suntour	55
3.4.7	Battery level indicator (battery)	56
3.4.7.1	Battery level indicator (battery)	56
3.5	Technical data	57
3.5.1	Pedelec	57
3.5.2	Emissions	57
3.5.3	BOSCH Intuvia on-board computer	57
3.5.4	USB port	57
3.5.5	BOSCH Performance Line CX motor	57

	3.5.6	Battery BOSCH PowerTube 625	57
	3.5.7	Bicycle lighting	57
	3.5.8	Torque	58
4	Transpo	orting and storing	
	4.1	Weight and dimensions for transportation	65
	4.2	Designated handles, lifting points	65
	4.3	Transportation	66
	4.3.1	Using the transport securing system	66
	4.3.2	Transporting the pedelec	66
	4.3.3	Shipping a pedelec	66
	4.3.4	Transporting the battery	66
	4.3.5	Shipping the battery	66
	4.4	Storing	67
	4.4.1	Storage mode	67
	4.4.2	Break in operation	67
	4.4.2.1	Preparing a break in operation	67
	4.4.2.2	Carrying out a break in operation	67
		Garrying out a broak in operation	0.
5	Assemb	oly	
	5.1	Unpacking	68
	5.2	Required tools	68
	5.3	Commissioning	69
	5.3.1	Checking the battery	69
	5.3.2	Preparing the battery	70
	5.3.2.1	Retrofitting the PowerTube adapter	70
	5.3.2.2	Fit battery cover onto Bosch PowerTube 625 battery (horizontal)	71
	5.3.2.3	Fit battery cover onto Bosch PowerTube 500 battery (horizontal)	72
	5.3.2.4	· · · · · · · · · · · · · · · · · · ·	73
		Securing the PowerTube BS2 battery mount	
	5.3.3	Preparing the wheel	78 70
	5.3.4	Installing the wheel in the SUNTOUR fork	79
	5.3.4.1	Screw-on axle (12AH2 and 15AH2)	79
	5.3.4.2	20 mm cross axle	80
	5.3.4.3	Q-LOC quick release	82
	5.3.5	Preparing the LIMOTEC seat post	83
	5.3.6	Fitting the pedals	84
	5.3.7	Checking the stem and handlebars	85
	5.3.7.1	Checking the connections	85
	5.3.7.2	Checking stem is firmly in position	85
	5.3.7.3	Checking the bearing clearance	85
	5.4	Selling the pedelec	85
6	Operation	on	
0	6.1	Risks and hazards	86
	6.2	Tips for a greater range	88
	6.3	Error message	89
	6.3.1	On-board computer	89
	6.3.2	·	91
		Rechargeable battery	
	6.4	Instruction and customer service	92
	6.5	Adjusting the pedelec	92
	6.5.1	Preparing	92
	6.5.2	Pedelec adjustment procedure	93
	6.5.3	Determining the sitting position	94
	6.5.3.1	Straighten saddle	95
	6.5.3.2	Positioning the saddle with eightpins suspension seat post	95
	6.5.3.3	Adjusting the saddle height	96
	6.5.3.4	Setting the saddle height with the remote control	97
	6.5.3.5	Adjusting the saddle position	98

6.5.3.6	Adjusting the saddle tilt	98
6.5.3.7	Checking saddle stability	98
6.5.4	Handlebars	99
6.5.4.1	Replace handlebars	99
6.5.4.2	Adjusting the handlebar width	99
6.5.4.3	Adjusting the hand position	99
6.5.4.4	Adjusting the handlebars	100
6.5.5	Stem	101
6.5.5.1	Replacing the handlebars	101
6.5.5.2	Adjusting the handlebar height with quick release	101
6.5.5.3	Checking the stem stability	101
6.5.5.4	Adjusting the quick release clamping force	101
6.5.5.5	Setting the quill stem	102
6.5.5.6	Adjusting the Ahead stem	102
6.5.5.7	Adjusting the angle-adjustable stem	103
6.5.6	Handles	104
6.5.6.1	Replacing the handles	104
6.5.6.2	Adjusting ergonomic handles	104
6.5.6.3	Checking handlebar stability	104
6.5.7	Tyres	105
6.5.7.1	Adjust tyre pressure	105
6.5.7.2	Replacing tyres	106
6.5.8	Brake	107
6.5.8.1	Change handbrake position	107
6.5.8.2	Change handbrake inclination angle	107
6.5.8.3		107
6.5.8.4	Determining the grip distance	109
	Grip distance on a MAGURA disc brake lever	110
6.5.8.5	Pressure point on a MAGURA brake lever	
6.5.8.6	Replacing brakes	111
6.5.8.7	Retracting the brake linings	111
6.5.9	Gear shift	112
6.5.9.1	Replacing the gear shift	112
6.5.9.2	Adjusting the SHIMANO shifter	112
6.5.10	Suspension	113
6.5.11	Fork sag	113
6.5.11.1	Adjusting the SR SUNTOUR fork steel suspension	114
6.5.11.2	Adjusting the SR SUNTOUR fork air suspension	115
6.5.12	Fork rebound damping	116
6.5.12.1	Adjusting the SR SUNTOUR fork rebound damping	117
6.5.13	Riding light	118
6.5.13.1	Adjusting the headlight	119
6.5.14	Adjust on-board computer	120
6.5.14.1	Attaching the on-board computer	120
6.5.14.2	Removing the on-board computer	120
6.5.14.3	Attaching the on-board computer	120
6.5.14.4	Securing the on-board computer against removal	120
6.5.14.5	Charging the on-board computer battery	121
6.5.14.6	Changing the system settings	121
6.6	Accessories	122
6.6.1	Child seat	122
6.6.2	Trailer	123
6.6.2.1	Approval for trailer with Enviolo hub	123
6.6.2.2	Approval for trailer with ROHLOFF hub	124
6.6.3	Mobile holder	124
6.6.4	Tubeless and airless tyres	124
6.6.5	Suspension fork coil spring	124
6.6.6	Pannier rack	125
6.6.7	Panniers and cargo boxes	125
6.7	Personal protective equipment and accessories for road safety	126

6.8	Before each ride	126
6.9	Straightening the quickly adjustable stem	127
6.10	Using the pannier rack	127
6.11	Raising the kickstand	128
6.12	Using the saddle	128
6.12.1	Using the leather saddle	128
6.13	Using the pedals	128
6.14	Using the bell	128
6.15	Using the handlebars	129
6.15.1	Using multi-position handlebars	129
6.15.2	Using bar ends	129
6.15.3	Using leather handles	129
6.16	Using the battery	130
6.16.1	Frame battery	130
6.16.1.1	Removing the frame battery	130
6.16.1.2	Inserting the frame battery	130
6.16.2	Pannier rack battery	130
6.16.2.1	Removing the pannier rack battery	130
6.16.2.2	Inserting the pannier rack battery	130
6.16.3	Integrated battery	131
6.16.3.1	Removing the integrated battery	131
6.16.3.2	Inserting the integrated battery	131
6.16.4	Charging the battery	132
6.16.5	Charging the dual battery	132
6.16.5.1	Charging process when two batteries are used	132
6.16.5.2	Charging process when one battery is used	132
6.16.6	Using double battery model with a single battery only	133
6.16.7	Waking the battery	133
6.17	Using pedelec with the electric drive system	134
6.17.1	Switching on the electric drive system	134
6.17.2	Switching off the electric drive system	134
6.18 6.18.1	Using the On-board computer	135 135
6.18.2	Using the USB port	135
6.18.3	Switching on the on-board computer Switching off the on-board computer	135
6.18.4	Using the push assist system	136
6.18.5	Using the push assist system Using the riding light	136
6.18.6	Selecting the level of assistance	136
6.18.7	Journey information	136
6.18.7.1	Switching the displayed journey information	136
6.18.7.2	Resetting the journey information	136
6.19	Using the brake	137
6.19.1	Use handbrake	137
6.19.2	Using the back-pedal brake	137
6.20	Use suspension and damping	138
6.20.1	Adjusting the SR SUNTOUR compression adjuster	139
6.21	Gear shift	140
6.21.1	Using the derailleur gears	140
6.21.2	Use SHIMANO hub gear	141
6.21.3	Using eShift	142
6.21.3.1	Using eShift with SHIMANO DI2 automatic hub gears	142
6.21.3.2	Using eShift with manual SHIMANO DI2 hub gears	142
6.21.3.3	Using eShift with SHIMANO DI2 automatic hub gears	142
6.22	Parking	143
6.22.1	Screwing in the quickly adjustable stem	144
Cleaning	g, servicing and inspection	
7.1	Before each ride	149
7.1.1	Checking the guards	149

7

7.1.2	Checking the frame	149
7.1.3	Checking the fork	149
7.1.4	Checking the rear frame damper	149
7.1.5	Checking the pannier rack	149
7.1.6	Checking the mudguards	149
7.1.7	Check wheel concentricity	149
7.1.8	Checking the quick releases	149
7.1.9	Checking the suspension seat post	150
7.1.10	Checking the bell	150
7.1.11	Checking the handles	150
7.1.12	Checking the USB cover	150
7.1.13	Checking the riding light	150
7.1.14	Checking the brake	150
7.2	After each ride	151
7.2.1	Cleaning the riding light and reflectors	151
7.2.2	Cleaning the suspension fork	151
7.2.3	Caring for the suspension fork	151
7.2.4	Cleaning the pedals	151
7.2.5	Cleaning the brake	151
7.2.6	Cleaning the suspension seat post	151
7.2.7	Cleaning the rear frame damper	151
7.3	Basic cleaning	152
7.3.1	Clean on-board computer and control panel	152
7.3.2	Cleaning the battery	152
7.3.3	Cleaning the motor	152
7.3.4	Clean Frame, fork, pannier rack, guards and kickstand	153
7.3.5	Cleaning the stem	153
7.3.6	Cleaning the handlebars	153
7.3.7	Clean handles	153
7.3.7.1	Cleaning leather handles	153
7.3.8	Clean seat post	153
7.3.9	Cleaning the saddle	154
7.3.9.1	Cleaning the leather saddle	154
7.3.10	Cleaning the tyres	154
7.3.11	Cleaning the spokes and spoke nipples	154
7.3.12	Clean hub	154
7.3.13	Cleaning the switching elements	154
7.3.13.1	Cleaning the shifter	154
7.3.14	Clean cassette, chain wheels and front derailleur	154
7.3.15	Clean brake Clean handbrake	155
7.3.15.1		155
7.3.16 7.3.17	Cleaning the brake disc	155 155
7.3.17	Cleaning the belt Cleaning the chain	155
7.3.16 7.3.18.1	Clean chain, including all-round chain guard	155
7.3.16.1 7.4	Servicing	156
7. 4 7.4.1	Frame	156
7.4.1	Fork	156
7.4.3	Pannier rack	157
7.4.4	Mudguard	157
7.4.5	Servicing the kickstand	157
7.4.6	Stem	157
7.4.7	Handlebars	157
7.4.8	Handle	157
7.4.8.1	Rubber handles	157
7.4.8.2	Leather handle	157
7.4.9	Seat post	158
7.4.9.1	Suspension seat post	158
7.4.9.2	Carbon seat post	158
	•	

7.4.10	Rim	158
7.4.11	Leather saddle	158
7.4.12	Hub	158
7.4.13	Spoke nipples	158
7.4.14	Gear shift	159
7.4.14.1	Rear derailleur articulated shafts and jockey wheels	159
7.4.14.2	Shifter	159
7.4.15	Pedal	159
7.4.16	Caring for the chain	159
7.4.16.1	Caring for the chain and all-round chain guard	160
7.4.17	Caring for the battery	160
7.4.18 7.4.18.1	Caring for the brake	160 160
7.4.10.1 7.4.19	Caring for handbrake Lubricating the Eightpins seat post tube	160
7.4.19 7.5	Inspection	161
7.5.1	Checking the wheel	161
7.5.1.1	Checking tyre pressure	161
7.5.1.2	Checking the tyres	163
7.5.1.3	Checking the rims	164
7.5.1.4	Checking the nipple holes	164
7.5.1.5	Checking the nipple well	164
7.5.1.6	Checking the rim hooks	164
7.5.1.7	Checking the spokes	164
7.5.2	Checking the brake system	165
7.5.2.1	Checking the handbrake	165
7.5.2.2	Checking the hydraulic brake system	165
7.5.2.3	Checking the Bowden cables	165
7.5.2.4	Checking the disc brake	166
7.5.2.5	Checking the back-pedal brake	167
7.5.2.6	Checking the rim brake	168
7.5.3	Checking the chain	169
7.5.4	Checking the chain tension	169
7.5.4.1	Check tension in derailleur gears	169
7.5.4.2	Check tension in hub gear	169
7.5.5	Checking the belt for wear	169
7.5.5.1	Rough check	169
7.5.5.2	Check	170
7.5.6	Checking the belt	171
7.5.7	Checking the belt for wear	171
7.5.8	Checking the belt sprockets for wear	171
7.5.9	Check belt tension	171
7.5.9.1	Gates Carbon Drive mobile app	172
7.5.9.2	Gates Krikit tension meter	172
7.5.9.3	ECO tension tester	173
7.5.10	Checking the riding light	174
7.5.11	Checking the stem	175
7.5.12	Checking the handlebars	175
7.5.13	Checking the saddle	175
7.5.14	Checking the seat post	175
7.5.14.1	Checking the derailleur gears	175
7.5.14.2	Checking the hub gear	176
7.5.15	Check gear shift	176
7.5.15.1 7.5.15.2	Electric gear shift Mechanical gear shift	176 176
7.5.15.2 7.5.15.3	Mechanical gear shift Checking the deraillour goars	176
7.5.15.3 7.5.16	Checking the derailleur gears	177
7.5.16 7.5.16.1	Adjusting gear shift Adjusting the ROHLOFF hub	177
7.5.16.1 7.5.17	Adjusting the ROBLOFF hab Adjusting cable-operated gear shift, dual-cable	177
7.5.17 7.5.18	Adjusting Cable-operated gear stritt, dual-cable Adjusting Bowden-cable-operated twist grip, dual-cable	177
	, agadang borraon dable operated twist grip, dual-dable	170

	7.5.19	Checking kickstand stability	178		
8	Inspecti	Inspection and maintenance			
	8.1	Initial inspection	179		
	8.2	Major inspection	179		
	8.3	Component-specific maintenance	179		
	8.4	Carry out initial inspection	182		
	8.5	Inspection and maintenance instructions	183		
		·			
	8.5.1	Inspecting the frame	190		
	8.5.1.1	Inspect the carbon frame	190		
	8.5.2	Inspecting the pannier rack	190		
	8.5.3	Inspect and maintain rear frame damper	190		
	8.5.4	Inspect gear hub	191		
	8.5.4.1	Adjusting the hub with cone bearing	191		
	8.5.5	Inspecting the stem	191		
	8.5.6	Inspect and grease steering headset	191		
	8.5.7	Inspecting axle with quick release	192		
	8.5.8	Inspecting the fork	193		
	8.5.8.1	Inspect the carbon suspension fork	193		
	8.5.8.2	Inspect the suspension fork	193		
	8.5.9	·	193		
		Inspecting the seat post			
	8.5.9.1	Inspect carbon seat post	194		
	8.5.9.2	Inspecting and greasing BY.SCHULZ suspension seat post	195		
	8.5.9.3	Inspecting and greasing RS SUNTOUR suspension seat post	195		
9	Troubleshooting, fault clearance and repair				
	9.1	Preventing pain	196		
	9.1.1	Sitting discomfort	197		
	9.1.2	Pain in hips	197		
	9.1.3	Backache	197		
	9.1.4	Pain in shoulders and nape of neck	198		
	9.1.5	Numb or aching hands	198		
	9.1.6	Pain in upper thigh	198		
	9.1.7	· · · · · · · · · · · · · · · · · · ·			
	9.1.7	Knee pain Pain in the foot	199 199		
9	Traubla	shooting, fault clearance and repair			
9	9.1	Troubleshooting and fault clearance	200		
	9.1.1	<u> </u>			
		Drive system or on-board computer does not start up	200		
	9.1.2	Error message	200		
	9.1.3	Assistance function errors	201		
	9.1.4	Battery error	202		
	9.1.5	On-board computer error	203		
	9.1.6	Lighting does not work	203		
	9.1.7	SR SUNTOUR suspension fork	204		
	9.1.7.1	Rebound too fast	204		
	9.1.7.2	Rebounding too slowly	205		
	9.1.7.3	Suspension too soft on inclines	206		
	9.1.7.4	Excessively hard damping on bumps	207		
	9.1.8	Problems with freewheel	208		
	9.1.9	Problems with hub gear	209		
	9.1.9	Problems with disc brakes	209		
	9.1.11	Problems with rim brakes	212		
	9.1.12	Problems with back-pedal brake	213		
	9.1.13	RockShox suspension fork	214		
	9.1.13.1	Rebound too fast	214		
	9.1.13.2	Rebounding too slowly	215		
	9.1.13.3	Suspension too soft on inclines	216		

	9.1.13.4	Excessively hard damping on bumps	217	
	9.1.14	Other errors	218	
	9.2	Repair	219	
	9.2.1	Original parts and lubricants	219	
	9.2.2	Repairing the frame	219	
	9.2.2.1	Removing paint damage on frame	219	
	9.2.2.2	Removing damage from impact on the carbon frame	219	
	9.2.3	Repairing the suspension fork	219	
	9.2.3.1	Removing paint damage on the fork	219	
	9.2.3.2	Removing damage from impact on the carbon frame	219	
	9.2.3.3	Repairing the seat post	219	
	9.2.3.4	Repairing damage from impact on the carbon post seat post	219	
	9.2.4	Replacing the riding light	220	
	9.2.5	Adjusting the headlight	220	
	9.2.6	Checking suspension fork-tyre clearance	220	
10	Recycli	ng and disposal		
	10.1	Guidelines on removal of waste	221	
11	Documents			
	11.1	Assembly report	223	
	11.2	Inspection and maintenance log	225	
	11.3	Parts list	229	
	11.3.1	SU-E FS 12	229	
	11.3.2	ZE 10	231	
	11.3.3	ZE 5F	233	
	11.3.4	ZE 5F Plus	235	
	11.3.5	ZE 5R	237	
	11.3.6	ZE 5F Plus	239	
	11.4	Charger operating instructions	241	
12	Glossar	v		
	12.1	Abbreviations	253	
	12.1	Simplified terms	253 253	
	12.2	Simplified terms	200	
13	Append			
	I.	Translation of the original EC/EU Declaration of Conformity	254	
	II.	Declaration of conformity for incomplete machine	255	
14	Keywor	d index		

Thank you for your trust!

ZEMO pedelecs are premium quality bicycles. You have made an excellent choice. Your specialist dealer will provide you with guidance and instruction and assemble your product. Your specialist dealer will also be happy to assist you in the future, whether you require maintenance, a retrofit or repair.

You are receiving these operating instructions with your new pedelec. Please take time to become familiar with your new pedelec and follow the tips and suggestions in the operating instructions. They will help you to enjoy your pedelec for a long time to come. We hope you have fun and wish you well on all of your rides!

Download the operating instructions onto your phone at the following link, so that you can use them when you are out riding:



https://www.zemo.com/de/de/index/download.html.

Copyright

© ZEG Zweirad-Einkaufs-Genossenschaft eG

Distribution or reproduction of these operating instructions and utilisation or communication of their content is prohibited unless expressly approved. Anyone who does not comply with these restrictions is liable for compensation. All rights reserved in the event that a patent, utility model or industrial design is registered.

Subject to internal changes

The information contained in these *operating instructions* are the approved technical specifications at the time of printing. In addition to the functions described here, the software may be modified at any time to rectify errors and extend functions.

Any significant changes are included in a new published version of the operating instructions. All changes and new versions of the operating instructions are published on the following website:

https://www.zemo.com/de/de/index/download.html

Editing

Text and images: ZEG Zweirad-Einkaufs-Genossenschaft eG Longericher Strasse 2 50739 Köln, Germany

Translation

RKT Übersetzungs- und Dokumentations-GmbH Bahnhofstrasse 27 78713 Schramberg Germany

If you have any questions or problems regarding these operating instructions, please contact:

tecdoc@zeg.de

1 About these operating instructions

1.1 Manufacturer

ZEG Zweirad-Einkaufs-Genossenschaft eG Longericher Strasse 2 50739 Köln, Germany

Tel.: +49 221 17959 0 Fax: +49 221 17959 31 Email: info@zemo.com

1.2 Laws, standards and directives

The *operating instructions* comply with the essential requirements specified in:

- Machinery Directive 2006/42/EC
- Electromagnetic Compatibility Directive 2014/30/ EU
- ISO 20607:2018 Safety of machinery

 Operating instructions

 General drafting principles
- EN 15194:2018 Cycles Electrically power assisted cycles – pedelec bicycles
- EN 11243:2016, Cycles Luggage carriers for bicycles – Requirements and test methods
- ISO 17100:2016-05 Translation Services Requirements for translation services.

1.3 Language

The *original operating instructions* are written in German. A translation is invalid without the *original operating instructions*.

1.4 For your information

Different markings are used in the operating instructions to make them easier to read.

ß	Text for specialist dealers
S	Notice on replacing components
	Notice on fitness

1.4.1 Warnings

Warnings indicate hazardous situations and actions. You will find three categories of warnings in the operating instructions:



May lead to serious or even fatal injuries if ignored. Medium-risk hazard.



May lead to minor or moderate injuries if ignored. Low-risk hazard.

Notice

May lead to material damage if ignored.

1.4.2 Markups

You will find ten text markups in the *operating instructions*:

Stylised form	Use
Italics	Glossary term, first mention in section
Underlined in blue	Link
Underlined in grey	Cross references
✓	Requirements
>	Instructions for actions without specific order
1	Instructions for actions in specified order
⇔	Result of the action
SPACED	Indicators on the display screen
•	Bulleted lists
Only applies to pedelecs with this equipment	A note beneath the heading indicates components which can be used as an option

Table 1: Markups

1.5 Aim of the operating instructions

These operating instructions are not a substitute for personal instruction by the specialist dealer supplying the bike. These operating instructions are an integral part of the pedelec. Therefore, if it is re-sold at a later time, they must be handed over to the subsequent owner.

These operating instructions are mainly written for people riding pedelecs.

Paragraphs with a white background are intended to enable non-professionals to make safe settings on the pedelec, use it, clean it and identify and eliminate any faults.



Sections intended for technical staff are highlighted in blue and marked with a spanner symbol.

These sections aim to allow trained technical staff (bicycle mechatronics engineers, bicycle mechanics or others) to carry out initial assembly, adjustment, inspection and repair safely.

Technical staff also need to read all sections for pedelec riders and operators to ensure they can provide better customer service.

Always fill out all reports in Section <u>11.1</u> and Section 11.2 when carrying out work.

Section	on	Rider	Specialist dealer
1	About these operating instructions		
2	Safety		
3	Description		
4	Transporting and storing		
5	Assembly		
6	Operation		
7	Cleaning, servicing and inspection		
8	Inspection and maintenance		
9.1	Preventing pain		
9.2	Troubleshooting and fault clearance		
9.2	Repair		
10	Recycling and disposal		
11	Documents		
12	Glossary		
13	Appendix		
14	Keyword index		

Table 2: Target groups-section matrix

1.6 Type number and model

These operating instructions are an integral part of pedelecs with the type numbers:

Type no.	Model	Pedelec type
21-17-3236	ZE 5R, Diamant	City and trekking bicycle
21-17-3237	ZE 5R, Wave	City and trekking bicycle
21-17-3234	ZE 5R Plus, Diamant	City and trekking bicycle
21-17-3235	ZE 5R Plus, Wave	City and trekking bicycle
22-15-2057	ZE 5F, Diamant	City and trekking bicycle
22-15-2058	ZE 5F, Wave	City and trekking bicycle
22-15-2057	ZE 5F Plus, Diamant	City and trekking bicycle
22-15-2058	ZE 5F Plus, Wave	City and trekking bicycle
22-15-2059	ZE 10, Diamant	City and trekking bicycle
22-15-2060	ZE 10, Wave	City and trekking bicycle
22-15-2061	SU-E FS 12, Diamant	City and trekking bicycle
22-15-2062	SU-E FS 12, Wave	City and trekking bicycle

Table 3: Type number, model and pedelec type

1.7 Frame number

Each frame has an individual frame number stamped on it (see Figure 2). The frame number can be used to associate the pedelec with the owner. The frame number is the most important identifier for verifying ownership.

1.8 Identifying the operating instructions

The operating instructions identification number is located in bottom left-hand corner of each page.

The identification number is composed of the document number, the version number and the release date.

2 Safety

2.1 Residual risk

Pedelecs pose the following residual risks:

- Risk of fire and explosion
- Electric shock
- Risk of a crash
- Risk of amoutation
- Malfunctions due to Bluetooth®
- · Key breaking off





2.1.1 Risk of fire and explosion

Never charge if there is a critical fault

If a charger is connected to the drive system when a critical error is reported, the battery may be damaged permanently and may catch fire.

► Connect charger to fault-free electric drive system only.

Protect against penetrating water

The battery is only protected from spray water. Penetration by water can cause a short circuit. The battery may self-ignite and explode.

- ▶ Never immerse battery in water.
- ▶ Take battery out of service if you suspect water has penetrated it.

Avoid heat

Temperatures over 60 °C can also cause liquid to leak from the battery and the battery will become damaged. The battery may self-ignite and explode.

- Protect the battery against heat.
- Never store next to hot objects.
- Never expose battery to continuous direct sunlight.
- Avoid wide temperature fluctuations.

Never use incorrect charger

Chargers with excessive voltage damage batteries. This may cause a fire or an explosion.

Only use approved batteries to charge.

Prevent short circuit due to interconnection

Metal objects may interconnect the battery's electrical terminals. The battery may self-ignite and explode.

- ▶ Never insert paper clips, screws, coins, keys and other small parts into the battery.
- ► Place the battery on clean surfaces only.

 Prevent charging socket and contacts against contamination from dirt, sand and similar.

Handling a damaged or faulty battery

Faulty batteries are hazardous goods. These include

- Cells or batteries which have been identified as faulty for safety reasons
- · Leaked batteries or which have released gas
- Cells or batteries which have sustained external or physical damage
- Cells or batteries whose safety has not been tested yet

The safety electronics may fail if the batteries are damaged or faulty. The residual voltage can cause a short circuit. The battery may self-ignite and explode.

- Only use and charge the battery and accessories if they are in perfect condition.
- ▶ Never open or repair the battery.
- ► Batteries with external damage must be removed from service immediately.
- ► If a battery is dropped or struck, remove it from service and keep it under observation for at least 24 hours.
- Contact specialist dealer.

Storing faulty batteries

Your specialist dealer will dispose of faulty batteries.

► Take faulty batteries to your specialist dealer.



 Store the battery in a safety container in a dry place as per special regulations (ADR SV 376, P908) until you dispose of it.



Figure 1: Example of a safety container

- Never store near flammable substances.
- ▶ Dispose of faulty batteries in the correct manner.

Avoid overheating in the charger

The charger heats up when charging the battery. If the battery is not allowed to cool down sufficiently, it can cause a fire or burns to the hands.

- ► Never use charger on a highly flammable surface.
- ▶ Never cover the charger during charging.
- Never leave battery unattended during charging.

Brakes and motors

Cool down overheated brakes and motors

The brakes and the motor may become very hot during operation. There is a risk of burns or fire in case of contact.

- Never touch the brakes or the motor immediately after a ride.
- Never place the pedelec on a flammable surface, such as grass or wood, directly after use.

2.1.2 Electric shock

2.1.2.1 Damage

Damaged chargers, cables and plug connectors increase the risk of electric shock.

► Check the charger, cable and plug connector before each use. Never use a damaged charger.

2.1.2.2 Water penetration

If water penetrates into the charger, there is a risk of electric shock.

▶ Never charge the battery outdoors.

2.1.2.3 Condensation

Condensation may form in the charger and in the battery when the temperature changes from cold to hot, causing a short circuit.

► Wait until both charger and battery are at room temperature before connecting them.

2.1.3 Risk of a crash

2.1.3.1 Incorrect quick release setting

Excessively high clamping force will damage the quick release and cause it to lose its function. Insufficient clamping force will result in unfavourable transmission of force. This can cause components to break. This will cause a crash with injuries.

- ► Never fasten a quick release using a tool (e.g. hammer or pliers).
- Only use the clamping lever with the specified set clamping force.

2.1.3.2 Incorrect tightening torque

If a screw is fastened too tightly, it may break. If a screw is not fastened enough, it may loosen. This will cause a crash with injuries.

▶ Always observe the indicated tightening torque on the screw or in the *operating instructions*.

2.1.3.3 Incorrect component

The wheels are designed exclusively for use with rim brakes or disc brakes. The wheel may break if an incorrect brake is used. This will cause a crash with injuries.

▶ Never use wheel with a different brake.

2.1.4 Risk of amputation

The brake disc in disc brakes is so sharp that it can cause serious injuries to fingers if they are inserted into the brake disc openings.

► Always keep fingers well away from the rotating brake discs.

2.1.5 Key breaking off

If you leave a key inserted when riding or transporting the pedelec, it may break off or the locking system may open accidentally.

▶ Pull the key from the battery lock.

2.2 Toxic substances

If substances are released or used which pose a risk to people and the environment, effective protective measures must be taken.

Possible hazards, contamination and health hazards due to:

- Carcinogenic, germ-cell-mutagenic and reproduction-toxic substances
- Toxic substances
- Irritants (skin, respiratory system) and corrosive substances

What might happen?

- · Serious harmful effects to health
- Threat to life
- Hazard to bystanders due to carry-over and contamination in the personal environment.



2.2.1 Carcinogenic substances

Carcinogenic hazardous substances are substances which can trigger cancer or promotes the formation of cancer. They are classified as categories 1A, 1B and 2 under European hazardous substances legislation and are labelled with the H-phrase codes H350/ H350i and H351. It is essential to carry out a professional risk assessment and select and use suitable protective measures due to the serious consequences for health and the occasionally long period of time it takes before the disease manifests itself.

Suspension oil

If you come into contact with the suspension oil in the fork, the 8pins seat post or the rear frame damper, it will irritate the respiratory tract and can cause cancer, sterility and changes to the genetic make-up of germ cells oil.

- ▶ Never dismantle the rear frame damper or the suspension fork.
- ▶ It is forbidden for pregnant women to carry out maintenance and cleaning tasks.
- Avoid skin coming into contact with suspension oil.



2.2.2 Toxic substances

Toxic substances (also known as poison or toxins) refer to substances which can cause damage to living beings if they enter the organism above a specific low dose. The more the ingested amount of a toxic substance increases, the greater the likelihood of damage to health due to poisoning is. This can lead to death.

Brake fluid

Brake fluid may leak out after an accident or due to material fatigue. Brake fluid can be fatal if swallowed or inhaled.

- ▶ Never dismantle the brake system.
- Avoid contact with skin.
- Do not inhale vapours.

Suspension oil

The suspension oil in the fork, the 8pins seat post and the rear frame damper is toxic to the touch.

- ▶ Never dismantle the rear frame damper or the suspension fork.
- ▶ It is forbidden for pregnant women to carry out maintenance and cleaning tasks.
- Avoid skin coming into contact with suspension oil.





2.2.3 Irritants and corrosive substances

Corrosive substances (also known as corrosives) destroy living tissue or attack surfaces. Corrosive substances may be in solid, liquid or gaseous form.

Irritants are hazardous substances which irritate the skin and mucous membranes once you come into contact with them. This may cause inflammation of the affected areas.

Defective battery

Liquids and vapours may leak from damaged or faulty batteries. Excessively high temperatures may also cause liquids and vapours to leak from the battery. Such liquids and vapours can irritate the airways and cause burns.

- ▶ Never dismantle the battery.
- ► Avoid contact with skin.
- ▶ Never inhale vapours.

2.3 Requirements for the pedelec rider

The pedelec rider must have adequate physical, motor and mental abilities to ride on public roads. A minimum age of 14 years is recommended.

2.4 Vulnerable groups

- ► Keep batteries and the charger away from children and people with reduced physical, sensory or mental capacities or lacking in experience and knowledge.
- ► Children and young people must be provided with comprehensive instructions by a legal guardian.

2.5 Personal protective equipment

- ▶ Wear a suitable helmet. The helmet must have a reflective strip or a light in a clearly visible colour.
- ▶ Wear sturdy shoes which are not too tightly laced.
- ▶ Wear padded cycling gloves.
- ▶ Wear clothing which is as bright or retroreflective as possible. Fluorescent materials are also suitable. High-visibility jackets and straps on your upper body ensure even greater safety. Never wear a skirt. Always wear trousers which reach down to your ankles instead.

2.6 Safety guards

Three safety guards on the pedelec protect pedelec riders against heat, dirt or moving parts:

- Chain or belt guards prevent clothing from being pulled into the drive train.
- The motor cover on the motor casing protects against heat.
- Mudguards protect against dirt and water splashing up from the road
- ▶ Never remove the guards.
- ► Check the guards on a regular basis.
- ► Take pedelec out of service if a guard is damaged or missing. Contact specialist dealer.

2.7 Safety markings and safety instructions

Pedelec and battery nameplates contain the following safety markings and safety instructions:

Symbol	Explanation
<u>(1)</u>	General warning
	Adhere to the instructions for use

Table 4: Meaning of safety markings

Symbol	Explanation
	Read the instructions
	Separate collection of electrical and electronic devices
X	Separate collection of ordinary and rechargeable batteries
	Must not be thrown into fire (burning prohibited)
	It is forbidden to open any batteries
	Device of protection class II
	Only suitable for use indoors
	Fuse (device fuse)
CE	EU conformity
	Recyclable material
max. 50°C	Protect from temperatures above 50 °C and direct sunlight

Table 5: Safety instructions

2.8 What to do in an emergency

2.8.1 Dangerous situation in road traffic

▶ If you encounter any hazards or dangers in road traffic, apply the brake until the pedelec comes to a halt. The brake acts as an emergency stop system in such cases.

2.8.2 Leaked brake fluid

- Remove those affected from the danger area to fresh air.
- ▶ Never leave those affected unattended.
- ► Remove any clothing contaminated with brake fluid immediately.
- ► Never inhale vapours. Ensure sufficient ventilation.
- Wear gloves and safety gloves as protective equipment.
- ► Keep unprotected persons away.
- ► Take care with leaked brake fluid as it poses a slip hazard.
- ► Keep leaked brake fluid away from naked flames, hot surfaces and sources of ignition.
- Avoid contact with skin and eyes.

If inhaled

- 1 Take in fresh air.
- 2 Immediately consult a doctor in case of any discomfort.

After skin contact

- 1 Wash affected skin with soap and water and rinse well.
- 2 Remove contaminated clothing.
- **3** Consult doctor in the event of pain or discomfort.

After contact with eyes

- 1 Rinse eyes under flowing water for at least ten minutes with the lids open; also rinse under lids.
- 2 Immediately consult a doctor in case of any pain or discomfort.

If swallowed

- 1 Rinse out mouth with water. Never induce vomiting. Risk of aspiration.
- 2 If a person is lying on their back and vomiting, place them in the recovery position.
- 3 Seek medical advice immediately.

Environmental protection measures

- ► Never allow brake fluid to flow into sewage, water courses or groundwater.
- Notify the relevant authorities if fluid penetrates the ground, water courses or the sewage system.
- Dispose of leaked brake fluid in an environmentally responsible way in accordance with statutory regulations (see Section 10.1).
- ► The brake system must be repaired immediately if brake fluid leaks out. Contact specialist dealer.

2.8.3 Battery vapour emission

Vapours may be emitted if the battery is damaged or used improperly. The vapours may cause respiratory tract irritation.

- 1 Get into fresh air.
- 2 Consult doctor in the event of pain or discomfort.

After contact with eyes

- 1 Carefully rinse eyes with plenty of water for at least 15 minutes. Protect unaffected eye.
- **2** Seek medical advice immediately.

After skin contact

- 1 Remove any solid particles immediately.
- 2 Remove contaminated clothing immediately.
- 3 Rinse the affected area with plenty of water for at least 15 minutes.
- **4** Then dab the affected skin gently. Do not rub drv.
- 5 Immediately consult a doctor if there is any redness, pain or discomfort.

2.8.4 Battery fire

The safety electronics may fail if the battery is damaged or faulty. The residual voltage can cause a short circuit. The battery may self-ignite and explode.

- 1 Keep your distance if the battery becomes deformed or starts to emit smoke.
- 2 If charging, remove the plug connector from the socket.
- 3 Contact the fire service immediately.
- ▶ Use Class fire extinguishers to put out the fire.
- ▶ Never extinguish damaged batteries with water or allow them to come into contact with water.

Inhaling vapours can cause intoxication.

- ➤ Stand on the side of the fire where the wind is blowing from.
- ▶ Use breathing apparatus if possible.

2.8.5 Oil and lubricant leaks from the rear frame damper

- ▶ Dispose of leaked oils and lubricants in an environmentally responsible way in accordance with statutory regulations (see Section 10.1).
- Contact specialist dealer.

2.8.6 Oil and lubricant leaks from the fork

Dispose of leaked oils and lubricants in an environmentally responsible way in accordance with statutory regulations (see Section 10.1).

3 Description

3.1 Proper use

All checklists and instructions for actions in these operating instructions met. Approved accessories can be installed by specialist staff.

Use the pedelec when it is in perfect, proper working order only. National requirements may apply to the pedelec which the standard equipment may not meet. Different regulations apply across the country to the riding light, reflectors and other components when riding on public roads. The general laws and the

regulations for the prevention of accidents and environmental protection in the respective country of use must be adhered to.

The rechargeable batteries are designed to supply power to the pedelec motor only. Never use the batteries for other purposes.

Each pedelec is assigned a pedelec type, which determines its proper use, function and area of use

City and trekking bicycle	Cycle for children and young adults	Mountain bike	Racing bicycle	Cargo bike	Folding bicycle
***	TXS S		\$		The state of the s
City and trekking bicycles are designed for comfortable, daily use and are suitable for riding on public roads.	Cycles for children and young adults are suitable for riding on public roads. Legal guardians must read the operating instructions before putting the bike into use. Tell children and young people what the operating instructions contain in a way appropriate to their age. Measure the height of adolescents and check the settings on the pedelec every three months for orthopaedic reasons. Check compliance with the maximum permitted total weight (PTW) every 3 months	frame structure and a wide transmission range. Mountain bikes are sports bikes and not a means of transport. In addition to being physically fit, riders need time to adapt to using the pedelec. Appropriate training is required for its use. It is especially important to practice braking and riding around bends. The strain on hands,	Racing bikes are designed for fast rides on roads and paths with a good, undamaged road surface. Racing bikes are sports bikes and not a means of transport. Racing bikes are characterised by their lightweight structure and a design which is stripped to the minimum parts required for riding. The frame geometry and the layout of the operating elements are designed to allow the bike to be ridden at high speeds. Learning how to ride slowly, apply the brakes and get on and off the bike safely takes practice due to the frame design. The riding position is athletic. The strain on hands, wrists, arms, shoulders, the neck and back is considerable. The riding position requires a high level of physical fitness.	Cargo bikes are suitable for transporting loads on public roads on a daily basis. The transportation of loads requires skill and physical fitness in order to balance the additional weight. The very varied loading conditions and weight distributions require special practice and skill when braking and riding in bends. A longer period is required to adaptation to the length, width and turning circle. You need to be cautious when riding a cargo bike. You must pay attention to the traffic on public roads and the condition of the route accordingly.	Folding bicycles are suitable for riding on public roads. Folding bikes can be folded together and thus save space when they are transported, e.g. in cars or on local transport. The folding bicycle's folding deisgn requires the use of smaller wheels and longer brake cables and Bowden cables. With increased strain, you should therefore expect a reduction in riding stability, braking power, comfort and durability.

Table 6: Proper use for every type of Pedelec

3.1.1 Improper use

Failure to adhere to the proper use poses a risk of personal injury and material damage. It is prohibited to use the pedelec in the following ways:

- when the electrical drive system been manipulated
- · riding with a damaged or incomplete pedelec
- · riding over steps
- riding through deep water
- · charging with an incorrect charger

- lending the pedelec to untrained pedelec rider
- · carrying other people
- · riding with excessive baggage
- riding with no hands
- · riding on ice and snow
- · improper servicing
- improper repair
- tough areas of use, such as professional competitions
- stunt riding or acrobatics.

City and trekking bicycle	Cycle for children and young adults	Mountain bike	Racing bicycle	Cargo bike	Folding bicycle
	N XS S		\$		
City and trekking bicycles are not sports bicycles. If used for sports, the rider can expect reduced riding stability and dimin- ished comfort	Cycles for children and young adults are not toys.	Mountain bikes must be retrofitted with riding light, a bell and other fittings as specified by national laws and regulations before they are used on public roads.	Racing bikes must be retrofitted with riding light, a bell and other fittings as specified by national laws and regula- tions before they are used on public roads.	Cargo bikes are not a touring or sports bicycle.	A folding bicycle is not a touring or sports bicycle.

Table 7: Notices on improper use

3.1.2 Permitted total weight (PTW)

The pedelec may only be loaded to its maximum permitted total weight (PTW).

The maximum permitted total weight is

- · the weight of the fully assembled pedelec
- plus body weight
- plus baggage

Type no.	Model	PTW [kg]
21-17-3236	ZE 5R, Diamant	150
21-17-3237	ZE 5R, Wave	150
21-17-3234	ZE 5R Plus, Diamant	150
21-17-3235	ZE 5R Plus, Wave	150
22-15-2057	ZE 5F, Diamant	150
22-15-2058	ZE 5F, Wave	150
22-15-2057	ZE 5F Plus, Diamant	150
22-15-2058	ZE 5F Plus, Wave	150
22-15-2059	ZE 10, Diamant	150
22-15-2060	ZE 10, Wave	150
22-15-2061	SU-E FS 12, Diamant	150
22-15-2062	SU-E FS 12, Wave	150

3.1.3 Environmental requirements

You can be ride the pedelec within a temperature range between -5 °C and +40 °C. The electric drive system is limited in its performance outside this temperature range.

Operating temperature -5... +40 °C

During winter use, especially at temperatures below 0 °C, we recommend that you don't insert a battery charged and stored at room temperature into the pedelec until just before setting off. We recommend using thermal protection sleeves when riding longer distances at low temperatures.

Temperatures under -10 °C and over +60 °C must be avoided as a general rule. Never put the battery in a car in summer or store it in direct sunlight.

You must also keep within the following temperature ranges:

Transportation temperature	+10 +40 °C
Storage temperature	+10 +40 °C
Work environment temperature	+15 +25 °C
Charging temperature	+10 +40 °C

The nameplate contains symbols for the pedelec's area of use.

► Check what tracks and roads you may ride on before setting off for the first time.

Area of use	City and trekking bicycle	Cycle for children and young adults	Mountain bike	Racing bicycle	Cargo bike	Folding bicycle
	1	XS S	S O	\$6		A D
1	Suitable for tarmacked and paved roads.	Suitable for tarmacked and paved roads.		Suitable for tarmacked and paved roads.	Suitable for tarmacked and paved roads.	Suitable for tarmacked and paved roads.
2	Suitable for tarmacked roads, cycle paths and firm gravel paths and roads, and longer sections with moderate slopes and jumps up to 15 cm.	Suitable for tarmacked roads, cycle paths and firm gravel paths and roads, and longer sections with moderate slopes and jumps up to 15 cm.	Suitable for tarmacked roads, cycle paths and firm gravel paths and roads, and longer sections with moderate slopes and jumps up to 15 cm.	Suitable for tarmacked roads, cycle paths and firm gravel paths and roads, and longer sections with moderate slopes and jumps up to 15 cm.		
~ 3		Suitable for tarmacked roads, cycle paths and easy to demanding off- road riding, sections with moderate slopes and jumps up to 61 cm.	Suitable for tarmacked roads, cycle paths and easy to demanding off- road riding, sections with moderate slopes and jumps up to 61 cm.			
4			Suitable for tarmacked roads, cycle paths and easy to demanding off- road riding, limited downhill use and jumps up to 122 cm.			

Table 8: Area of use

The pedelec is unsuitable for the following areas of use:

Area of use	City and trekking bicycles	Child's bicycles/ bicycles for young adults	Mountain bikes	Racing bicycle	Cargo bike	Folding bicycle
	20	M xs S	S	\$		A P
1	Never drive off- road or perform jumps.	Never drive off- road or perform jumps.		Never drive off- road or perform jumps.	Never drive off- road or perform jumps.	Never drive off- road or perform jumps.
2	Never drive off- road or perform jumps over 15 cm.	Never drive off- road or perform jumps over 15 cm.	Never drive off- road or perform jumps over 15 cm.	Never drive off- road or perform jumps over 15 cm.		
\sim 3		Never ride down- hill or perform jumps over 61 cm.	Never ride down- hill or perform jumps over 61 cm.			
\$ 4			Never traverse extremely difficult off-road terrain or perform jumps over 122 cm.			

Table 9: Unsuitable terrain

3.2 Nameplate

The nameplate is situated on the *frame. The exact* position of the nameplate is described in Figure 3.

The nameplate contains thirteen pieces of information.




Figure 2: Example ZEG nameplate

No.	Designation	Description	More information
1	CE marking	The manufacturer uses the CE marking to declare that the pedelec complies with applicable requirements.	
2	Manufacturer's contact details	You can contact the manufacturer at the address indicated.	Section 1.1
3	Type number	All pedelec models have an eight-digit type number, which is used to specify the design model year, the type of pedelec and the version.	Section 3.2
4	Maximum continuous power rating	The maximum continuous power rating is the greatest possible power for the electric motor output shaft over 30 minutes.	
5	Maximum permitted total weight	The maximum permitted total weight is the weight of the fully assembled pedelec with the body weight plus the baggage.	
6	Year of manufacture	The year of manufacture is the year in which the pedelec was manufactured.	
7	Pedelec type	Each pedelec is assigned a pedelec type, which determines its proper use, function and area of use.	Section 3.1
8	Safety markings	Safety markings warn of hazards.	Section 2.7
9	Disposal instructions	Follow the guidelines on waste disposal when disposing of the pedelec.	Section 10.1
10	Area of use	Ride pedelec in permitted locations only.	Section 3.1.3
11	Model year	The model year refers to the first production year that the series-manufactured pedelec was produced in the version concerned. The production period is between June 2021 and June 2022. The model year is sometimes different from the year of manufacture.	
12	Weight of the ready-to-ride pedelec	The weight of the ready-to-ride pedelec is specified as a weight of 25 kg or above and refers to its weight at the time of purchase. Any extra accessories need to be added to the weight.	Section 4.1
13	Shut-off speed	The speed that the pedelec reaches at the moment when the current has dropped to zero or to the no-load current value.	

Table 10: Explanation of information on the nameplate

3.3 Components

3.3.1 Overview



Figure 3: Pedelec viewed from right, Bull Cross Rider EVO 2 used as example

1	Front wheel	10	Seat post	20	Chain
2	Front wheel hub	11	Saddle	21	Frame number
3	<u>Fork</u>	12	Pannier rack	22	Chain guard
4	Front wheel mudguard	13	Reflector	23	<u>Motor</u>
5	Front light	14	Rear light	23	Motor cover
6	Steering headset	15	Rear wheel mudguard	24	Pedal
7	Handlebars	16	Rear wheel brake	25	Rechargeable battery
8	Stem	17	Kickstand	22	<u>Nameplate</u>
9	Frame	18	Rear wheel	26	Front wheel brake
		19	Gear shift and rear wheel		
			hub		

3.3.2 Chassis

The chassis comprises two components:

- · Frame and
- · steering system

3.3.2.1 Frame

The frame absorbs all forces which act on pedelec from body weight, pedalling and the ground. The frame also acts as a carrier for most components.

The frame geometry determines the pedelec's ride performance.

3.3.2.2 Steering system

The steering system components are:

- Steering headset
- Stem,
- Handlebars
- Fork.

3.3.2.3 Steering headset

The steering headset (also known as a bike headset or simply a headset) is the fork bearing system in the frame. A distinction is made between two different types:

- Conventional steering headsets for fork steerers with thread and
- Steering headsets for threadless fork steerers, what are known as headsets.

3.3.2.4 Stem

The stem connects the handlebars to the fork steerer tube. The stem is used to adjust the handlebars to body size. The stem is used to adjust the handlebar height and the gap between the handlebars and saddle (see Section 6.5.6).

Quickly adjustable stems

Quickly adjustable stems are an extension to the fork steerer. You can change the height and angle of quickly adjustable stems without any tools. Up to 3 settings can be adjusted, depending on the model:




Figure 4: Example – BY.SCHULZ seat Speedlifter Twist Pro SDS

- 1 Height adjustment
- 2 Twist function
- 3 Stem angle adjustment.

Adjusting the height and stem angle increase ride comfort as different riding positions can be adopted on longer rides. The twist function saves space when parking.



Figure 5: Twist function, using BY.SCHULZ as an example

3.3.2.5 Handlebars

The pedelec is steered using the handlebars. The handlebars are used to support the upper body and is the mount for most controls and displays (see Section 3.4.1).




Figure 6: Handlebar dimensions

The main dimensions of handlebars are:

- 1 Rise (height)
- 2 Width
- 3 Backsweep

3.3.2.6 Fork

The stem and handlebars are attached to the top end of the fork steerer. The axle is fastened to the fork ends. The wheel is fastened to the axle.




Figure 7: Overview of fork

- 1 Fork steerer
- 2 Side reflectors (optional)
- 3 Fork end
- 4 Fork leg

3.3.3 Suspension

Both forks and suspension forks are fitted in this model series.

3.3.3.1 Rigid fork

Rigid forks do not feature suspension. They transfer the used muscle and motor power to the road to optimum effect. Pedelecs with rigid forks consume less energy on steep roads and have a greater range than pedelecs with suspension.

3.3.3.2 Suspension fork

A fork deflects when a steel spring, air suspension, or both suspension types act on it.

Unlike rigid forks, suspension forks improve contact with the ground and thus enhance comfort using two functions: suspension and damping. The suspension in a pedelec prevents an impact, such as one caused by a stone lying in the pedelec's path, from being channelled directly into the body via the fork. The impact is absorbed by the suspension system instead. This causes the suspension fork to compress.

After compressing, the suspension fork returns to its original position. If the bike has a damper, the damper will slow this movement down. It thus prevents the suspension system from springing back in an uncontrolled manner and the fork from oscillating. Dampers which dampen compressive deflection movements, i.e. a compression load, are called compression dampers or compression dashpots.



Figure 8: Without suspension (1) and with suspension (2)

Dampers which dampen rebound deflection movements, i.e. a rebound load, are called rebound dampers or dashpots.

The compression can be disabled in suspension forks. A suspension fork will then behave like a rigid fork.

The stem and the handlebars are fastened to the fork steerer. The wheel is fastened to the axle.

Negative deflection (sag)

Negative deflection (sag) is the percentage of total deflection that is compressed by body weight, including equipment (such as a backpack), the riding position and frame geometry. Sag occurs whether you are actually riding or not. The pedelec rebounds at a controlled

speed if it is optimally adjusted. The wheel stays in contact with the ground when passing over bumps (blue line). The fork head, handlebars and body follow terrain (green line) when riding over bumps. The suspension motion is predictable and controlled.



Figure 9: Optimum fork ride performance

When optimally adjusted, the fork counteracts deflection on hilly terrain and stays higher in its

deflection range. This allows the rider to maintain the same speed more easily on hilly terrain.



Figure 10: Optimum fork ride performance on hilly terrain

When optimally adjusted, the fork deflects quickly and unhindered when the bike hits bumps and absorbs a bump. Traction is retained (blue line). The fork responds quickly to the bump. The headset and handlebars rise slightly when absorbing a bump (green line).




Figure 11: Optimum fork ride performance over bumps

Rebound damping

Rebound damping defines the speed at which the suspension rebounds after being loaded. Rebound damping controls the suspension fork extension and rebound speed, which, in turn, has an impact on traction and control. Rebound damping can be adjusted to body weight, spring stiffness, deflection, the terrain and the pedelec rider's preferences. If the air pressure or spring stiffness increases, the extension and rebound

speeds also increase. Rebound damping needs to be increased to achieve an optimal setting if the air pressure or spring stiffness is increased. The damper rebounds at a controlled speed if the fork is optimally adjusted. The wheel stays in contact with the ground when passing over bumps (blue line). The fork head, handlebars and body follow terrain (green line) when riding over bumps. The suspension motion is predictable and controlled.



Figure 12: Optimum fork ride performance

Suspension fork compression damper

The compression damper allows the rider to make quick adjustments to the fork's suspension behaviour to adapt to changes in terrain. It is intended for adjustments made during the ride. The compression damper controls the compression lifting speed or the extent to which the fork deflects during slow impacts. The compression damper affects the absorption of bumps when weight shifts or during transitions,

cornering and uniform impacts caused by bumps and when braking. When optimally adjusted, the fork counteracts deflection on hilly terrain, stays higher in its deflection range and helps to maintain speed when riding on hilly terrain. The fork deflects quickly and unhindered and absorbs the bump when the bike hits a bump. Traction is retained (blue line).



Figure 13: Optimum ride performance on hilly terrain

Steel suspension fork structure

The stem and the handlebars are fastened to the fork steerer. The wheel is fastened to the axle.




Figure 14: SR SUNTOUR steel suspension fork as an example

- 1 Fork steerer
- 2 Sag setting wheel
- 3 Crown
- 4 Dust seal
- 5 Q-Loc
- 6 Axle
- 7 Fork end
- 8 Stanchion
- 9 Compression damper

Air suspension fork structure

The air suspension fork comprises up to three assembly groups:

- Air suspension assembly (orange)
- Compression damper assembly (blue)
- At times, a rebound damper assembly (red)




Figure 15: Internal structure of air suspension fork

- 1 Air valve
- 2 Air valve cap
- 3 Fork steerer
- 4 Sag setting wheel
- 5 Rebound adjuster,
- 6 Stanchion

3.3.4 Wheel




Figure 16: Visible wheel components

- 1 Tyres
- 2 Rim
- 3 Spoke
- 4 Spoke nipples
- 5 Hub
- 6 Valve

The wheel comprises a tyre, an inner tube with a valve and the wheel itself.

3.3.4.1 Tyres

The tyre forms the outer section of the wheel. The tyre is pulled onto the rim. Tyres differ in design, profile and width, depending on their intended use.



Figure 17: Example: Information on tyres

Tyre size

The tyre size pressure range is indicated on the side of the tyre.

Tyre pressure

The permitted pressure range is indicated on the side of the tyre. It is indicated in psi or bars. The tyre is only able to support the pedelec if there is adequate tyre pressure. The tyre pressure must be adjusted to the body weight and then checked on a regular basis.

Tyre design types

There are five different tyre design types:

- Tube-type tyres,
- Tubeless tyres (also tubeless ready)
- Tubular or single tube tyres
- Solid tyres
- Mixed types.

3.3.4.2 Tube-type tyre

A distinction is made between different kinds of tube-type tyre:

- Clinchers with steel wire reinforcement in bead core
- Folding tyres with aramid fibre reinforcement in bead core
- Beaded edge tyres without reinforcement in the bead core but with pronounced beads that hook under the rim edge and overlap in the rim well.



Figure 18: Structure of tube-type tyre

- 1 Rim (see Section 3.3.4.2)
- 2 Carcass
- 3 Puncture protection belt (optional)
- 4 Tread with profile
- 5 Bead core

Carcass

The carcass is the tyre's supporting structure. There are usually three carcass plies beneath the tread. The carcass comprises a webbing with threads, usually made of polyamide (nylon). The webbing is coated with rubber on both sides and cut at an angle of 45°. The carcass gives the tyre stability thanks to this cut at an angle to the direction of travel. The carcass plies are woven with different densities, depending on the quality of the tyres. The density of the carcass fabric is indicated by the number of threads per inch, in EPI (ends per inch) or TPI (threads per inch). There are tyres with 20 to 127 EPI carcasses.

If the EPI value is higher, the diameter of the threads used is lower. Carcass plies with a higher EPI value have threads with a smaller diameter. The higher the EPI value:

- the less rubber is needed to encase the threads,
- · the lighter the tyres are
- the more flexible the tyres are and they consequently have less rolling resistance.
- The webbing is denser, so that there is greater resistance to penetration of foreign bodies.
 This increases puncture resistance.

In carcasses with 127 EPI, each individual thread is just 0.2 mm thick and, consequently, more vulnerable. This means that a 127 EPI tyre offers low puncture protection. 67 EPI offers the optimum compromise between weight and robustness.

Besides the webbing, the tyre's rubber compound is also important. The rubber compound comprises numerous parts:

40-60%	Natural and synthetic rubber
15–30%	Fillers, e.g. carbon black, silicic acid or silica gel
20–35%	 Anti-ageing agent Vulcanisation agent, e.g. sulphur Vulcanisation accelerator, e.g. zinc oxide Pigments and dyes

Table 11: Rubber compound in carcasses

Tread with profile

A rubber tread is attached to the exterior of the carcass.

The tread has little influence on riding characteristics on a smooth road. The grip between the road and tyre is mainly provided by the rolling friction between the rubber and the road surface.

Slicks and road tyres

Unlike cars, a pedelec will not aquaplane. The tread contact is small and the contact pressure high. Thanks to the small contact surface on narrow and treadless tyres, the tyre interlocks with the road surface finish. Theoretically, the tyre will not aquaplane until speeds of 200 km/h are reached.

On a clean road, whether dry or wet, slick tyres will grip more effectively than treaded tyres because the contact surface is larger. The rolling resistance of slick tyres is also lower.

Off-road tyres

The tread is highly important on terrain. In this case, the tread creates an interlock with the ground, thus enabling the driving, braking and steering forces to be transmitted. The MTB tread can also help improve control on dirty roads or farm tracks.

Tread blocks on MTB tyres deform as they meet the contact surface. The energy used for this is partly converted into heat. Another part is stored and converted into the tread block's sliding movement when it leaves the contact surface, which contributes to the tyre's wear.

If a tyre with a deep tread is used on asphalt, this may make an unpleasant noise. If a pedelec with an MTB tyre is mainly ridden on the road, it is thus best to change the tyre for a pair of tyres with as little tread as possible to reduce wear and save energy. In such a case, the specialist dealer needs to replace the tyre with a new one with a shallow tread.

Bead core

Tyre carcasses are wrapped around bead cores. Wrapping the carcass around both sides creates three carcass plies.

To ensure that tyres do not slip when inflated on the rim and have an effective grip, the bead cores are stabilised in two different ways:





Figure 19: Steel bead core (1) and Kevlar bead core (2)

- with a steel wire. These tyres are called clinchers.
- With aramid fibres (Kevlar®). These tyres are called folding tyres. Folding tyres are about 50-90 g lighter than clinchers. It can also be folded into a smaller pack size.

Puncture protection belt

There may be a puncture protection belt between the carcass and the tread.



Figure 20: Effect of puncture protection belt

Each tyre manufacturer has its own puncture protection classes which are not on par with one another.

3.3.5 Braking system

A pedelec's brake system is primarily operated using the brake lever on the handlebars.

- If the left brake lever is pulled, the brake on the front wheel is applied.
- If the right brake lever is pulled, the brake on the rear wheel is applied.

The brakes are used to regulate speed and make an emergency stop. Applying the brakes will bring the pedelec to a safe, rapid halt in an emergency.

The brake is applied using the brake lever either

- with the brake lever and shift cable (mechanical brake) or
- with the brake lever and hydraulic brake cable (hydraulic brake).

3.3.5.1 Mechanical brake

The brake lever is connected to the brake via a wire inside the shift cable (also known as a Bowden cable).



Figure 21: Bowden cable structure

3.3.5.2 Hydraulic brake

The brake fluid is in a closed hose system. If the brake lever is pulled, the brake fluid transfers pressure to the brake on the wheel.




Figure 22: Components in a brake cable

- 1 Brake cable
- 2 Cable clip
- 3 Union nut
- 4 Cover cap
- 5 Knob
- 6 Insert pin

3.3.5.3 Disc brake




Figure 23: Brake system with disc brake - example

- 1 Brake disc
- 2 Brake calliper with brake linings
- 3 Handlebars with brake lever
- 4 Front wheel Brake disc
- 5 Rear wheel brake disc

On a pedelec with a disc brake, the brake disc is permanently screwed to the hub.

You increase brake pressure by pulling the brake lever. The brake fluid is used to transfer pressure through the brake cables to the cylinders in the brake calliper.

The braking force is boosted by a speed reduction and applied to the brake linings. These apply the brake disc mechanically. If the brake lever is pushed, the brake linings are pressed against the brake disc and the wheel movement is decelerated until it comes to a stop.

3.3.6 Saddle

The purpose of the saddle is to absorb body weight, provide support and enable different riding positions. The shape of the saddle thus depends on the intended use of the pedelec and the rider's physique and posture.

When riding a pedelec, the rider's body weight is distributed between the pedals, the saddle and the handlebars. When the rider is an upright positon, the relatively small saddle area bears about 75% of the body weight. The seat area is one of the most sensitive regions of the body. The saddle should allow the rider sit free of pain and fatigue.

3.3.7 Seat post

Seat posts are not designed to fasten the saddle but also to adjust exactly to the optimum sitting position. The seat post can:

- · adjust the seat height in the seat tube
- adjust the saddle horizontally with a clamping mechanism and
- adjust the saddle angle by swivelling the entire saddle clamping mechanism.

Retractable seat posts feature a remote control on the handlebars, which can be used to lower the seat post at a traffic light, for example, and then raise it again.

3.3.7.1 Patent seat post



Figure 24: Example of ergotec patent seat post with either one or two seat clamp screws

Patent seat posts have a rigid link between the saddle and the post. Patent seat posts which are angled more markedly towards the rear are offset seat posts. Offset seat posts provide a greater distance between the saddle and the handlebars.

In patent saddle posts, the saddle is attached to the head with one or two seat clamp screws. It is recommended to lubricate the thread in these screws to ensure sufficient tension when tightening the screw.

Patent saddle posts are fastened into the seat tube with either a quick release or a screwable clamp.




Figure 25: Example of a quick release

3.3.7.2 Suspension seat post

Suspension seat posts can reduce shock after one-time hard impacts, thus improving ride comfort significantly. However, suspension seat posts are not able to compensate for bumps in the road.

If the seat post is the only suspension element, the entire pedelec is a non-suspended mass. This has an unfavourable effect on loaded touring bikes or pedelecs with child trailers.

Suspension seat posts feature small, heavy-duty slide bearings, guides and articulated joints. If they are not lubricated on a regular basis, the sensitive response behaviour diminishes considerably, causing excessive wear.

The pre-tensioning in non-damped suspension seat posts must be adjusted in such a way that the suspension seat post does not deflect with just body weight. This prevents the suspension seat post from deflecting and bobbing intermittently at higher pedalling frequencies or if the rider pedals irregularly.

The spring stiffness can be set lower with damped suspension seat posts, thus making use of the negative deflection.

3.3.8 Mechanical drive system

The pedelec is driven by muscle power, just like a bicycle.

The force which is applied by pedalling in the direction of travel drives the front chain wheel. The chain or belt transmits the force onto the rear chain wheel and then onto the rear wheel.




Figure 26: Diagram of mechanical drive system

- 1 Direction of travel
- 2 Chain or belt
- 3 Rear chainring or belt pulley
- 4 Front chainring or belt sprocket
- 5 Pedal

The pedelec is equipped with either a chain or belt drive.

3.3.8.1 Chain drive layout



Figure 27: Chain drive with derailleur gears

- 1 Rear derailleur
- 2 Chain

The chain drive is compatible with a

- Back-pedal brake,
- · Hub gear or
- · Derailleur gears.

3.3.8.2 Belt drive layout



Figure 28: Belt drive

- 1 Front belt sprocket
- 2 Rear belt sprocket
- 3 Belt

A belt drive is compatible with

- Back-pedal brake and
- Hub gear.

A belt drive is not compatible with derailleur gears.

3.3.9 Electric drive system

The pedelec has an electric drive system in addition to a mechanical one.




Figure 29: Diagram of an electric drive system with electric components

- 1 Front lamp
- 2 On-board computer
- 3.1 Integrated battery and/or
- 3.2 Frame battery and/or
- 3.3 Pannier rack battery
- 4 Rear light
- 5 Electric gear shift (alternative)
- 6 Motor
- (7) A charger which is designed for the battery (not shown).

3.3.9.1 Motor

As soon as the muscle power required for pedalling passes a certain level, the motor is activated gently and assists the pedalling motion. The pre-set level of assistance determines the motor output.

The motor switches off automatically as soon as the rider no longer pedals, the temperature is outside the permitted range, there is an overload or the shut-off speed of 45 km/h has been reached.

A push assist system can be activated. The speed depends on the selected gear. The motor continues to drive the pedelec as long as the rider presses the push assist button on the handlebars. The speed can be a maximum of 6 km/h in this case. The electric drive system stops when the push assist button is released.

The pedelec does not have a separate emergency shut-off button. In the event of an emergency, the motor can be stopped by removing the on-board computer. The mechanical brakes are used as an emergency stop system and bring the bicycle to a halt quickly and safely in the event of an emergency.

3.3.9.2 Rechargeable battery

BOSCH batteries are lithium ion batteries which are developed and manufactured to the latest technical standards. Each battery cell is protected by a steel cup and encased in a plastic battery housing. Applicable safety regulations are met. The battery has an interior electronic protection circuit, which is specifically designed for the charger and the pedelec. The battery temperature is monitored at all times. The battery is protected against deep discharge, overcharging, overheating and short circuit. In the event of a hazard, a protective circuit switches the battery off automatically.

The battery has a high energy content when charged. The code of practice for their safe handling is found in Section 2 Safety and Section 6.9 Rechargeable battery in the operating instructions. If the electric drive system is not used for 10 minutes and no button has been pressed on the on-board computer or the control panel, the electric drive system and the battery are automatically switched off to save energy.

The type and duration of operating conditions have a significant effect on the battery life. Just like any other lithium-ion battery, the battery will age naturally if it is not being used. The battery's service life can be extended if the battery is well maintained and stored at the correct temperature. The charging capacity will decrease with age, even if the battery is maintained properly. If the operating time is severely shortened after charging, this is a sign that battery has reached the end of its useful life.

Battery performance is reduced when the temperature drops since this increases electrical resistance. You should expect the range to be less than normal at low temperatures in winter. We recommend using thermal protection sleeves when riding longer distances at low temperatures.

Each battery has its own lock.

3.3.9.3 Frame battery

Three different types of frame batteries can be fitted:



Figure 30: Overview of frame battery




Figure 31: Details of frame battery

- 1 Battery housing
- 2 Battery lock
- 3 Battery key
- 4 On-off button (battery)
- 5 Battery level indicator (battery)
- 6 Charging port cover
- 7 Charging port

3.3.9.4 Pannier rack battery

Three different types of pannier rack batteries can be fitted:



Figure 32: Overview of pannier rack battery




Figure 33: Details of pannier rack battery

- 1 Battery housing
- 2 Charging port
- 3 Charging port cover
- 4 Battery lock
- 5 Battery key
- 6 Battery level indicator (battery)
- 7 On-Off button (battery)

3.3.9.5 Integrated battery

Four different types of pannier rack batteries can be fitted:




Figure 34: Overview of integrated battery




Figure 35: Integrated battery in detail

- 1 Battery key
- 2 Retainer guard
- 3 Securing hook
- 4 On-off button (battery)
- 5 Battery level indicator (battery)
- 6 Battery housing

3.3.9.6 Charger

Each pedelec is supplied with a charger. As a general rule, any BOSCH charger may be used:

- The 2A compact charger
- The 4A standard charger
- The 6A fast charger

Observe the operating instructions in the Section 11.4 Documents.

3.3.10 Lighting

When the riding light is activated, the front light and rear light are switched on together at the same time.

3.3.11 On-board computer

The pedelec has a BOSCH Intuvia on-board computer.

The on-board computer controls the drive system and displays the journey data.

The rider can switch off the electric drive system by removing the on-board computer.

The battery powers the on-board computer if the on-board computer is inserted into its mount, a sufficiently charged battery is inserted into the pedelec and the electric drive system is switched on. If the rider removes the display from its mount, the on-board computer is powered by a on-board computer battery. The on-board computer battery cannot be replaced.



Figure 36: BOSCH Intuvia on-board computer

3.3.11.1 USB port

There is a USB port beneath the rubber cover on the right-hand edge of the on-board computer.

3.3.12 Control panel

The control panel controls the electric drive system.



Figure 37: Overview of control panel

3.4 Description of controls and screens

3.4.1 Handlebars




Figure 38: Detailed view of handlebars with BOSCH Intuvia on-board computer, example

- 1 Rear wheel hand brake
- 2 Bell
- 3 Front lamp
- 4 On-board computer
- 5 Front wheel handbrake
- 6 Handle

- 7 Seat post remote control
- 8 Control panel
- 9 Sag setting wheel
- 10 Fork lock, lockout
- 11 Shift indicator
- 12 Shifter

3.4.2 On-board computer

The on-board computer is operated using four buttons on its casing and the buttons on the control panel.




Figure 39: BOSCH Intuvia on-board computer layout

- 1 Riding light button
- 2 Info button (on-board computer)
- 3 RESET button
- 4 On-Off button (on-board computer)
- 5 On-board computer mount
- 6 On-board computer
- 7 USB port
- 8 USB port protective flap

The on-board computer has seven indicators:




Figure 40: Overview of on-board computer display screen

- 1 Riding light indicator, see Section <u>3.4.2.1</u>
- 2 Level of assistance indicator, see Section <u>3.4.2.2</u>
- Motor power used indicator, see Section 3.4.2.4
- 4 Battery level indicator (on-board computer), see Section <u>3.4.2.3</u>
- 5 Gear recommendation indicator, see Section <u>3.4.2.5</u>
- 6 Tachometer display, see Section <u>3.4.2.6</u>
- 7 Function display, see Section <u>3.4.2.7</u>

3.4.2.1 Riding light indicator

The riding light indicator lights up when the riding light is activated.

3.4.2.2 Level of assistance indicator

The higher the selected level of assistance is, the more the electric drive system assists the rider when pedalling. These levels of assistance are available.

Level of assistance	Use
TURBO	Maximum assistance up to high pedalling frequencies for sport riding.
SPORT	Powerful assistance, for sport rides on mountainous rides and on urban roads.
TOUR	Constant assistance, for long-range tours.
ECO	Low assistance for maximum range with maximum efficiency.
OFF	When the drive system is switched on, the motor assistance is switched off. The pedelec can be used like a normal bicycle by simply pedalling. Push assist is disabled.

Table 12: Overview of levels of assistance, standard

The eMTB MODE level of assistance is available for Performance Line CX drives. In eMTB MODE Mode, the assistance factor and the torque are adjusted dynamically, depending on the pedalling force applied to the pedals. If the pedelec has been configured with eMTB MODE, eMTB MODE will appear briefly when the SPORT level of assistance is selected.

Level of assistance	Use
TURBO	Maximum assistance up to high pedalling frequencies for sport riding.
еМТВ	Optimum assistance on any terrain, sporty start-up, improved dynamics and maximum performance.
TOUR	Constant assistance, for long-range tours.
ECO	Low assistance for maximum range with maximum efficiency.
OFF	When the drive system is switched on, the motor assistance is switched off. The pedelec can be used like a normal bicycle by simply pedalling. Push assist is disabled.

Table 13: Overview of levels of assistance - eMTB mode

3.4.2.3 Charge level indicator (on-board computer)

The battery level indicator displays the pedelec battery level, not the level for the on-board computer's internal battery. If the on-board computer is removed from its mount, the last battery level displayed is saved. Each bar in the battery symbol on the screen represents 20% capacity.

Symbol	Meaning
	The battery is fully charged.
	The battery needs to be recharged.
	The LEDs on the charge level indicator go out. The capacity for drive assistance has been used up and assistance is gently switched off. The remaining capacity is reserved for lighting and the on-board computer. The screen flashes. The pedelec battery capacity is sufficient to provide 2 more hours of lighting. Other electrical loads, such as automatic gears and charging of external devices connected to the USB port, are not taken into account here.

Table 14: Overview of battery level indicator

If a pedelec is used with two batteries, the battery level indicator shows the charge level for both batteries.

If both batteries are being charged on a pedelec, the function display shows the charging progress for both batteries. You can see which of the two batteries is being charged as the indicator will flash on the battery being charged.




Figure 41: The left-hand battery is being charged

You can also see the battery charge level on the level indicator LEDs (battery).

3.4.2.4 Indicator for motor power used

If the motor is active, the motor power used indicator is shown on the on-board computer display. The maximum motor power depends on the selected level of assistance. A long bar indicates high power consumption.

3.4.2.5 Gear recommendation indicator

Pedalling frequencies higher than 50 revolutions per minute optimise drive unit efficiency. However, very slow pedalling uses up a great deal of energy. The speed and range can be increased while applying the same force if you select the right gear.

The gear recommendation function reacts to excessively slow or excessively quick pedalling and recommends a change of gear.

✓ The gear recommendation function has to be switched on in the system settings.

Symbol	Use
A	Pedalling frequency is too high, a higher gear is recommended
▼	Pedalling frequency is too low, a lower gear is recommended

Table 15: Symbols of the gear recommendation function

3.4.2.6 Tachometer indicator

The tachometer indicator shows the current speed at all times.

You can select whether the speed is displayed in kilometres or miles in the system settings.

3.4.2.7 Function display

The function display shows texts and readings. Three different types of information are shown:

- Journey information,
- System settings and data, and
- System messages.

3.4.2.8 Journey information

Depending on the type of pedelec, the function display may show up to seven journey information items. The displayed journey information can be switched.

Display	Function
CLOCK	Current time
MAX. SPEED	Maximum speed reached since the last RESET
AVG. SPEED	Average speed reached since the last RESET
TRIP TIME	Journey time since last RESET
RANGE	Estimated range of the available battery charge
ODOMETER	Display of the total distance travelled (cannot be changed)
TRIP DISTANCE	Distance travelled since the last RESET

Table 16: Journey information

3.4.2.9 Additional journey information

Only applies to SHIMANO DI2 automatic hub gears

The following additional function is available on the function display:

Display	Change
AUTO: ON/AUTO: OFF	This menu option indicates whether the automatic mode is switched on or off

Table 17: Additional journey information for SHIMANO DI2 automatic hub gears

Applies only to eShift with manual Shimano DI2 hub gears

The following additional function is available on the function display:

Display	Change
GEAR	The gear shift currently selected is displayed on the on-board computer display screen. The new selected gear is shown briefly on the on-board computer each time it is changed.

Table 18: Additional eShift journey information with manual Shimano DI2 hub gears

Applies only to eShift with SHIMANO DI2 automatic hub gears

The following additional function is available on the function display:

Display	Change
GEAR	The gear shift currently selected is displayed on the on-board computer display screen. The new selected gear is shown briefly on the on-board computer each time it is changed.

Table 19: Additional eShift journey information with Shimano DI2 hub gears

Applies only to eShift with NuVinci HISync/ ENVIOLO with Optimized H|Sync

The following additional function is available on the function display:

Display	Change
± NUVINCI CADENCE/ ± NUVINCI GEAR:	The gear shift currently selected is displayed on the on-board computer display screen. The new selected gear is shown briefly on the on-board computer each time it is changed.
	The standard setting is ± NuVinci cadence.

Table 20: Additional journey information eShift with NuVinci HISync/enviolo with Optimized HISync

Applies only to eShift with ROHLOFF E-14 Speedhub 500/14

The following additional functions are available on the function display:

Display	Change
GEAR	The gear shift currently selected is displayed on the on-board computer display screen. The new selected gear is shown briefly on the on-board computer each time it is changed.

Table 21: Additional journey information eShift with ROHLOFF E-14 Speedhub 500/14

3.4.2.10 System settings and data

The system settings need to be opened to see the system settings and specifications. The system setting values can be changed but the system specifications can't.

Display	Function	
Changeable system settings		
- CLOCK +	Changes the time	
- WHEEL CIRCUM +	Wheel circumference in mm	
- ENGLISH +	Changing the language	
- UNIT KM/MI +	Select whether the speed and distance are displayed in kilometres or miles	
- TIME FORMAT +	Select whether the time is displayed in 12-hour clock or 24-hour clock format	
- SHIFT RECOM. OFF +	Switches the gear recommendation on and off	
Invariable system settings		
POWER ON HOURS	Display of the total journey duration	
DISPL. VX.X.X.X	On-board computer software version	
DU VX.X.X.X	Drive system software version	
DU SN XXXXXXX/XXX	Drive system serial number	
DU PN XXXXXXXXX	Drive unit type part number	
SERVICE MM/YYYY	(Alternative) defined inspection date	
SERV. XX KM/MI	(Alternative) defined inspection	
BAT. VX.X.X	Software version	
1.BAT VX.X.X	Software version	
2.BAT VX.X.X.X	Software version	

Table 22: System settings

3.4.2.11 Additional system settings

Applies only to eShift with SHIMANO DI2 automatic hub gears

Display	Change
Start gear +	This is where you can set the start gear. The automatic gear switch function is switched off in Position – . This menu option is only shown when the on-board computer is positioned in its mount.
Gear adjustment	You can use this menu option to make a fine adjustment to the SHIMANO DI2. You'll find the specified setting range described in the gear manufacturer's operating instructions. Make fine adjustments if the gear shift makes unusual noises. This menu option is only shown when the onboard computer is positioned in its mount.
Gear vx.x.x.x:	this is the gear software version. This menu option is only shown when the on-board computer is positioned in its mount. This menu option is only shown if you have an electronic control gear.

Table 23: Changing the system settings

Applies only to eShift with manual SHIMANO DI2 hub gears

Display	Change
Start gear +	This is where you can set the start gear. The automatic gear switch function is switched off in Position – . This menu option is only shown when the on-board computer is positioned in its mount.
Gear adjustment	You can use this menu option to make a fine adjustment to the SHIMANO DI2. You'll find the specified setting range described in the gear manufacturer's operating instructions. Make fine adjustments if the gear shift makes unusual noises. This menu option is only shown when the on-board computer is positioned in its mount.
Gear vx.x.x:	this is the gear software version. This menu option is only shown when the on-board computer is positioned in its mount. This menu option is only shown if you have an electronic control gear.

Table 24: Changing the system settings

Applies only to eShift with SHIMANO DI2 automatic hub gears

Display	Change
Gear adjustment	You can use this menu option to make a fine adjustment to the SHIMANO DI2. You'll find the specified setting range described in the gear manufacturer's operating instructions. Make fine adjustments if the gear shift makes unusual noises. This menu option is only shown when the on-board computer is positioned in its mount.
Gear recovery	You can use this menu option to reset the rear derailleur if it has been detached – due to a crash or impact against the derailleur, for example. You will find a description of how to reset the gear shift in the gear shift manufacturer's operating instructions. This menu option is only shown when the on-board computer is positioned in its mount.
Gear vx.x.x:	this is the gear software version. This menu option is only shown when the on-board computer is positioned in its mount. This menu option is only shown if you have an electronic control gear.

Table 25: Changing the system settings

Applies only to eShift with NuVinci HISync/ ENVIOLO with Optimized HISync

Display	Change
Gear calibration	This is where the continuously adjustable gear is calibrated. You might need to perform calibration while riding in the event of a fault. The menu option is only shown when the on-board computer is positioned in its mount.
	Press on the Lighting button to confirm calibration.
	► Follow the instructions.
Gear vx.x.x.x:	this is the gear software version. This menu option is only shown when the on-board computer is positioned in its mount. This menu option is only shown if you have an electronic control gear.

Table 26: Changing the system settings

Applies only to eShift with ROHLOFF E-14 Speedhub 500/14

Display	Change
Start gear	This is where you can set the start gear. The automatic gear switch function is switched off in Position – . This menu option is only shown when the on-board computer is positioned in its mount.
Gear vx.x.x.x:	this is the gear software version. This menu option is only shown when the on-board computer is positioned in its mount. This menu option is only shown if you have an electronic control gear.

Table 27: Changing the system settings

3.4.2.12 System message

The drive system monitors itself continuously and if an error is detected, it is indicated by a system message. The system may switch off automatically depending on the type of error. You will find more information and a table containing all system messages in Section 6.2.

3.4.3 Control panel

The on-board computer is operated using four buttons on the control panel.




Figure 42: Overview of the BOSCH control panel

- 1 Info button (control panel)
- 2 Push Assist button
- 3 Plus button (control panel)
- 4 Minus button (control panel)

3.4.4 Gear shift

3.4.4.1 SHIMANO derailleur gears

Only applies to vehicles with this equipment

The gear shift is on the right of the handlebars. The gear shift has one or two shifters.

SHIMANO SL-M315 gear shift




Figure 43: Example of SHIMANO SL-M315

- 1 Shifter A
- 2 Shifter B

SHIMANO SL-M3100 gear shift




Figure 44: Example of SHIMANO SL-M3100

- 1 Shifter A
- 2 Shifter B (optional)

3.4.5 Handbrake

There is a handbrake on the left and right of the handlebars.




Figure 45: Front wheel (2) and rear (1) brake levers – Shimano brake used as an example

The left handbrake (2) controls the front wheel brake.

The right handbrake (1) controls the rear wheel brake.

3.4.6 Fork lock

Only applies to vehicles with this equipment

The suspension in suspension forks is adjusted using fork locks. The fork locks are either directly on the suspension fork or can be controlled using the remote control on the handlebars.

3.4.6.1 SR Suntour

The following (compression dampers) may be featured on the suspension fork:

Suspension fork	RL	RL-R	LO	LO-R	HLO
	Lockout with remote control	Lockout with remote control + rebound adjustment	Lockout on the fork	Rebound adjustment + lockout on the fork	Hydraulic lockout
		W Lost	Lotte Lotte	Tool Look	
Axon		х		х	
CR			х		х
M3010					
MOBIE25		х		х	
NCX	x		x		
NEX	x		x		х
NVX	x				х
XCE					
хсм	х		х	х	
XCR	x	х	x	x	
хст					х

Table 28: Fork lock by suspension fork

3.4.7 Battery level indicator (battery)

Each battery has its own level indicator:




Figure 46: Position of charge level indicator on pannier rack battery




Figure 47: Position of battery level indicator on seat tube battery




Figure 48: Position of charge level indicator on integrated battery

- 1 On-Off button (battery)
- 2 Battery level indicator (battery)

3.4.7.1 Battery level indicator (battery)

The five green LEDs on the battery level indicator show the charge level when the battery is switched on. Each LED represents 20% of battery capacity.

LED 1,2,3,4,5	Battery level
••••	10080%
••••	7960%
•••00	5940%
••000	3920%
•0000	1915%
00000	50%

Figure 49: Battery level indicator

Symbols:



All five LEDs will light up when the battery is fully charged. The charge level for the activated battery is also shown on the on-board computer.

If the battery level falls below 5%, all the LEDs on the operating status and battery level indicator will go out.

The battery level is still shown on the on-board computer.

3.5 Technical data

3.5.1 Pedelec

Power output/system	250 W (0.25 kW)
Shut-off speed	25 km/h

Table 29: Pedelec technical data

3.5.2 Emissions

The safety requirements as per Electromagnetic Compatibility Directive 2014/30/EU have been met. The pedelec and the charger can be used in residential areas without restriction.

A-weighted emission sound pressure level	< 70 dB(A)
Total vibration level for the hands and arms	< 2.5 m/s ²
Highest effective value of weighted acceleration for the entire body	< 0.5 m/s²

Table 30: Emissions from the pedelec*

3.5.3 BOSCH Intuvia on-board computer

Internal lithium ion battery	3.7 V, 230 mAh
Operating temperature	-5 +40 °C
Storage temperature	-10 +40 °C
Charging temperature	0 +40 °C
Protection class (with USB cover closed)	IPx54
Weight about	0.15 kg

Table 31: Technical data for BOSCH Intuvia on-board computer, BUI255

3.5.4 **USB** port

Charge voltage	5 V
Charging current	Max. 500 mA

Table 32: USB port technical data

3.5.5 BOSCH Performance Line CX motor

Maximum continuous power rating	250 W
Max. torque	85 Nm
Nominal voltage	36 V DC
Protection class	IP54
Weight	3 kg
Operating temperature	-5 +40 °C
Storage temperature	-10 +40 °C

Table 33: Technical data for BSOCH Performance Line CX motor, BDU450CX

3.5.6 Battery BOSCH PowerTube 625

Nominal voltage	36 V
Nominal capacity	16.7 Ah
Energy	625 Wh
Weight	3.5 kg
Protection class	IP54
Operating temperature	-5 +40 °C
Storage temperature	+10 +40 °C
Permitted charging temperature range	0 40 °C

Table 34: Technical data for BOSCH PowerTube 625, BBP282 and BBP283 vertical batteries

3.5.7 Bicycle lighting

Voltage about	12 V
Maximum output	
Front light	17.4 W
Rear light	0.6 W

Table 35: Bicycle lighting

3.5.8 Torque

Model	Torque	Screw
3.5.8.1 Hub		
SHIMANO quick release version FH-M3050, FH-M4050, FH-MT200-B, FH-MT400, FH-MT400-B, FH-MT500, FH-MT500-B, FH-MT510, FH-MT510-B, FH-RM33, FH-RM35, FH-TX505, FH-TY505, FH-UR600 HB-M3050, HB-M4050, HB-MT200, HB-M7400, HB-MT400-B, HB-RM33 HB-TX505 SLX FH-M7000, FH-M7010, FH-M7010-B HB-M7000, HB-M7010, HB-M7010-B DEORE FH-M618, FH-M618-B, FH-M6000, FH-M6010, FH-M6010-B, HB-M618, HB-M618-B, HB-M6000, HB-M6010, HB-M6010-B	40.11	
Brake disc attachment screw SHIMANO E-THRU quick release axle	40 Nm	Adjustable spanner and special tool TL-LR15 (SHIMANO)
Retaining ring for brake disc	40 Nm	Special tool TL-FC36 (SHIMANO)
SHIMANO, FH-M3050, FH-M4050, FH-M7000, FH-M6000, FH-RM33, FH-RM35, FH-UR600 Attachment screw, freewheel body	35 50 Nm	10 mm hex bit
SHIMANO, FH-MT200, FH-TX505,		
FH-TY505 Attachment screw, freewheel body	147 200 Nm	12 mm hex bit
SHIMANO, FH-M7010, FH-M7010-B, FH-M6010, FH-M6010-B, FH-M618, FH-M618-B, FH-MT400, FH-MT400-B FH-MT500, FH-MT500-B, FH-MT510 FH-MT510-B Lock nut	15 20 Nm	Hub spanner, 17 mm
SHIMANO , HB-M7000, HB-M6000, HB-M4050 Lock nut	10 15 Nm	Hub spanner, 13 mm and 17 mm
SHIMANO, HB-M7010, HB-M7010-B, HB-M6010, HB-M6010-B, HB-M618, HB-M618-B, HB-MT400, HB-MT400-B Lock nut	21 26 Nm	Hub spanner, 22 mm
SHIMANO hub dynamo E2 model	20 - 25 Nm	Screw wrench
SHIMANO hub dynamo J2 model	20 Nm	Screw wrench
SHIMANO hub dynamo J2-A model	20 Nm	Screw wrench
3.5.8.2 Shifter		
SHIMANO DEORE SL-M4100 Attachment screw	3 Nm	4 mm hex bit
SHIMANO DEORE SL-M5100 Attachment screw	3 Nm	4 mm hex bit
SHIMANO DEORE SL-M6100 Attachment screw	3 Nm	4 mm hex bit
SHIMANO DEORE XT SL-M8100 Attachment screw	3 Nm	4 mm hex bit
SHIMANO DEORE XT SL-M8130 Attachment screw	3 Nm	4 mm hex bit

SHIMANO SI V SI M7400		
SHIMANO, SLX SL-M7100 Attachment screw	3 Nm	4 mm hex bit
SHIMANO XTR SL-M9100 Attachment screw	3 Nm	4 mm hex bit
3.5.8.3 Rear derailleur		
SHIMANO for MTB/trekking Attachment screw, standard type	8–10 Nm	Hex key, 5 mm
SHIMANO for MTB/trekking Attachment screw with bracket	3–4 Nm	Hex key, 5 mm
SHIMANO for BMX bicycles Attachment screw	3–4 Nm	Adjustable spanner
SHIMANO for MTB/trekking Attachment screw for inner cable	6–7 Nm	Hex key, 4 mm/ Hex key, 5 mm/ Adjustable spanner
SHIMANO for MTB/trekking Attachment screw for the guide pulley	2.5–5 Nm	Hex key, 3 mm
SHIMANO for MTB/trekking Attachment screw for the tensioning roller	2.5–5 Nm	Hex key, 3 mm
SHIMANO for racing bicycles Attachment screw, standard type	8–10 Nm	Hex key, 5 mm
SHIMANO for racing bicycles Attachment screw with bracket	3–4 Nm	Screw wrench
SHIMANO for racing bicycles Attachment screw for inner cable	6–7 Nm	Hex key, 4 mm/ Hex key, 5 mm
SHIMANO for racing bicycles Attachment screw for pulley	2.5–5 Nm	Hex key, 3 mm
3.5.8.4 Front derailleur		
SHIMANO for MTB/trekking Attachment screw, clip type, E-type and direct fitting	5–7 Nm	Hex key, 5 mm
SHIMANO for MTB/trekking Inner bearing adapter	35–50 Nm	
SHIMANO for MTB/trekking Top swing screw, clip type and e-type	5–7 Nm	Hex key, 5 mm/ Screw wrench, 9 mm
SHIMANO for MTB/trekking Down swing screw, clip type, direct fitting	5–7 Nm	Hex key, 5 mm
SHIMANO for racing bicycles Attachment screw	5–7 Nm	Hex key, 5 mm/ Screw wrench, 9 mm
SHIMANO for racing bicycles Attachment screw, Bowden cable	6–7 Nm	Hex key, 5 mm/
3.5.8.5 Freewheel		
SHIMANO	35 Nm	Multiple freewheel tool TL-FW30
3.5.8.6 Axle		
Conventional axle nut	35 40 Nm*	
SR SUNTOUR screw-on axle 12AH2 Axle Securing screw	8–10 Nm 5–6 Nm	6 mm hex bit 5 mm hex bit
SR SUNTOUR screw-on axle 15AH2 Axle Securing screw	8–10 Nm 5–6 Nm	6 mm hex bit 5 mm hex bit

3.5.8.7 Handlebars		
Clamping screw, conventional	5 7 Nm*	
CONTROL TECH, handlebar clamp with one or two screws	14 16 Nm	
SHIMANO, handlebar clamp with one or two screws	20 29 Nm	
3.5.8.8 Stem		
FSA, carbon quill stem,	9 Nm	15 mm spanner
3.5.8.9 Seat post		
by.schulz, G1 M8 seat clamp screw M5 fixing grub screws	20 24 Nm 3 Nm	2.5 mm hex bit
by.schulz, G2 M6 seat clamp screw M5 fixing grub screws	12 14 Nm 3 Nm	2.5 mm hex bit
eightpins NGS2 Seat post axle Slipper clutch Valve cover Postpin axle Rear clamping screw (saddle) M5 attachment screw for outer sleeve	8 Nm 18 Nm 0.5 Nm 8 Nm 8 Nm 0.5 Nm	6 mm hex bit 3 mm hex bit 5 mm hex bit 5 mm hex bit 3 mm hex bit 3 mm hex bit
eightpins H01 Seat post axle Slipper clutch Valve cover Postpin axle Rear clamping screw (saddle) M5 attachment screw for outer sleeve	8 Nm 18 Nm 0.5 Nm 8 Nm 8 Nm 0.5 Nm	6 mm hex bit 3 mm hex bit 5 mm hex bit 5 mm hex bit 3 mm hex bit 3 mm hex bit
LIMOTEC LimoDP Clamping screw for seat post Clamping screw for saddle	6 7 Nm 7 9 Nm	
SR SUNTOUR suspension seat post Seat clamp screw M5 fixing grub screws	15 18 Nm 3 Nm	2.5 mm hex bit
3.5.8.10 Seat post remote control		
eightpins Attachment screw Bowden cable fastener	2.5 Nm 5 Nm	4 mm hex bit 3 mm hex bit
3.5.8.11 Pedal		
Pedal, conventional	33 35 Nm	Screw wrench, 15 mm
SHIMANO Attachment screw	35–55 Nm	Screw wrench, 15 mm
3.5.8.12 Handbrake		
SHIMANO Attachment screw	6–8 Nm	Hex key, 4 mm Hex key, 5 mm
SHIMANO Attachment screw, BL-M987/ BL-M9000/BL-M9020	4–6 Nm	Hex key, 4 mm
SHIMANO, lever for disc brake Bleed nipple	4–6 Nm	Socket wrench, 7 mm
SHIMANO, lever for disc brake Bleed screw	0.3–0.5 Nm	

3.5.8.13 Brake cable			
SHIMANO Connecting screw, handbrake	5–7 Nm	Screw wrench, 8 mm	
SHIMANO Connecting screw, brake calliper, version for banjo type connection	5–7 Nm 8–10 Nm	Hex key, 3 mm Hex key, 4 mm	
SHIMANO Connecting screw for brake calliper, straight version	5–7 Nm	Hex key, 3 mm	
SHIMANO for racing bicycles Connecting screw for cable sleeve	5–7 Nm	Screw wrench, 8 mm	
3.5.8.14 Brake linings			
SHIMANO Circlip	2–4 Nm	Hex key, 3 mm Slotted-head screwdriver	
3.5.8.15 Brake calliper			
SHIMANO Adapter attachment screw and brake calliper attachment screw, version with IS brake mount	6–8 Nm		
SHIMANO Brake calliper attachment screw, post- mount version	6–8 Nm		
3.5.8.16 Disc brake			
SHIMANO for centre lock type Attachment screw, quick release	40–50 Nm	TL-LR15 TL-FC36/TL-LR11 Adjustable spanner	
SHIMANO for centre lock type Attachment screw, nut version	40–50 Nm	TL-LR10 Screw wrench	
SHIMANO for 5-hole version Attachment screws	2–4 Nm	Star bit [no. 25]	
SHIMANO for 6-hole version Attachment screws	2–4 Nm	Star bit [no. 25]	
3.5.8.17 V-Brake brake			
SHIMANO Attachment screw for connecting cable	6–8 Nm	Hex key, 5 mm	
SHIMANO Brake shoe nut	6–8 Nm	Hex key, 5 mm	
SHIMANO Bowden cable attachment screw	6–8 Nm	Hex key, 5 mm	
3.5.8.18 Dual pivot rim brake			
SHIMANO Attachment screw	8–10 Nm	Hex key, 5 mm	
SHIMANO, models with nut Attachment screw	8–10 Nm	Screw wrench, 10 mm	
SHIMANO Attachment screw for brake shoe	5–7 Nm	Hex key, 4 mm	
SHIMANO, left side Attachment screw for brake cable	6–8 Nm	Hex key, 5 mm	
SHIMANO, right side Attachment screw for brake cable	1–1.5 Nm	Hex key, 2 mm	

5–7 Nm	Hex key, 5 mm
8–9 Nm	Hex key, 5 mm Screw wrench, 10 mm
6–8 Nm	Hex key, 5 mm
14–16 Nm	
16–17 Nm	
12 14 Nm	Hex key, 5 mm/star bit [no. 30]
12 14 Nm 16–17 Nm	Hex key, 5 mm/star bit [no. 30] Hex key, 5 mm/star bit [no. 30]
12 14 Nm 16–17 Nm	Hex key, 5 mm/star bit [no. 30] Hex key, 5 mm/star bit [no. 30]
12 14 Nm	Star bit [no. 30]
12 14 Nm 16–17 Nm	Star bit [no. 30] Star bit [no. 30]
10 12 Nm 16–17 Nm	Star bit [no. 30] Star bit [no. 30]
35–45 Nm	
35–50 Nm	TL-FC24/TL-FC25/TL-FC32/TL-FC36
0.7–1.5 Nm	TL-FC16 / TL-FC18
12–14 Nm	Hex key, 5 mm
50–70 Nm	TL-UN74-S/ TL-UN66
35–50 Nm	Hex key, 8 mm Hex key, 10 mm
50–70 Nm	TL-UN74-S
35–50 Nm	Hex key, 8 mm
	14–16 Nm 16–17 Nm 12 14 Nm 12 14 Nm 16–17 Nm 12 14 Nm 16–17 Nm 12 14 Nm 16–17 Nm 10 12 Nm 16–17 Nm 35–45 Nm 35–50 Nm 0.7–1.5 Nm 12–14 Nm 50–70 Nm

3.5.8.22 On-board computer		
BOSCH Intuvia 100 bracket		
Attachment screw 1, M3× 22	1 Nm	
Attachment screw 2, M3× 14	1 Nm	3 mm hex bit
BOSCH System Controller Attachment screw	0.5 Nm	Torx® T10
BOSCH Mini Remote Attachment screw	0.4 Nm (not 0.6 Nm, as written on mini-remote)	3 mm hex bit
SHIMANO SC-E5003 Attachment screw	0.8 Nm	3 mm hex bit
3.5.8.23 Motor		
BOSCH motor BDU37xx		
6 x attachment screws for motor	20 ± 2 Nm	Torx Plus® P40, M8 × 16 Torx ® Torx Plus ®
		XX XX
3.5.8.24 Rechargeable battery		
BOSCH PowerPack 400/500/600/800		
4 × attachment screws for casing base	5 Nm	Torx® T25, M5 × 20
locking mechanism 2 x attachment screws for cover	2 Nm	M3.5 × 12 M3.5 × 12 (pointed)
2 x attachment screws for cover 2 × attachment screw for bracket on	2 Nm	Torx® T15
cable side 1 × attachment screw for bracket on	1.3 Nm 5 Nm	Torx® T25, M5 × 20
cable side 2 × attachment screws for bracket on	5 Nm	Torx® T25
lock side 1 × attachment screw for bracket on lock side	1 Nm	Torx® T15, M3.5 × 12
3.5.8.25 Motor cover		
BOSCH motor cover BDU37xx		
Attachment screws for lower motor cover	Initial fitting: 3 ± 0.5 Nm Retrofit: 2 ± 0.5 Nm	Torx® TX 20
Attachment screws for motor cover	Initial fitting: 3 ± 0.5 Nm Retrofit: 2 ± 0.5 Nm	Torx® TX 20, 4 × 8 mm
3.5.8.26 Chain guard		
Chain guard for BOSCH Motor BDU37xx		
Attachment screws	Max.10 Nm	M6 × 10; head: max. 5 mm; length: max. 8.5 mm

3.5.8.27 Headlight		
FUXON headlight Attachment screw	>5 Nm	
SUPERNOVA, M99 Pure/Pure+, V521s Attachment screw	2 Nm	M6 attachment screw, self-locking nut, washer
SUPERNOVA, M99 Pure/Pure+, V521s Stem screw	6 Nm	

^{*}if there is no other data on the component

4 Transporting and storing

4.1 Weight and dimensions for transportation

Weight and dimensions during transportation

Type no.	Frame	Dimsions Box [cm]	Weight** [kg]	Shipping weight [kg]
	43 cm	#	26	#
22-15-2061	48 cm	#	26	#
	53 cm	#	26	#
	43 cm	#	26	#
22-15-2062	48 cm	#	26	#
	53 cm	#	26	#
	43 cm	#	27	#
22-15-2059	48 cm	#	27	#
	53 cm	#	27	#
	43 cm	#	27	#
22-15-2060	48 cm	#	27	#
	53 cm	#	27	#
	43 cm	#	27	#
22-15-2057	48 cm	#	27	#
	53 cm	#	27	#
	43 cm	#	27	#
22-15-2058	48 cm	#	27	#
	53 cm	#	27	#
	43 cm	#	27	#
21-17-3236	48 cm	#	27	#
	53 cm	#	27	#
	43 cm	#	27	#
21-17-3237	48 cm	#	27	#
	53 cm	#	27	#

Table 36: Type number, model and pedelec type

4.2 Designated handles, lifting points

The box does not have any handles.

^{**} Vehicle weight without battery

[#] Not yet available when the instructions were produced

4.3 Transportation



Crash caused by unintentional activation

There is a risk of injury if the drive system is activated unintentionally.

▶ Remove the battery.

4.3.1 Using the transport securing system

Applicable for pedelec disc brakes only



Oil leak if no transport securing device

The brake securing device prevents the brakes from being applied accidentally during transportation or shipment. This could cause irreparable damage to the brake system or an oil leak, which will harm the environment.

- Never push the brake lever when the wheel has been dismounted.
- ► Always use the transport securing system when transporting or shipping.
- ► Insert the transport securing devices between the brake linings.
- ⇒ Transport securing device is squeezed between the two linings and prevents undesired sustained braking which can cause brake fluid to leak out.




Figure 50: Fastening the transport securing device

4.3.2 Transporting the pedelec

Bicycle rack systems which use the handlebars or frame to hold the pedelec in an upside-down position exert inadmissible forces on its components during transportation. This can cause the supporting parts to break.

- Never use bicycle rack systems which hold the pedelec in an upside-down position resting on its handlebars or frame. The specialist dealer will give a consultation on correct selection and safe use of a rack system.
- ► Take into account the weight of the ready-touse pedelec when transporting it.
- ▶ Protect the electrical components and connections on the pedelec from the weather conditions with suitable protective covers.
- ► Transport the battery in a dry, clean position where it is protected from direct sunlight.

4.3.3 Shipping a pedelec

When shipping the pedelec, we recommend that you have the specialist dealer place it in proper packaging.

4.3.4 Transporting the battery

Batteries are subject to hazardous goods regulations. Undamaged batteries may be transported by private persons in road traffic.

Commercial transport operators must comply with regulations on packaging, labelling and the transportation of hazardous goods. Open contacts must be covered and the battery securely packaged.

4.3.5 Shipping the battery

The battery is considered a hazardous good and only trained persons may pack and ship a battery. Contact specialist dealer.

4.4 Storing

➤ Store pedelec, on-board computer, battery and charger in a clean, dry place where they are protected from sunlight. Do not store outdoors to ensure a long service life.

Optimum pedelec storage temperature

+10... +20 °C

Table 37: Storage temperature for batteries and the pedelec

- ✓ Temperatures under -10 °C or over +40 °C must generally be avoided.
- ✓ Storage at about 10 °C to 20 °C is beneficial to a long battery life.
- ✓ Store pedelec, on-board computer, battery and charger separately.

4.4.1 Storage mode

The battery features a power-saving storage mode status, which minimises discharge from the battery.

▶ Setting the storage mode status in the settings.

4.4.2 Break in operation

Notice

The battery discharges when not in use. This can cause irreparable damage to the battery.

The battery must be recharged every 6 months.

The battery may become damaged if it is connected permanently to the charger.

► Never connect the battery to the charger permanently.

The on-board computer battery discharges when it is not in use. This can cause irreparable damage to it.

► Recharge the on-board computer battery for at least 1 hour every 3 months.

Remove the on-board computer from its mount if the pedelec is not going to be used for up to four weeks. Store the on-board computer away safely in a dry environment at room temperature.

▶ If the pedelec is removed from service for longer than four weeks, you need to prepare it for a break in operation.

4.4.2.1 Preparing a break in operation

- ✓ Remove the rechargeable battery from the pedelec.
- ✓ Charge battery to 30%–60%.
- ✓ The pedelec needs to be cleaned with a damp cloth and preserved with wax spray. Never wax the friction surfaces of the brake.
- ✓ Before longer periods without use, it is recommended to have the specialist dealer carry out maintenance and basic cleaning and apply preservative agent.

4.4.2.2 Carrying out a break in operation

- 1 Store the pedelec, battery and charger in a dry, clean environment. We recommend storing them in uninhabited rooms with smoke alarms. Dry locations with an ambient temperature between 10 °C and 20 °C are ideal.
- **2** Recharge the on-board computer battery for at least 1 hour every 3 months.
- 3 Check the battery level after 6 months. If only one LED on the battery level indicator lights up, recharge the battery to between 30% and 60%.

5 Assembly

MARNING

Risk of eye injury

Problems may arise if components are set incorrectly. They may cause serious injuries to the face.

Always wear safety glasses to protect eyes when assembling pedelecs.



Crash and crushing hazard caused by unintentional activation

There is a risk of injury if the electric drive system is activated unintentionally.

- Remove the battery.
- ✓ Assemble the pedelec in a clean, dry environment.
- ✓ The Work environment temperature should be between 15 °C and 25 °C.
- ✓ The fitting stand used must be approved for a maximum weight of least 30 kg.

5.1 Unpacking

The packaging material consists mainly of cardboard and plastic film.

- ▶ Dispose of the packaging in accordance with the regulatory requirements (see Section 10).
- ⇒ Pedelecs are fully assembled in the factory for test purposes and then dismantled for transportation. The pedelec is 95% to 98% preassembled.

Scope of delivery

1 pre-assembled pedelec
1 front wheel
2 pedals
2 quick releases (optional)
1 charger
1 set of operating instructions on CD
1 battery (supplied separately from the pedelec)

5.2 Required tools

The following tools are required to assemble the pedelec:




Table 38: Tools required for assembly



5.3 Commissioning

Only trained specialist staff may perform initial commissioning since initial commissioning of the pedelec requires special tools and specialist knowledge.

Experience has shown that a pedelec which has not yet been sold is automatically handed to customers as soon as it appears ready to ride.

- ▶ It makes sense to prepare each pedelec so that it is fully ready for use immediately after being assembled.
- ➤ The assembly report (see Section 11.2) describes all safety-relevant inspections, tests and maintenance tasks.
- ➤ All assembly work must be completed to ensure the pedelec is ready to ride.
- ► Complete an assembly report to document quality assurance (see Section 11.1).

5.3.1 Checking the battery

The battery must be checked before it is charged for the first time.

- ▶ Press the On-Off button (battery).
- If none of the LEDs on the battery level indicator light up, the battery may be damaged.
- ⇒ The battery may be fully charged if at least one, but not all, of the LEDs on the **battery level indicator** lights up.



5.3.2 Preparing the battery

5.3.2.1 Retrofitting the PowerTube adapter

Only applies to pedelecs with this equipment

The PowerTube Adapter 400 or 500 needs to be altered to use the BOSCH PowerTube 625 battery mount.

1 Use a TORX® T25 wrench to undo the screws in the battery mount.



Figure 51: Undoing screws on battery mount

2 Use ratchet to remove the two 4 mm hexagon screws from the PowerTube adapter. You can use a hexagonal key to remove the screws if you don't have a small ratchet.



Figure 52: Removing the 4 mm hexagon screws

3 Use ratchet to remove the two 4 mm hexagon screws from the PowerTube adapter.



Figure 53: Removing hexagon screws

4 Remove the PowerTube adapter.



Figure 54: Pulling out the PowerTube adapter

5 Use adapter plates to adjust the distance if necessary.



Figure 55: Fitted adapter plates

6 Use a TORX® T25 wrench to fasten the screws into the battery mount.




Figure 56: Fastening the battery mount



5.3.2.2 Fit battery cover onto Bosch PowerTube 625 battery (horizontal)

Only applies to pedelecs with this equipment

1 Detach upper interface (lock side) from the BOSCH PowerTube 625 battery with a TORX® T20 wrench.



Figure 57: Detaching the upper interface

2 Screw the battery mounting plate to the BOSCH PowerTube 625 battery with original BOSCH screws (M4 × 8 T20). In doing so, ensure that the removal tab faces the front of the battery.



Figure 58: Fitting the mounting plate

- 3 Press to push the battery cover onto the battery. In doing so, ensure that the battery On-Off button fits through its designated slot in the cover.
- ⇒ The battery cover will lock into the fitting grooves on the battery.



Figure 59: Pushing the battery cover onto battery

► Insert battery into the frame.



5.3.2.3 Fit battery cover onto Bosch PowerTube 500 battery (horizontal)

Only applies to pedelecs with this equipment

1 Detach upper interface (lock side) from the BOSCH PowerTube 625 battery with a TORX® T20 wrench.



Figure 60: Detaching the upper interface

2 Fasten PowerTube extension to the BOSCH PowerTube 500 battery using the two M4 x 8 T20 screws supplied. In doing so, ensure that the closed side faces the front of the battery, towards the battery On-Off button. The smooth upper surface of the PowerTube extension must face upwards, away from the battery.



Figure 61: Fitting the PowerTube extension

3 Screw the battery mounting plate onto PowerTube extension with original BOSCH screws (M4 × 8 T20). To do so, use PowerTube extension screw plate as counter support. When positioning the extension, ensure that the removal tab faces the front of the battery.



Figure 62: Fastening the battery mounting plate

- 4 Press to push the battery cover onto the battery. In doing so, ensure that the battery On-Off button fits through its designated slot in the cover.
- ⇒ The battery cover will lock into the fitting grooves on the battery.



Figure 63: Pushing the battery cover onto battery

▶ Insert battery into the frame.



5.3.2.4 Securing the PowerTube BS2 battery mount

Only applies to pedelecs with this equipment

The BOSCH PowerTube BS2 battery mount must be secured by clamping a clip on its rear.

- ➤ Since one locking nut is on the battery mount rear, remove the motor to fasten the nuts.
- 1 Take out battery, (see Section 6.16).
- 2 Fasten pedelec into fitting stand.

Removing the belt or chain guard

- 3 Undo mount screw.
- 4 Remove belt or chain guard.



Figure 64: Position of mount screw

Removing the pedals

The mark is either on the top end, the axle or the pedal body.



Figure 65: Example of mark on pedals

- 5 Use a 15 mm screw wrench to undo the left pedal thread in a clockwise direction and the right pedal thread in an anti-clockwise direction.
- **6** Turn the pedal marked R anti-clockwise by hand out of the crank arm on the right as seen when facing the direction of travel.



Figure 66: R-pedal in the right-hand crank arm

7 Turn the pedal marked L clockwise by hand out of the crank arm on the left as seen when facing the direction of travel.



Figure 67: L-pedal in the left-hand crank arm



Removing the belt or chain

Notice

Do not buckle, twist, reverse, knot or tie the belt, or bend it backwards. Never use the belt as a strap wrench or chain whip. Never roll the belt up with the sprocket. Never remove the belt with a lever. This can damage the belt and the belt sprocket.

- 8 Undo rear wheel and push forwards.
- ⇒ The belt or the chain is loosened.




Figure 68: Push rear wheel forwards

- 9 Remove rear wheel.
- ⇒ The belt or the chain hangs above the crank set.
- **10** Remove belt or chain from the belt sprocket or the chain wheel.




Figure 69: Removing the belt

Removing the crank set

- **11** Use a hex bit to undo the retaining screws on the left and right.
- **12** Unfasten the crank screw with an 8 mm hex key.



Figure 70: Unfastening the belt sprocket

- **13** Use BOSCH crank puller on a ratchet to remove the crank to the right.
- 14 Detach crank.
- **15** Unfasten belt sprocket with BOSCH removal tool on ratchet or torque wrench.
- 16 Detach belt sprocket with washer.

Removing the motor

17 Unfasten the 3 attachment screws for lower motor cover with Torx® TX 20.




Figure 71: Attachment screws in lower motor cover (1)

- 18 Remove lower motor cover.
- **19** Unfasten the 2 attachment screws from motor cover with Torx® TX 20.





Figure 72: Position of attachment screws (1)

- 20 Remove motor cover.
- 21 Remove cabling.



Figure 73: Motor without cover

22 Have second person hold motor. Unfasten motor screws with Torx Plus® IP40 in the specified order: 1 - 2 - 3 - 4 - 5 - 6.




Figure 74: Position of motor screw 1 to 6

23 Remove the motor.

Undoing screws on battery mount

24 Use a TORX® T25 wrench to undo the screws in the battery mount. The counter nut will fall into the frame.



Figure 75: Undoing screws on battery mount

- 25 Remove battery mount and turn over.
- **26** Clamp the clip (VLD-I-1232) onto the battery mount on the rear.



Figure 76: Clip (VLD-I-1232)



Figure 77: Clamping the clip



- **27** Turn battery mount over and place on the aluminium brace in the frame.
- **28** Use a TORX® T25 wrench to fasten the screws into the battery mount. Hold onto the counter nut through the frame.

Fitting the motor

- 29 Insert the motor.
- 30 Have second person hold motor.
- 31 Fasten motor screws with Torx Plus® IP40 and torque of 20 ± 2 Nm in the specified order: 1 2 3 4 5 6.




Figure 78: Position of motor screw 1 to 6

32 Connect cables correctly.

Notice

The motor can be damaged permanently if connected incorrectly.




Figure 79: Position of connection on Motor Performance Line CX (BDU450 CX)

Position	Connection	Colour	Voltage
1	Headlight	blue	12 V
2	Speed sensor	Grey	At least 3.3 V
3	Rechargeable battery	Black	36 V
4	Display	Black	12 V
5	Power Port	Black	12 V
6	Rear light*	Black	12 V

Table 39: Description of connection

- * In the case of vehicles with a brake light function, connect the rear light together with the brake light and, if present, the GPS cable in position 5, Power Port.
- 33 Position the motor cover. Fasten the 2 attachment screws with Torx® TX 20 and torque of 2 ± 0.5 Nm.



Figure 80: Position of attachment screws (1)

34 Fasten the 3 attachment screws for lower motor cover with Torx® TX 20 and torque of 2 ± 0.5 Nm.



Figure 81: Attachment screws in lower motor cover (1)

5

Fitting the crank set

- **35** Grease the toothing on the crankshafts. Grease belt sprocket or chain wheel. Place belt sprocket or chain wheel on the crankshaft.
- **36** Position crank on top. Use the BOSCH tool and a ratchet to fasten the crank to the left.
- **37** Fasten the crank screw with the specified torque (Section 3.5.9.20 and 3.5.9.21).
- **38** Use a hex bit to fasten the retaining screws on the left and right.



Figure 82: Fastening the belt sprocket (example)

Fitting the belt

39 Pull belt or chain over the belt sprocket or the chain wheel.




Figure 83: Fitting the belt

40 Push the rear wheel backwards to tension the belt or chain.




Figure 84: Pushing the rear wheel backwards

- **41** Check and adjust belt or chain tension (see Section 7.5.9 or 7.5.4).
- 42 Fit the pedal (see Section 5.3.6).
- **43** Remove belt or chain guard. Fasten retaining screw.



Figure 85: Position of mount screw

44 Insert battery (see Section 6.16).



5.3.3 Preparing the wheel

There is an arrow on the sides of the tyres with the inscription ROTATION to show the direction of rotation. The inscription says DRIVE on older tyres. The rotation direction arrow indicates the recommended direction of rotation. On road tyres, the direction of rotation is mainly for optical reasons.



Figure 86: Rotation direction arrow

The direction of rotation is much more important on off-road terrain because the tread creates an interlock with the ground. While the rear wheel needs to transmit the drive forces, the front wheel is responsible for transmitting braking and steering forces. Drive and braking forces have different directions of action. This is why some tyres are mounted on the front and rear wheels in opposite directions. On these tyres, there are two rotation direction arrows:

- The FRONT rotation direction arrow indicates the recommended direction of rotation for the front wheel.
- The REAR rotation direction arrow indicates the recommended direction of rotation for the rear wheel.



Figure 87: Rotation direction arrow on MTB tyres

- ➤ The rotation direction arrow must point in the direction of travel when the wheel is placed in the fork.
- ► There are also non-directional tyre profiles with no rotation direction arrow.



5.3.4 Installing the wheel in the SUNTOUR fork

Only applies to Suntour forks with this equipment

5.3.4.1 Screw-on axle (12AH2 and 15AH2)

Only applies to Suntour forks with this equipment

- ✓ Before installing the wheel, ensure that the O-ring is in the right position on the thread piece.
- 1 Insert the front wheel into the fork ends.
- 2 Insert the axle into the hub on the drive side.



Figure 88: Inserting the axle in the direction of the arrow

3 Use a 6 mm hex key to tighten the axle using between 8 and 10 Nm. The axle thread must be visible.




Figure 89: Tighten the axle in the direction of the arrow

4 Insert the securing screw on the non-drive side.



Figure 90: Inserting the securing screw

5 Tighten the securing screw with a 5 mm hex key using between 5 and 6 Nm.



Figure 91: Tightening the securing screw

⇒ The wheel is now fitted.

5.3.4.2 20 mm cross axle

Only applies to Suntour forks with this equipment

/! CAUTION

Crash caused by loose cross axle

A faulty or incorrectly installed cross axle may become caught in the brake disc and block the wheel. This will cause a crash.

Never fit a defective cross axle.

Crash caused by faulty or incorrectly installed cross axle

The brake disc becomes very hot during operation. Parts of the cross axle may become damaged as a result. The cross axle becomes loose. This will cause a crash with injuries.

The cross axle and the brake disc must be opposite one another.

Crash caused by incorrectly set cross axle

Insufficient clamping force will result in unfavourable transmission of force. The suspension fork or the quick release axle may break. This will cause a crash with injuries.

- Never fasten the cross axle with a tool (e.g. hammer or pliers).
- 1 Insert the cross axle into the hub on the drive side.




Figure 92: Inserting the cross axle in the direction of the arrow

2 Tighten the cross axle with the red handle.



Figure 93: Tighten the axle in the direction of the arrow

3 Push red lever into the cross axle.




Figure 94: Pushing the red lever in the direction of the arrow

4 Closing the quick release lever.



Figure 95: Pressing the quick release lever in the direction of the arrow

⇒ The cross axle is secured.



5 Check the position and clamping force of the quick release lever. The quick release lever must be flush with the shock absorber.



Figure 96: Perfect position for the clamping lever

6 Use 4 mm hexagon socket spanner to adjust the clamping lever clamping force if required.



Figure 97: Adjusting the quick release clamping force

- 7 Check the quick release lever position and clamping force.
- ⇒ The wheel is now fitted.

5.3.4.3 Q-LOC quick release

Only applies to Suntour forks with this equipment

! CAUTION

Crash caused by unfastened quick release

A faulty or incorrectly installed quick release may become caught in the brake disc and block the wheel. This will cause a crash.

Never fit a defective quick release.

Crash caused by faulty or incorrectly installed quick release

The brake disc becomes very hot during operation. Parts of the quick release may become damaged as a result. The quick release comes loose. This will cause a crash with injuries.

➤ The front wheel quick release lever and the brake disc must be situated on opposite sides.

Crash caused by incorrectly set clamping force

Excessively high clamping force will damage the quick release and cause it to lose its function. Insufficient clamping force will result in unfavourable transmission of force. The suspension fork or the quick release may break. This will cause a crash with injuries.

- Never fasten a quick release using a tool (e.g. hammer or pliers).
- Only use the clamping lever with the specified set clamping force.
- ✓ Before installing, ensure that the quick release flange is extended. Open the lever fully.





Figure 98: Closed and opened flange

1 Push in the quick release until you can hear a click. Make sure that the flange is extended.




Figure 99: Inserting the quick release in the direction of the arrow

2 Adjust tensioning with half-open clamping lever until the flange reaches the fork end.




Figure 100: Adjusting the clamping

3 Fully close the quick release. Check that it is firmly in place and adjust it on the flange if necessary.



Figure 101: Closing the quick release

⇒ The wheel is now fitted.



5.3.5 Preparing the LIMOTEC seat post

Only applies to pedelecs with this equipment

- 1 Use the seat height formula to calculate the optimum seat post height for leg length: Seat height (SH) = inner leg length (I) × 0.9
- 2 Lower the seat post further into the seat tube
- 3 The seat post Bowden cable must be tightened in the frame up to the remote control to the same length as the seat post was lowered.
- **4** Trim the seat post Bowden cable on the handlebars if necessary.



5.3.6 Fitting the pedals

The pedals have two different threads to ensure they don't come loose while the rider is pedalling.

- The pedal on the left facing the direction of travel has a left-hand thread and is marked L.
- The pedal on the right facing the direction of travel has a right-hand thread and is marked R.

The mark is either on the top end, the axle or the pedal body.



Figure 102: Example of markings on pedals

- 1 Coat threads in both pedals with waterproof grease.
- 2 Turn the pedal marked L anti-clockwise by hand into the crank arm on the left as seen when facing the direction of travel.



Figure 103: L-pedal in the left-hand crank arm

3 Turn the pedal marked R anti-clockwise by hand into the crank arm on the right as seen when facing the direction of travel.



Figure 104: R-pedal in the right-hand crank arm

4 Use a 15 mm spanner to fasten the left-hand pedal thread in an anti-clockwise direction and the right-hand pedal in a clockwise direction with a torque between 33 Nm and 35 Nm.



5.3.7 Checking the stem and handlebars

5.3.7.1 Checking the connections

- Stand in front of the pedelec. Clamp the front wheel between your legs. Grasp the handlebar grips.
- 2 Try to twist the handlebars against the direction of the front wheel.
- ⇒ The stem must not move or twist.
- 3 If the stem can be twisted, check fastening.
- ⇒ If the stem cannot be fastened, contact your specialist dealer.

5.3.7.2 Checking stem is firmly in position

- 1 Press full body weight on the handlebars.
- ⇒ The handlebars must not move downwards in the fork.

Stem with clamping lever version I

- 2 If the handlebars should move, increase the lever tension in the clamping lever.
- **3** Turn knurled nut in a clockwise direction with the clamping lever open.
- 4 Close clamping lever and check stem is firmly in position again.
- 5 If the handlebars cannot be fastened, contact your specialist dealer.

Stem with clamping lever version II and stem with screw

▶ If the handlebars cannot be fastened, contact your specialist dealer.

5.3.7.3 Checking the bearing clearance

- 1 Place the fingers of one hand on the upper headset cup. Pull the front wheel brake with the other hand and try to push the pedelec backwards and forwards. Keep in mind that there may be noticeable backlash due to worn-out bearing bushes or brake lining backlash in suspension forks and disc brakes.
- ⇒ The headset cup halves must not move towards one another.
- 2 Adjust bearing clearance as per the stem repair manual as quickly as possible; otherwise, the bearing will become damaged. Contact specialist dealer.

5.4 Selling the pedelec

- Complete pedelec pass on the operating instructions envelope.
- Note down the manufacturer and the number of the battery key.
- ► Adjust the pedelec; see Section 6.5.
- Adjust the stand and shifter.
- ▶ Brief pedelec rider on all the pedelec's functions (see Section 6.3).

6 Operation

6.1 Risks and hazards

!WARNING

Injuries and death caused by blind spots

Other road users, trucks, cars and pedestrians often underestimate the speed of pedelecs. Likewise, other road users frequently do not see pedelecs. This may lead to an accident with serious injuries or even death.

- ➤ Wear a helmet. The helmet must have a reflective strip or a light in a clearly visible colour.
- Clothing should be retroreflective or as light as possible. Fluorescent materials are also suitable. High-visibility jackets and straps on your upper body ensure even greater safety.
- Always take a defensive approach to riding.
- Avoid the blind spots of vehicles turning off the road. Reduce speed as a precaution when other road users turn right.

Injuries and death caused by riding incorrectly

A pedelec is not a bicycle. Mistakes made while riding and underestimated speeds quickly lead to hazardous situations. This can cause an accident with serious or fatal injuries.

- ➤ Slowly get used to road traffic and speed before riding at speeds over 12 km/h, especially if you have not ridden a bike for some time.
- ▶ Increase the levels of assistance gradually.
- Practice braking hard on a regular basis.
- ▶ Take and complete a riding safety course.

! WARNING

Injuries and death caused by distraction

A lack of concentration while riding increases the risk of an accident. This may cause a crash with serious injuries.

- ▶ Never allow yourself to be distracted by the on-board computer or your mobile phone.
- ➤ Stop the pedelec if you want to make inputs on the on-board computer other than change the level of assistance. Only enter data when stationary.



Crash caused by loose clothing

Laces, scarves and other loose items may become entangled in the spokes on the wheels and the chain drive. This may cause a crash with injuries.

Wear sturdy footwear and close-fitting clothing.

Crash caused by difficult-to-spot damage

If the pedelec topples over or you have a fall or an accident, there may be difficult-to-spot damage to components such as the brake system, quick releases or frame. This may cause a crash with injuries.

Take pedelec out of service. Contact specialist dealer.

CAUTION

Crash caused by material fatigue

Intensive use can cause material fatigue. A component may suddenly fail in case of material fatigue. This may cause a crash with injuries.

- ► Remove the pedelec from service immediately if there are any signs of material fatigue. Have your specialist dealer inspect the component.
- ▶ Arrange the mandatory inspection appointments with your specialist dealer on a regular basis. During the major inspection, the specialist dealer will inspect the pedelec for any signs of material fatigue on the frame, fork, suspension element mountings (if there are any) and components made of composite materials.

Carbon becomes brittle when exposed to heat radiation such as heating. This can cause the carbon part to break and result in a crash with injuries.

▶ Never expose carbon components parts on the pedelec to strong sources of heat.

Crash caused by poor road conditions

Loose objects, such as branches and twigs, may become caught in the wheels and cause a crash with injuries.

- ▶ Be aware of the road conditions.
- ▶ Ride slowly and brake in good time.

The *tyres* may slip on wet roads. In wet conditions you must also expect a longer braking distance. The braking sensation differs from the usual sensation. This can cause loss of control or a crash, which may result in injuries.

▶ Ride slowly and brake in good time when it is raining.



Crash caused by soiling

Heavy soiling can impair pedelec functions, such as braking. This may cause a crash with injuries.

▶ Remove coarse soiling before riding.

Notice

Heat or direct sunlight can cause the *tyre pressure* to increase above the permitted maximum pressure. This can destroy the *tyres*.

- ▶ Park pedelec in the shade.
- ► On hot days, regularly check the *tyre pressure* and adjust it as necessary.

When riding downhill, high speeds may be reached. The pedelec is only designed to exceed a speed of 25 km/h for short intervals. The *tyres* in particular can fail if exposed to a continuous load.

▶ Use the brakes to decelerate the pedelec if you reach speeds greater than 25 km/h.

Moisture penetrating at low temperatures may impair individual functions due to the open structural design.

- Always keep the pedelec dry and free from frost.
- ▶ If the pedelec is used at temperatures below 3 °C, the specialist dealer must perform a major inspection beforehand and prepare it for winter use.

Off-road riding subjects the joints in the arms to severe strain. Take a break from riding every 30 to 90 minutes, depending on the road surface conditions and your physical fitness.

6.2 Tips for a greater range

The pedelec's range depends on many influencing factors. A single battery charge may only last fewer than 20 kilometres but much more than 100 is also possible. Test the pedelec's range before embarking on longer rides. There are a few tips which will generally help you maximize range.

Suspension elements

Only open suspension fork and damper when necessary on terrain or gravel paths. Block suspension fork and damper on tarmacked roads or on hills.

Mileage

The more own physical effort the rider makes, the greater the attainable range is.

▶ Shift down 1 to 2 gears to increase the induced power and pedalling frequency.

Pedalling frequency

- ▶ Ride using pedalling frequencies of over 50 revolutions per minute. This optimises the electric drive's efficiency.
- ► Avoid pedalling very slowly.

Weight

Minimise the total weight of pedelec and baggage.

Stopping and starting

- ▶ Ride long distances at a constant speed.
- Avoid stopping and starting frequently.

Level of assistance

► The lower the selected levels of assistance are, the greater the range is.

Gear switching habits

- ► Use a low gear and a low level of assistance on hills and when setting off.
- Switch up a gear depending on the speed and terrain.
- ▶ 50-80 crank rotations per minute are optimal.
- Avoid high stress loads on the crank during a gear change.
- Switch gear back in good time, e.g. before inclines.

Tyres

- ▶ Always select the right tyres for the surface type. As a general rule, narrower treads move along more easily than heavier ones. Long studs and large grooves usually have an unfavourable effect on energy consumption.
- When riding on asphalt, it is important to always use the maximum permitted tyre pressure.
- ▶ When riding off-road, on gravel tracks or soft woodland or meadow soils, it is important to remember: the lower the tyre pressure is, the greater the rolling resistance is and thus the greater electric drive system energy consumption is.

Rechargeable battery

Electrical resistance increases as the temperature drops. Battery performance is reduced. As a result, you should expect the range to be shorter than normal in winter.

► Use a thermal protection sleeve on the battery in winter.

The range also depends on the battery's age, charge level and state of repair.

► Maintain the battery and replace older batteries where necessary.

6.3 Error message

6.3.1 On-board computer

The drive system monitors itself continuously and displays a number as an error message if a known error is detected. The system may switch off automatically depending on the type of error.

Code Description Method of resolution 410 One or more on-board computer buttons are blocked ▶ Check whether buttons are jammed because dirt has accumulated between them, for example. 414 Connection problem with the control panel with the control panel are blocked ▶ Contact specialist dealer. Have ports and connections checked. 418 One or more buttons on the control panel are blocked ▶ Check whether buttons are jammed because dirt has accumulated between them, for example. 419 Configuration error 1 Re-start the system. 2 Contact your specialist dealer if the problem persists. 2 Contact your specialist dealer if the problem persists. 422 Battery connection problem ▶ Have ports and connections checked. 423 Battery connection problem ▶ Have ports and connections checked. 424 Communication error with components communicating with one another ▶ Have ports and connections checked.			
computer buttons are blocked are jammed because dirt has accumulated between them, for example. Clean buttons if necessary. Connection problem with the control panel with the control panel are blocked One or more buttons on the control panel are blocked Clean buttons are jammed because dirt has accumulated between them, for example. Clean buttons if necessary. Clean buttons if necessary. Clean buttons if necessary. Re-start the system. Configuration error Re-start the system. Contact your specialist dealer if the problem persists. Battery connection problem Phave ports and connections checked. Battery connection problem Lave ports and connections checked. Phave ports and connections checked. Lave ports and connections checked. Phave ports and connections checked.	Code	Description	Method of resolution
414 Connection problem with the control panel 418 One or more buttons on the control panel are blocked 419 Configuration error 419 Configuration error 420 Battery connection problem 421 Battery connection problem 422 Communication error with components communicating with one another 423 Connection problem 424 Communication error with components communicating with one another 426 Contact specialist dealer. Have ports and connections checked. 427 Have ports and connections checked. 428 Have ports and connections checked.	410	computer buttons are	are jammed because dirt has accumulated between them, for example. Clean buttons if
with the control panel dealer. Have ports and connections checked. Check whether buttons are jammed because dirt has accumulated between them, for example. Clean buttons if necessary. Contact your specialist dealer if the problem persists. Battery connection problem Battery connection problem Battery connection problem Communication error with components communicating with one another Mealer. Have ports and connections are jammed because dirt has accumulated between them, for example. Clean buttons if necessary. Re-start the system. Contact your specialist dealer if the problem persists. Have ports and connections checked. Have ports and connections checked.	444		•
on the control panel are jammed because dirt has accumulated between them, for example. Clean buttons if necessary. Configuration error Re-start the system. Contact your specialist dealer if the problem persists. Battery connection problem Battery connection problem Phave ports and connections checked. Accumulated between them, for example. Clean buttons if necessary. He-start the system. Have ports and connections checked. Have ports and connections checked. Phave ports and connections checked.	414		dealer. Have ports and
necessary. 1 Re-start the system. Configuration error 1 Re-start the system. Contact your specialist dealer if the problem persists. 422 Battery connection problem Battery connection problem Have ports and connections checked.	418	on the control panel	are jammed because dirt has accumulated between them, for
2 Contact your specialist dealer if the problem persists. 422 Battery connection problem 423 Battery connection problem 424 Communication error with components communicating with one another 2 Contact your specialist dealer if the problem persists. Have ports and connections checked.			
dealer if the problem persists. 422 Battery connection problem 423 Battery connection problem Have ports and connections checked.	419	Configuration error	1 Re-start the system.
problem tions checked. 423 Battery connection problem Have ports and connections checked. 424 Communication error with components communicating with one another Have ports and connections checked.			dealer if the problem
problem tions checked. 424 Communication error with components communicating with one another tions checked. Have ports and connections checked.	422		·
with components communicating with one another	423		
	424	with components communicating with	·
Internal time-out error It is not possible to display or adjust the tyre size in the basic settings menu in this error status.	426	Internal time-out error	adjust the tyre size in the basic settings menu in this
1 Re-start the system.			1 Re-start the system.
Contact your specialist dealer if the problem persists.			dealer if the problem
430 On-board computer battery flat ▶ Recharge on-board computer battery (while in its mount or using USB port).	430		computer battery (while in its mount or using
431 Software version error 1 Re-start the system.	431	Software version error	,
Contact your specialist dealer if the problem persists.			dealer if the problem

Table 40: List of on-board computer error messages

Code	Description	Мє	ethod of resolution
440	Battery internal error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
450	Internal software error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
460	Error in USB port	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
490	On-board computer internal error	•	Have on-board computer checked.
500	Battery internal error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
502	Fault in the lighting	1	Check the light and its cabling.
		2	Re-start the system.
		3	Contact your specialist dealer if the problem persists.
503	Speed sensor error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
504	Speed signal manipulation detected	•	Check position of spike magnets and re-adjust if necessary.
		 	Check for manipulation.
		•	Assistance from drive has been reduced.
510	Internal sensor error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
511	Battery internal error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
530	Battery error	1	Switch off system.
		2	Remove the battery.
		3	Re-insert battery.
		4	Restart electric drive system.
		5	Contact your specialist dealer if the problem persists.

Table 40: List of on-board computer error messages

Code	Description	Мє	ethod of resolution
531	Configuration error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
540	Temperature error The pedelec is outside the permitted temper- ature range	2 3	Switch off the system to cool the motor and battery down or warm them to the permitted temperature range. Re-start the system. Contact your specialist dealer if the problem persists.
550	An inadmissible electrical load has been detected	1 2 3	Remove consumer. Re-start the system. Contact your specialist dealer if the problem
			persists.
580	Software version error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
591	Authentication error	1	Switch off system.
		2	Remove the battery.
		3	Re-insert battery.
		5	Re-start the system. Contact your specialist dealer if the problem persists.
592	Incompatible component	1	Insert compatible on-board computer.
		3	Re-start the system. Contact your specialist dealer if the problem persists.
593	Configuration error	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.
595,	Communication error	1	Check cabling to the gears.
596		2	Re-start the system.
		3	Contact your specialist dealer if the problem persists.
602	Internal error during charging	1	Disconnect charger from battery.
		2	Re-start the system.
		3	Connect charger to the battery.
		4	Contact your specialist dealer if the problem persists.
603	Internal fault	1	Re-start the system.
		2	Contact your specialist dealer if the problem persists.

Table 40: List of on-board computer error messages

Code	Description	Method of resolution
605	Temperature error The pedelec is outside the permitted temper- ature range	Switch off the system to cool the motor and battery down or warm them to the permitted temperature range.
		Re-start the system. Contact your specialist dealer if the problem persists.
606	External fault	Check cabling. Re-start the system. Contact your specialist dealer if the problem persists.
610	Voltage error	Re-start the system. Contact your specialist dealer if the problem persists.
620	Charger error	Replace charger. Contact your specialist dealer if the problem persists.
640	Internal fault	Re-start the system. Contact your specialist dealer if the problem persists.
655	Multiple battery error	Switch off system. Remove the battery. Re-insert battery. Re-start the system. Contact your specialist dealer if the problem persists.
656	Software version error	Contact your specialist dealer to install a software update.
7xx	Gear error	Observe the gear shift manufacturer's operating instructions.
800	Internal ABS error	Contact specialist dealer.
810	Implausible signals from the wheel speed sensor	Contact specialist dealer.
820	Error in the line to the front wheel speed sensor	Contact specialist dealer.
821 826	Implausible signals from the front wheel speed sensor. It is defective or incorrectly installed; significantly different tyre diameter between the front wheel and rear wheel; extreme riding, such as riding on the rear wheel only	 Re-start the system. Take a test ride of at least two minutes. The ABS indicator lamp must go out. Contact your specialist dealer if the problem persists.

Table 40: List of on-board computer error messages

Code	Description	Method of resolution	
830	Error in the line to the rear wheel speed sensor	Contact specialist dealer.	
831 833 835	Implausible signals from the rear wheel speed sensor. Sensor disc may be missing. It is defective or incorrectly installed; significantly different tyre diameter between the front wheel and rear wheel; extreme riding, such as riding on the rear wheel only	Re-start the system. Take a test ride of at leas two minutes. The ABS indicator lamp must go ot Contact your specialist dealer if the problem persists.	-
840	Internal ABS error	 Contact specialist dealer. 	
850	Internal ABS error	Contact specialist dealer.	
860, 861	Error in the power supply	Re-start the system. Contact your specialist dealer if the problem persists.	
870, 871, 880 883 885	Communication error	Re-start the system. Contact your specialist dealer if the problem persists.	
889	Internal ABS error	Contact specialist dealer.	
890	ABS indicator lamp is defective or missing; ABS may not be functioning	Contact specialist dealer.	
No screen display	On-board computer internal error	► Re-start the drive syste by switching it on and o	

Table 40: List of on-board computer error messages

6.3.2 Rechargeable battery

The battery is protected against deep discharge, overcharging, overheating and short circuits by Electronic Cell Protection (ECP). In the event of a hazard, a protective circuit switches the battery off automatically. If a fault is detected in the battery, the LEDs flash on the battery level indicator.

Descrip	ntion	Me	thod of resolution
Code:		72-	
charging three LE	ttery is outside its g temperature range, Ds will flash on the evel indicator.	2 3	Disconnect charger from battery. Leave battery to cool down. Contact your specialist dealer if the problem persists.
Code:			
battery,	is detected in the two LEDs flash on the evel indicator.	•	Contact specialist dealer.
Code:		7	
is defect One or r	s will flash if the charger ive and will not charge. more LEDs will light up ently, depending on the evel.	•	Contact specialist dealer.
Code:		7	
No LED: no powe	s will light up if there is r.	1 2 3	Check all plug connections. Check contacts on the battery for dirt. Clean the contacts carefully if needed. Contact your specialist dealer if the problem persists.

Table 41: List of battery error messages

6.4 Instruction and customer service

The supplying specialist dealer will provide customer service. Contact details can be found on the pedelec pass for these operating instructions. The specialist dealer will explain all the pedelec functions to the new owner in person, this being when the specialist dealer hands over the pedelec at the latest. These operating instructions are provided with every pedelec, so that the rider can consult them at a later stage.

The supplying specialist dealer will also perform all inspection, modifications and repairs in the future.

6.5 Adjusting the pedelec



Crash caused by incorrectly adjusted torque

If a screw is fastened too tightly, it may break. If a screw is not fastened enough, it may loosen. This will cause a crash with injuries.

► Always observe the torque indicated on the screw and in the operating instructions.

Only a correctly adjusted pedelec will guarantee the desired ride comfort and health-promoting activity.

All settings must be re-configured if the body weight or maximum baggage weight changes.

6.5.1 Preparing

The following tools are required to adjust the pedelec:




Table 42: Tools required for assembly

6.5.2 Pedelec adjustment procedure

▶ Observe the correct order for adjustment.

			For com	pede	lecs ents	with only	
Sequence	Adjustment	Section	Rhomboid seat post	Ergonomic handles	Suspension fork	Rear frame damper	Headlight
1.1 1.2 1.3 1.4	Saddle Straighten saddle Adjust saddle height Adjust saddle position Adjust saddle tilt	6.5.4.1 6.5.3.3 6.5.3.5 6.5.3.6					
2	Handlebars	6.5.4					
3	Stem	6.5.5					
4	Handles	6.5.6		х			
5	Tyres	6.5.7					
6.1 6.2 6.3 6.4 6.5	Brake Position of the brake handles Brake handle tilt angle Determine grip distance Pressure point Retract the brake linings	6.5.8.1 6.5.8.2 6.5.8.3 6.5.8.5 6.5.8.7					
7	Gear shift	6.5.9					
9	Adjust suspension - Adjust the suspension fork sag - Adjust damper sag	6.5.12			х		
	- Adjust suspension fork rebound damper - Adjust damper rebound damper	6.5.12			х		
10	Light	6.5.13					х
11	Adjust on-board computer	6.5.15					

6.5.3 Determining the sitting position

The starting point for a comfortable posture is the correct position of the pelvis. If the pelvis is in the wrong position, it can cause different types of pain, e.g. in the shoulder or back.



Figure 105: The pelvis is in the right position (green) or incorrect position (red)

The pelvis is in the right position if the spine forms an S-shape and a natural, easy arch.

The pelvis is positioned incorrectly if it tilts slightly backwards. As a result, the spine becomes curved and can no longer deflect to an optimal extent.

A suitable sitting position must be selected beforehand depending on the pedelec type, physical fitness and desired trip distance or speed.

It is especially advisable to check and optimise the sitting position once more before longer rides.




Table 43: Overview of sitting positions

6.5.3.1 Straighten saddle

▶ Position saddle in direction of travel. In doing so, align the tip of the saddle with the top tube.




Figure 106: Positioning the saddle in direction of travel

6.5.3.2 Positioning the saddle with eightpins suspension seat post

Only applies to pedelecs with this equipment

- 1 Position saddle in direction of travel. In doing so, align the tip of the saddle with the top tube.
- **2** Use a torque wrench to tighten the seat post axle with 8 Nm.



Figure 107: Tightening the seat post axle

6.5.3.3 Adjusting the saddle height

- ✓ To adjust the saddle height safely, either:
- Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
- Ask another person to hold the pedelec.
- Use the seat height formula to roughly set the saddle height:
 Seat height (SH) = inner leg length (I) × 0.9
- 2 Climb onto the bicycle.
- 3 Place your heel on the pedal and extend your leg, so that the pedal is at the lowest crank rotation point. Your knee should now be fully extended.




Figure 108: Heel method

- 4 Take a test ride.
- ⇒ Pedelec riders sit straight on the saddle at an optimal saddle height.
- If the pelvis moves to the left and right as you pedal, the saddle is too high.
- If your knees are painful after a few kilometres, the saddle is too low.
- ⇒ Position the seat post according to needs if necessary. Adjust the seat height with the quick release.

5 Open the quick release on the seat post to change the seat height (1). To do so, push the clamping lever away from the seat post (3).




Figure 109: Opening the seat post quick release

6 Set the seat post to the required height.



Crash caused by an excessively high seat post setting

A *seat post* which is set too high will cause the *seat post* or the *frame* to break. This will cause a crash with injuries.

▶ Do not pull the seat post out of the frame beyond the minimum insertion depth marking.




Figure 110: Detailed view of the seat post – examples of the minimum insertion depth marking

- 7 To close it, push the seat post clamping lever as far as it will go into the seat post (2).
- 8 Check the clamping force of the quick releases.

6.5.3.4 Setting the saddle height with the remote control

Use the seat height formula to set the saddle height:

Seat height (SH) = inner leg length (I) \times 0.9

Notice

If you are unable to achieve the required saddle height, the seat post must be lowered further into the seat tube. The seat post Bowden cable must be tightened in the frame up to the remote control to the same length as the seat post was lowered. If this is not possible, contact your specialist dealer.

Lowering the saddle

- 1 Sit on the saddle.
- 2 Press the remote control operating lever.
- ⇒ The seat post will lower.
- 3 Release the remote control operating lever when you have reached the desired height.




Figure 111: Remote control operating lever (1)

Raising the saddle

- 1 Remove any pressure from the saddle.
- 2 Press the remote control operating lever.
- ⇒ The seat post will rise.
- 3 Release the remote control operating lever when you have reached the desired height.

6.5.3.5 Adjusting the saddle position

The saddle can be shifted on the saddle frame. The right horizontal position ensures an optimal leverage position for legs. This prevents knee pain and painful incorrect pelvis positions. If you have displaced the saddle more than 10 mm, you need to adjust the saddle height again since both settings affect one another.

- ✓ The saddle setting must only be made when the bicycle is stationary.
- ✓ To adjust the saddle position either:
- Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
- Ask another person to hold the pedelec.
- Move the saddle within its permitted displacement range only (marked on the saddle stay).
- 1 Climb onto the pedelec.
- 2 Place the pedals into the vertical position with your feet.
- ⇒ Pedelec riders are adopting the optimal saddle position if the perpendicular line from the kneecap runs through the pedal axle.
- ▶ If the perpendicular line crosses behind the pedal, bring the saddle further forward.
- ▶ If the perpendicular line crosses in front of the pedal, bring the saddle further back.




Figure 112: Knee cap perpendicular line


3 Unfasten and adjust the designated screw connections, and clamp them with the maximum tightening torque for the saddle clamping screws.

6.5.3.6 Adjusting the saddle tilt

The saddle tilt must be adjusted to the seat height, the saddle and handlebar position, and the saddle shape to ensure an optimum fit. The seating position can be optimised in this way if needed.

The saddle prevents pedelec riders from slipping backwards or forwards when placed in a horizontal position. This prevents seat problems. In any other position, the tip of the saddle may press uncomfortably into the crotch area. It is also recommended that the centre of the saddle is exactly straight. This ensures that the rider is seated with their sit bones on the wide rear part of the saddle.

- 1 Adjust the saddle tilt to horizontal.
- 2 Position saddle middle so that it is completely



straight.

Figure 113: Horizontal saddle tilt with 0° tilt in the centre of the saddle

- → Pedelec riders sit comfortably on the saddle and do not slip backwards or forwards.
- 3 Pedelec riders tend to slip forwards on the narrow part of the saddle, adjust the riding position (see Section 6.6.2.3) or tilt the saddle very slightly backwards.

6.5.3.7 Checking saddle stability

► Check saddle stability after adjusting it (see Section 7.5.13).

6.5.4 Handlebars

6.5.4.1 Replace handlebars

Not included in price



Handlebars are components that may be replaced after approval by the vehicle or parts manufacturer. Handlebars may be replaced if the cable and/or line lengths do not need to be changed. A change in riding position is allowed within the original cable length. Furthermore, the load distribution on the pedelec changes considerably and may potentially lead to critical steering performance

- ► Check handlebar width and hand position.
- ▶ Have handlebars replaced at the specialist dealer's if necessary.

6.5.4.2 Adjusting the handlebar width

The handlebar width should be as wide as the rider's shoulders as a minimum. This is measured from mid-point to mid-point on the hand contact surfaces.




Figure 114: Determining the optimal handlebar width

The wider the handlebars are, the more control they provide, although wide handlebars require greater supporting force. Wider handlebars are particularly useful to ensure a safer ride for loaded touring bikes.

6.5.4.3 Adjusting the hand position

The hand is an optimal position on the handlebars when the forearm and hand are in a straight line, i.e. the wrist is not bent. In this way, the nerves are not pinched and do not cause pain.




Figure 115: Distribution of nerves with curved and straight handlebars

The narrower the shoulders are, the greater the bend of the handlebars should be (maximum 28°).

Straight handlebars are advisable for sports bikes (e.g. MTB). They support direct steering behaviour, but lead to peaks in pressure and greater muscular strain on the arm and shoulder muscles.

6.5.4.4 Adjusting the handlebars

The handlebars and their position determine the posture that the pedelec rider adopts on the pedelec.

- **1** After selecting the riding position (see Section 6.6.2.1), determine the angle of the upper body and upper arm.
- 2 Pre-tension the back muscles when adjusting the handlebars. The only way to stabilise the spine and protect it from excessive strain is with the back and abdominal muscles pretensioned. Passive muscles are not able to perform this important task.
- **3** Set the required handlebar position by adjusting the stem height and angle (see Section 6.6.6).
- 4 After adjusting the handlebars, check the saddle height and riding position again. The position of the pelvis on the saddle may have changed when the handlebars were adjusted. This can have considerable impact on the position of the hip joint due to the pelvis tilting and may change the usable leg length on the saddle support by up to 3 cm.
- **5** Correct the saddle height and riding position if necessary.

6.5.5 Stem

6.5.5.1 Replacing the handlebars

Not included in price



Handlebar-stem units are components that may be replaced after approval by the vehicle or parts manufacturer. A stem must be replaced if cable and/or line lengths do not need to be changed. A change in riding position is allowed within the original cable length. Furthermore, the load distribution on the pedelec changes considerably and may potentially lead to critical steering performance

6.5.5.2 Adjusting the handlebar height with quick release

Only applies to pedelecs with this equipment

1 Open the stem clamping lever.




Figure 116: Open (2) and closed (1) stem clamping lever; All Up used as an example




Figure 117: Pulling the locking lever upwards; All Up used as an example

- **2** Pull out the handlebars to the required height. Observe minimum insertion depth.
- 3 Close the stem clamping lever.

6.5.5.3 Checking the stem stability

- ► Hold handlebars firmly after adjusting the saddle. Press full body weight on the handlebars.
- ⇒ The handlebars remain stable in their position.
- 6.5.5.4 Adjusting the quick release clamping force



Crash caused by incorrectly set clamping force

Applying excessive clamping force damages the quick release. Insufficient clamping force will result in unfavourable transmission of force. This can cause components to break. This will cause a crash with injuries.

► Never fasten a quick release using a tool (e.g. hammer or pliers).

If the *handlebar clamping lever* stops before reaching its end position, unscrew the *knurled nut*.

- ➤ Tighten the *knurled nut* on the seat post if the seat post clamping lever's clamping force is not effective enough.
- Contact your specialist dealer if the clamping force cannot be set.

6.5.5.5 Setting the quill stem

Only applies to pedelecs with this equipment

In the case of a quill stem, the stem and fork steerer form a permanently interconnected component, which is clamped in the fork steerer. The stem and shaft must be replaced together.




Figure 118: Adjusting the quill stem height

- 1 Undo screw.
- 2 Pull quill stem out.
- 3 Tighten screw.

6.5.5.6 Adjusting the Ahead stem

Only applies to pedelecs with this equipment

In the case of an Ahead stem, the stem is placed directly on the fork steerer, which protrudes over the frame.




Figure 119: Raising the Ahead stem by fitting spacer rings

The handlebar height is adjusted once during production using spacer rings. The part of the fork steerer protruding is then cut off. The handlebar stem can then no longer be set higher, but only slightly lower.

6.5.5.7 Adjusting the angle-adjustable stem

Only applies to pedelecs with this equipment

Angle-adjustable stems are available in different lengths for quill and Ahead stems.




Figure 120: Different versions of angle-adjustable stems

Adjusting the stem angle (c) changes both the distance from the upper body to the handlebars (b) and the handlebar height (a).



Figure 121: City bike (blue) and trekking bike position (red) by changing the angle

6.5.6 Handles

6.5.6.1 Replacing the handles

Not included in price



Handles with bolt clamps are components which may be replaced without approval.

If there is pain or numbness in the index, middle finger or thumb, this may be due to excessive pressure on the exit of the carpal tunnel. On longer rides, this can increasingly cause hand fatigue and make it more and more difficult to maintain a correct hand position.

In the case of ergonomically shaped handles, the palm rests on the anatomically shaped handle. A greater contact surface means that the pressure is of more evenly distributed. Nerves and vessels are no longer squeezed in the carpal tunnel.

Moreover, the hand is supported and held in the correct position so that the hand can no longer bend.

If the pre-mounted handles are uncomfortable or cause pain or numbness in the index, middle finger or thumb, ergonomic handles, bar ends or multi-position handlebars should be used.

6.5.6.2 Adjusting ergonomic handles

Only applies to pedelecs with this equipment





Figure 122: Incorrect (1) and correct (2) position of the handle.



- 2 Turn handle into the right position.
- 3 Fasten handle clamping screw with the torque value indicated there.
- ⇒ The handles are firmly fastened.
- The pull-off force of the handles is at least 100
 N in the roadster, city and trekking positions, and at least 200 N in the sporty position.

6.5.6.3 Checking handlebar stability

► See Section <u>7.5.12</u>.

6.5.7 Tyres

6.5.7.1 Adjust tyre pressure

The correct tyre pressure largely depends on the weight load on the tyres. This load is determined by the weight of the pedelec, the rider's body weight and the luggage load.

Unlike cars, the weight of the vehicle has little impact on the total weight. Moreover, the personal preferences for low rolling resistance or a high degree of suspension comfort vary a great deal.

It is important to remember that

- the higher the tyre pressure is, the lower the wear, rolling resistance and the risk of breakdown are.
- The lower the pressure in the tyre is, the greater the comfort and grip that the tyre offers is.

In the case of pedelecs used on the road, the rule is the greater the tyre pressure is, the lower the tyre rolling resistance is. The risk of breakdown is also lower when the pressure is high. A permanently excessively low tyre pressure often leads to premature wear in the tyre. Cracking in the side wall is a typical consequence of very low tyre pressure. Abrasion is also unnecessarily high.

On the other hand, a tyre can absorb road impacts more effectively at a low pressure.

As a general rule, wide tyres are operated at a lower tyre pressure. They provide the option of exploiting the advantages of the lower tyre pressure without the serious disadvantages it causes with regard to wear, rolling resistance and breakdown protection.

- ✓ Never exceed or go below the minimum and maximum pressure limits indicated on the tyre.
- **1** Pump the tyre to the recommend tyre pressure.

Tyre width	Tyre pressure in bar for body weight				
Tyre width	approx. 60 kg	approx. 80 kg	approx. 110 kg		
25 mm	6.0	7.0	8.0		
28 mm	5.5	6.5	7.5		
32 mm	4.5	5.5	6.5		
37 mm	4.0	5.0	6.0		
40 mm	3.5	4.5	6.0		
47 mm	3.0	4.0	5.0		
50 mm	2.5	4.0	5.0		
55 mm	2.0	3.0	4.0		
60 mm	2.0	3.0	4.0		

Table 44: SCHWALBE recommend tyre pressure

2 Perform a visual check on tyres.



Figure 123: Correct tyre pressure. The tyre is barely deformed under the load of the body weight



Figure 124: Much too little tyre pressure

6.5.7.2 Replacing tyres

Not included in price



Tyres are components that may be replaced after approval by the vehicle or parts manufacturer.

Different tyres need to be used when the area of use is changed, more weight or greater puncture protection is added, and greater acceleration or more dynamic cornering is used.

Tyres may be replaced if

- They are approved for use on e-bikes
- They comply with ETRTO dimensions
- They have the same load capacity as a minimum
- They have a comparable level of puncture protection as a minimum

6.5.8 Brake

The handbrake grip distance can be adjusted to ensure that it can be reached more easily. The pressure point can also be adjusted to the pedelec rider's preferences.

6.5.8.1 Change handbrake position

Having the brake handle in the correct position prevents the rider from stretching their wrist too far. Moreover, the brake can also be operated without any discomfort and without changing the handle position or releasing the handle.

- ✓ Apply handbrake with the third finger phalanx in bursts to brake gently.
- ✓ The setting for the middle finger is used for pedelec riders who brake with their middle finger or with two fingers.
- 1 Position your hand on the handle in such a way that the outer heel of the hand is flush with the end of the handlebar.
- 2 Extend the index finger (about 15°).



Figure 125: Brake handle position

3 Push handbrake outwards until the third finger phalanx sits in the recessed grip.

6.5.8.2 Change handbrake inclination angle

The nerves that pass through the carpal tunnel are connected to the thumb and the index and middle fingers. An excessively steep or excessively flat brake angle will cause the wrist to bend, thus narrowing the carpal tunnel. This can cause numbness and tingling in the thumb and index and middle fingers.

1 Calculate the difference between the height of the handlebars and the saddle height to determine the saddle-handlebar height difference.




Figure 126: Example of 4 different handlebar heights (A, B, C and D) and the saddle height (E)

Calculation	Saddle-handlebar height difference [mm]
A – E	>10
B – E	0 +10
C – E	010
D – E	< -10


Table 45: Examples of saddle-handlebar height difference

Adjust the angle of the handbrake so that it forms a natural extension of the forearm.

2 Set the brake lever angle as indicated in the table

ı	Saddle-handlebar height difference (mm)	Brake angle
	>10	20°25°
	0 10	25°30°
	010	30°35°
	< -10	35°45°

Figure 127: Brake angle



6.5.8.3 Determining the grip distance

- **1** Measure hand size using the grip distance gauge.
- 2 Adjust the grip distance at the pressure point based on the hand size.



Figure 128: Handbrake positioning

Hand size	Grip distance (cm)
S	2
М	3
L	4

6.5.8.4 Grip distance on a MAGURA disc brake lever

Only applies to pedelecs with this equipment

! WARNING

Crash caused by incorrectly set grip distance

If brake cylinders are set incorrectly or installed wrongly, the braking power may be lost at any time. This may cause a crash with injuries.

► Ensure that the fully applied brake lever is at a minimum distance of 20 mm from the handlebars.

The brake lever position can be adjusted to the rider's requirements. Such adjustment does not

affect the pressure point or the position of the brake linings.

- ➤ Turn the setting screw/twist knob (5) anticlockwise towards minus (–).
- ⇒ The brake lever moves closer to the handlebar grip.
- ➤ Turn the setting screw/twist knob (5) clockwise towards plus (+).
- ⇒ The brake lever moves away from the handlebar grip.




Figure 129: Adjusting the grip distance on a MAGURA disc brake lever

6.5.8.5 Pressure point on a MAGURA brake lever

Only applies to pedelecs with this equipment

! WARNING

Brake failure due to incorrect setting

If the pressure point is set with brakes where the brake linings and brake disc have reached their wear limit, the brakes may fail and cause an accident with injury.

▶ Before you adjust the pressure point, ensure that the brake linings and brake disc have not reached their wear limit.

The pressure point setting is adjusted using the twist knob.

- ➤ Turn the twist knob towards the plus (+) symbol.
- ⇒ The brake lever moves closer to the handlebar grip. Re-adjust the grip distance as necessary.
- ⇒ The lever pressure point activates sooner.
- ► Turn the twist knob towards the minus (–).
- ⇒ The brake lever move further away from the handlebar grip. Re-adjust the grip distance as necessary.
- ⇒ The lever pressure point activates later.




Figure 130: Using the twist knob (1) to adjust the pressure point

6.5.8.6 Replacing brakes

Not included in price



Brake components may only be replaced with original components.

In the case of disc brake pads, the optimum pad compound may be adapted to the surface and the rider's experience.

6.5.8.7 Retracting the brake linings

Disc brakes require wearing-in time. The braking force increases over time. The braking force is increased during break-in time. This is also the case when the brake pads or brake discs are replaced.

- 1 Accelerate pedelec to 25 km/h.
- 2 Brake pedelec until it comes to a halt.
- 3 Repeat process 30 to 50 times.
- ⇒ The disc brake is retracted and provides optimal braking power.

6.5.9 Gear shift

Adjust the position of the gear shift to the pedelec riders' needs.

- 1 Undo attachment screw.
- Place control panel or shifter into the position where the pedelec rider can use the control panel or the shifter with their thumb and/or index finger. The shifter must never block the handbrake.
- 3 Tighten attachment screw.

6.5.9.1 Replacing the gear shift

Not included in price



All gear shift components (rear derailleur, shifter, twist grip, shift cables and sleeves) may be replaced provided that:

- All gear shift components are suitable for the number of gears
- All gear shift components are compatible with one another

It is permitted to change from an electronic gear shift variant to a mechanical one.

It is prohibited to change from a mechanical gear shift variant to an electronic one.

6.5.9.2 Adjusting the SHIMANO shifter

Only applies to pedelecs with this equipment




Figure 131: Position of attachment screw in SHIMANO shifter (1)

6.5.10 Suspension



All suspension components (rigid and suspension forks and rear frame dampers) are parts which may be replaced after approval by the vehicle or part manufacturer.

A pedelec's fork suspension and rear frame damper suspension can be adjusted to the rider's weight in up to six increments, depending on the suspension system.

► Follow the correct order for adjustment.

			For pedelecs with components only	
Sequence	Adjustment	Section	Suspension fork	Rear frame damper
1	Adjust the suspension fork sag	6.5.11	х	
2	Adjust the rear frame damper sag			х
3	Adjust suspension fork rebound damper	6.5.12	x	
4	Adjust rear frame damper rebound damper			х
5	Adjust the rear frame damper compression adjuster			х
6	The fork compression adjuster is adjusted to the terrain while riding.	6.20		

Table 46: Order for adjusting the suspension

6.5.11 Fork sag



Crash caused by incorrectly set suspension

If the suspension is set incorrectly, the fork may become damaged, meaning problems may occur when steering. This will cause a crash with injuries.

- ▶ Never ride without air in the air suspension fork.
- ▶ Only use the pedelec if the suspension fork is adjusted to the rider's body weight.

Adjustments on the chassis change ride performance significantly. The rider needs to get used to the pedelec and break it in to prevent accidents.

The sag depends on the position and body weight and should be between 10% and 30% of the maximum fork deflection, depending on preferences and on how the pedelec is used.

Greater sag (20% to 30%)

A greater sag increases sensitivity to bumps, thus producing greater suspension motion. A greater sensitivity to bumps ensures more comfortable ride performance and is used on pedelecs with a longer deflection.

Decreased sag (10% to 20%)

A decreased sag reduces sensitivity to bumps, thus producing less suspension motion. A lower sensitivity to bumps ensures a firmer, more efficient ride performance and is generally used on pedelecs with a shorter deflection.

The adjustment shown here represents a basic setting. Pedelec riders should change the basic setting to suit the surface and their preferences.

It is advisable to make a note of the basic settings. These can then be used a starting point for subsequent settings and as a safeguard against unintentional changes.

6.5.11.1 Adjusting the SR SUNTOUR fork steel suspension

Only applies to pedelecs with this equipment

1 You will find the **sag setting wheel (1)** beneath the plastic cover on the crown. Remove the plastic cover.




Figure 132: Sag setting wheel (1) on the suspension fork crown

- ► Turn the **sag setting wheel** clockwise to increase the spring pre-tensioning.
- ► Turn the **sag setting wheel** anti-clockwise to decrease the spring pre-tensioning.
- ⇒ You will have made the ideal setting when the shock absorber deflects 3 mm when subject to body weight.
- **3** Replace the plastic cover on the crown after making the setting.

6.5.11.2 Adjusting the SR SUNTOUR fork air suspension

Only applies to pedelecs with this equipment

► The air valve is located beneath the air valve cap on the crown. Twist off the air valve cap.



Figure 133: Different screw caps

- 1 Attach a high-pressure damper pump to the air
- Pump air suspension fork to the required pressure. Observe the levels in the SR SUNTOUR tyre pressure table. Never exceed the recommended maximum tyre pressure.

	Recommended air pressure (psi)					
Body weight	AION35 Mobie 45	Axon34 XCR34 XCR32	Mobie 45	NCX	XCR24	XCM-Jr.
<55 kg	35 50	40 55	40 55	40 55	40 55	40 55
55 65 kg	50 60	55 65	55 65	55 65	-	-
65 75 kg	60 70	65 75	65 75	65 75	-	-
85 95 kg	85 100	85 100	85 100	85 95	_	-
> 100 kg	+105	+100	+100	+100	-	_
Maximum air pressure	120	145	130	180	100	100

Table 47: SR SUNTOUR tyre pressure table for the air fork

- 3 Detach high-pressure damper pump.
- 4 Measure the distance between the crown and the dust seal. This distance is total deflection of the fork.
- **5** Push a cable tie attached temporarily downwards against the dust seal.
- **6** Put on normal pedelec clothing (including baggage).
- 7 Sit on the pedelec in your usual riding position and support yourself against an object, such as a wall or tree.
- **8** Get off the pedelec without allowing it to deflect.

- **9** Measure distance between the dust seal and the cable tie.
- ⇒ This measurement is the sag. The recommended value is between 15% (hard) and 30% (soft) of the total fork deflection.
- **10** Increase or reduce air pressure until you have reached the desired sag.
- **11** If the sag is correct, turn the **air valve cap** clockwise.
- **12** If you are unable to achieve the required sag, an internal adjustment may be needed. Contact specialist dealer.

6.5.12 Fork rebound damping

Only applies to pedelecs with this equipment

Rebound damping in the suspension fork and the rear frame damper determines the speed at which the rear frame damper rebounds after being subjected to load. Rebound damping controls the suspension fork extension and rebound speed, which, in turn, has an impact on traction and control.

Rebound damping can be adjusted to body weight, spring stiffness, deflection, the terrain and the pedelec rider's preferences.

If the air pressure or spring stiffness increases, the extension and rebound speeds also increase. Rebound damping needs to be increased to achieve an optimal setting if the air pressure or spring stiffness is increased.

The damper rebounds at a controlled speed if the fork is optimally adjusted. The wheel stays in contact with the ground when passing over bumps (blue line).

The fork head, handlebars and body follow terrain (green line) when riding over bumps. The suspension motion is predictable and controlled.



Figure 134: Optimum fork ride performance

6.5.12.1 Adjusting the SR SUNTOUR fork rebound damping

Only applies to pedelecs with this equipment



Figure 135: Example of SR SUNTOUR rebound screw (1)

- ✓ The fork sag is adjusted.
- 1 Turn the rebound screw in a clockwise direction towards the closed position until it stops.
- 2 Turn the **rebound screw** slightly in an anticlockwise direction.
- ⇒ Adjust the rebound damper in such a way that the fork rebounds quickly, but without bottoming out upward. Bottoming out refers to when the fork rebounds too quickly and stops moving abruptly once it has reached the full rebound distance. You can hear and feel a slight impact when this happens.

6.5.13 Riding light

Example 1

If the headlight is positioned too high, oncoming traffic will be dazzled. This can cause a serious accident with fatalities.

Example 2

Positioning the headlight correctly can ensure that oncoming traffic is not dazzled and no-one is put at risk.

Example 3

If the headlight is positioned too low, the space ahead is not illuminated to an optimum extent and the rider's vision is reduced in the dark.




Figure 136: Light positioned too high (1), correctly (2) and too low (3)

6.5.13.1 Adjusting the headlight




Figure 137: Measuring on the wall

4 Place pedelec 5 m in front of the wall.

5 Stand the pedelec up straight.

- 1 Position the pedelec so that its front is facing a wall.
- 2 Mark the height of the headlight (1) on the wall with chalk.
- 3 Mark half the height of the headlight (2) on the wall with chalk.

- 6 Hold the handlebars straight with both hands. Do not use the kickstand.
- 7 Switch on riding light.




Figure 138: Light positioned too high (1), correctly (2) and too low (3)

- 8 Check the position of the light beam.
- ▶ (I) if the upper edge of the light beam is above the headlight height mark (1), the riding light will dazzle. The headlight must be positioned lower.
- ▶ If the mid-point of the light beam is on or slightly below the mark showing half the height of the headlight (2), the lighting is optimally positioned.
- ▶ If the light beam is in front of the wall, move the headlight up.

6.5.14 Adjust on-board computer

/ CAUTION

Crash caused by distraction

A lack of concentration while riding increases the risk of an accident. This may cause a crash with serious injuries.

- ▶ Never allow yourself to be distracted by the on-board computer.
- ➤ Stop pedelec if you want to make inputs on the on-board computer other than change the level of assistance. Only enter data when the bicycle is stationary.

Notice

- Do not use on-board computer as a handle. The on-board computer may become irreparably damaged if you use it to lift the pedelec.
- ▶ Remove the on-board computer from its mount if the pedelec is not going to be used for several weeks. Store the on-board computer away safely in a dry environment at room temperature.

The internal on-board computer battery discharges when it is not in use. This can cause damage to the internal on-board computer battery.

► Charge internal on-board computer battery every 3 months for at least 1 hour.

6.5.14.1 Attaching the on-board computer

Notice

If the rider is not present, the on-board computer can be used without authorisation, e.g. it may be stolen, the system settings may be changed or journey information may be read.

▶ Remove on-board computer when you park.

The system is switched off by removing the onboard computer.

6.5.14.2 Removing the on-board computer

▶ Push the on-board computer catch down and simultaneously push the on-board computer forwards and out of the mount.

6.5.14.3 Attaching the on-board computer

- 1 Place the on-board computer on the mount.
- 2 Push the on-board computer back as far as it will go.



Figure 139: Push on-board computer (2) over the onboard computer catch (1) until it locks into the mount (3)

6.5.14.4 Securing the on-board computer against removal

- 1 Detach the on-board computer mount from the handlebars.
- 2 Place on-board computer in its mount.
- 3 Fasten the blocking screw (M3 thread, 8 mm in length) into its designated thread in the mount from below.
- 4 Fit the mount to the handlebars.
- ⇒ The on-board computer is secured against removal.

6.5.14.5 Charging the on-board computer battery

Notice

The on-board computer battery discharges when it is not in use. This can cause irreparable damage to the on-board computer battery.

- ► Recharge the on-board computer battery for at least 1 hour every 3 months.
- ✓ If the on-board computer battery is low when the on-board computer is switched, ATTACH TO PEDELEC appears on the text display for three seconds. The on-board computer will then switch back off.

There are two options for charging the battery.

Charging on the pedelec

- Once a battery has been inserted into the pedelec, place the on-board computer in the onboard computer mount. Press the battery On-Off button.
- 2 Using the pedelec

Charging using the USB port

- 1 Open the protective flap on the USB port.
- 2 Connect the USB port to a commercially available USB charger or the USB port on a computer (5 V charge voltage; max. 500 mA charging current), using a suitable USB cable.
- ✓ USB CONNECTED is displayed on the onboard computer.

6.5.14.6 Changing the system settings

The System settings can be displayed and changed no matter whether the on-board computer is inserted in the mount or not. A few settings are only visible and changeable if the on-board computer is inserted. A few menu options may be missing, depending on the equipment used.

- ▶ Press the Info button (on-board computer) and the RESET button together.
- ⇒ SETTINGS is displayed on the on-board computer. The System settings is opened.
- Press the info button (on-board computer) repeatedly until the system setting which you wish to change is displayed.
- Press the plus button or the minus button to change the displayed setting.
- ▶ Press and hold the RESET button for 3 seconds to save the changed system settings and return to the journey information.

Display	Change
- CLOCK +	The current time can be adjusted. If you hold the setting button down, you can change the time more quickly.
- WHEEL CIRCUM +	The value pre-set by the manufacturer can be changed by ± 5%. This menu option is only shown when the display is positioned in its mount.
- ENGLISH +	You can change the language for text messages. You can choose between English, German, French, Dutch, Spanish, Danish, Swedish, Italian and Portuguese.
- UNIT KM/MI +	You can choose whether the speed and distance are displayed in kilometres or miles.
- TIME FORMAT +	You can display the time in 12- hour clock or 24-hour clock format.
- SHIFT RECOM. OFF +	You can turn the gear recommendation indicator on or off.

Table 48: Changing the system settings

6.6 **Accessories**

Not included in price

We recommend a parking stand into which either the front wheel or rear wheel can be inserted securely for pedelecs which do not have a kickstand. The following accessories are recommended:

Description	Article number
Protective cover for electrical components	080-41000 ff
Panniers, system component	080-40946
Rear wheel basket, system component	051-20603
Bicycle box, system component*	080-40947

Table 49: Accessories

6.6.1 **Child seat**

/! WARNING

Crash caused by incorrect child seat

Pannier racks with a maximum load capacity under 27 kg and the down tube are unsuitable for mounting child seats and may break. Such an incorrect position may cause a crash with serious injuries for the pedelec rider or child.

▶ Never attach a child seat to the saddle. handlebars or down tube.

/! CAUTION

Crash caused by improper handling

When using child seats, the pedelec's handling characteristics and stability change considerably. This can cause a loss of control, a crash and injuries.

➤ You should practice how to use the child seat safely before using the pedelec in public spaces.

/ CAUTION

Risk of crushing due to exposed springs

The child may crush his/her fingers on exposed springs or open mechanical parts of the saddle or the seat post.

- Never install saddles with exposed springs if a child seat is being used.
- ► Never install suspension seat post with open mechanical parts or exposed springs if a child seat is being used.

Notice

- ▶ Observe the legal regulations on the use of child seats.
- ▶ Observe the operating and safety instructions for the child seat system.
- ▶ Never exceed the maximum permitted total weight.

The specialist dealer will advise you on which child seat system is suitable for the child and the pedelec.

The specialist dealer must install the child seat the first time to ensure that it is safely fitted.

When fitting a child seat is fitted, the dealer will ensure that the seat and seat fastening mechanism are suitable.

- all components are installed and securely fastened,
- shift cables, brake cables, hydraulic and electrical cables are adjusted as necessary,
- the pedelec rider has optimum freedom of movement
- the maximum permitted total weight of the pedelec is observed.

The specialist dealer will provide instruction on how to handle the pedelec and the child seat.

6.6.2 Trailer



Crash caused by brake failure

The braking distance may be longer if the trailer is carrying excessive load. The long braking distance can cause a crash or an accident and injuries.

▶ Never exceed the specified trailer load.

Notice

- ► The *operating* and safety instructions for the trailer system must be observed.
- Observe the statutory regulations on the use of bicycle trailers.
- ▶ Only use type-approved coupling systems.

A pedelec which is approved for towing a trailer will bear an appropriate adhesive label. You may only use trailers with a tongue load and weight which do not exceed the permitted values.




Figure 140: Trailer sign

The specialist dealer will advise you on which trailer system is suitable for the pedelec. The specialist dealer must install the trailer the first time to ensure that it is fitted safely.

6.6.2.1 Approval for trailer with Enviolo hub

Only applies to pedelecs with this equipment

Only compatible bicycle trailers are approved for ENVIOLO hub gears.

KETTLER

KETTLER QUADRIGA child trailer

BURLY

Trailer	Adapter
Minnow Bee	
Honey Bee	
Encore	
solo	
Cub	Item no. 960038
D'Lite	
Normad	
Flatbed	
Tail Wagon	

CROOZER

Trailer	Adapter	
Croozer Kid	Item no. 122003516,	
Croozer Kid Plus	XL: +10 mm Item no. 122003716 Item no. 12200715	
Croozer Cargo	Croozer axle nut adapter with Thule coupling	
Croozer Dog		

THULE

Adapter
Item no. 20100798

6.6.2.2 Approval for trailer with ROHLOFF hub

Only applies to pedelecs with this equipment

ROHLOFF Speedhub 500/14

As a basic rule, it is permitted to use a trailer in combination with the ROHLOFF SPEEDHUB 500/

There must be **no component contact** with the cover of the ROHLOFF E-14 gear shift unit caused by pressure or tension at any time during assembly or when riding with the trailer **under any circumstances**.

Collision causing possible damage to the ROHLOFF E-14 gear shift unit can be avoided with suitable washers or special axle adapters (spacers or polygon) from the coupling manufacturer concerned.

Speedhub with A-12



Risk of an accident

The A-12 attachment screw has a very low screwin depth. The screw or the thread in the axle plate can be damaged or ripped out if a trailer hitch is fitted directly onto the axle or the A-12 attachment screw. This may cause an accident with injuries.

Never fit a trailer hitch directly on the axle and the A-12 attachment screw to a ROHLOFF Speedhub with an A-12 axle system in a 12 mm quick release axle frame.

6.6.3 Mobile holder

Only applies to pedelecs with this equipment

A holder for SP Connect mobile case is fitted to the stem.

- ✓ Observe the operating instructions for the mobile and the SP Connect mobile case.
- ✓ Use on tarmacked roads only.
- ✓ Protect mobile from theft.
- ➤ To attach: insert the SP Connect mobile case in the holder and turn 90° to the right.
- ► To release: turn the SP Connect mobile case 90° to the left and remove.

6.6.4 Tubeless and airless tyres

Riding a pedelec without tubes reduces the risk of tyre punctures or even avoids them completely.

The specialist dealer will advise you on which tyre system is suitable for the pedelec.

A specialist dealer must carry out conversion to tubeless or airless tyres for safety reasons.

6.6.5 Suspension fork coil spring

If the desired suspension fork sag cannot be achieved after adjustment, the coil spring assembly must be replaced with a softer or harder spring.

► Fit a softer coil spring assembly group to increase the sag.

Fit a harder coil spring assembly group to decrease the sag.

6.6.6 Pannier rack

The specialist dealer will advise on choosing a suitable pannier rack.

The specialist dealer must install the pannier rack the first time to ensure that it is safely fitted.

When installing a pannier rack, the specialist dealer makes sure that the fastening mechanism is suitable for the pedelec and that all components are installed and firmly fastened. They will also ensure that shift cables, brake cables, hydraulic lines and electrical cables are adjusted as necessary, the person riding has optimum freedom of movement and the pedelec's maximum permitted total weight is not exceeded.

The specialist dealer will provide instruction on how to handle the pedelec and the pannier rack.

6.6.7 Panniers and cargo boxes

▶ Use a paint protection film when attaching panniers. This will reduce abrasion on paint and wear on components.

6.7 Personal protective equipment and accessories for road safety

Seeing and being seen is crucial in road traffic. The following requirements must be met for riding a pedelec safely on public roads.




Figure 141: Road safety

- 1 The helmet must have a reflective strip or a light in a clearly visible colour.
- 2 Cycle clothing is essential at all times of year. Clothing should be retroreflective or as light as possible. Fluorescent materials are also suitable. High-visibility jackets and straps on your upper body ensure even greater safety. Never wear a skirt. Always wear trousers which reach down to your ankles instead.
- 3 The large red reflector with a "Z" registration mark and the red rear light must be clean. The rear light is attached high enough so that cars can see it (minimum height 25 cm). The rear light must work.
- 4 The two reflectors on the two non-slip pedals must be clean.
- 5 The yellow spoke reflectors on both wheel or the white, fluorescent surface on both wheels must be clean.
- 6 The white front light must work and must be positioned so that it does not dazzle other road users. The white front light and the white reflector must be clean at all times.

- 7 The two separate brakes on the pedelec must work at all times.
- 8 The clear sounding bell must be fitted and must work.

6.8 Before each ride

► Check pedelec before each ride; see Section 7.1.

Check list before each ride				
	Check everything is sufficiently clean.	See Section <u>7.2</u> .		
	Check guards.	See Section <u>7.1.1</u> .		
	Check battery to ensure it is firmly in place.	See Section <u>6.16.2</u> .		
	Check lights.	See Section <u>7.1.13</u> .		
	Check brake.	See Section 7.1.14.		
	Check suspension seat post.	See Section 7.1.9.		
	Check pannier rack.	See Section <u>7.1.5</u> .		
	Check bell.	See Section <u>7.1.10</u> .		
	Check handles.	See Section <u>7.1.11</u> .		
	Check rear frame damper.	See Section <u>7.1.4</u> .		
	Check frame.	See Section <u>7.1.2</u> .		
	Check wheel concentricity.	See Section <u>7.1.7</u> .		
	Check quick releases.	See Section 7.1.8.		
	Check mudguards.	See Section 7.1.6.		
	Check USB cover.	See Section <u>7.1.12</u> .		

- ▶ Be alert to any unusual noises, vibrations or odours while riding. Be alert to any unusual operating sensations when braking, pedalling or steering. This indicates material fatigue.
- ⇒ Take pedelec out of service if there are any deviations from the "Before each ride" checklist or any unusual behaviour. Contact specialist dealer.

6.9 Straightening the quickly adjustable stem

Only applies to pedelecs with this equipment

1 Open stem clamping lever.




Figure 142: Example of All Up with open stem clamping lever

2 Pull handlebars into the highest possible position.




Figure 143: Example of All Up pulled into highest possible position

3 Turn handlebars 90° anti-clockwise so that they are straight.




Figure 144: Example of All Up in straight position

- 4 Place handlebars at required height.
- 5 Close stem clamping lever.

6.10 Using the pannier rack



Crash caused by loaded pannier rack

The pedelec is handled differently with a loaded pannier rack, in particular when the rider needs to steer and brake. This can lead to a loss of control. This may cause a crash with injuries.

➤ You should practice how to use a loaded pannier rack safely before using the pedelec in public spaces.

Crushing the fingers in the spring flap

The spring flap on the *pannier rack* operates with a high clamping force. There is a risk of crushing the fingers.

- ► Never allow the spring flap to snap shut in an uncontrolled manner.
- ▶ Be careful where you position your fingers when closing the spring flap.

Crash caused by unsecured baggage

Loose or unsecured objects on the *pannier rack*, e.g. belts, may become caught in the rear wheel. This may cause a crash with injuries.

Objects which are fastened to the pannier rack may cover the *reflectors* and the *riding light*. Other users may not see the pedelec on public roads as a result. This may cause a crash with injuries.

- ► Secure any objects which are attached to the pannier rack sufficiently.
- ▶ Objects fastened to the pannier rack must never cover the reflectors, the headlight or the rear light.
- ▶ Distribute the baggage as evenly as possible between the left- and right-hand side.
- We recommend the use of panniers and baggage baskets.



Figure 145: The maximum load bearing (1) capacity is indicated on the pannier rack

- ► Pack the pedelec to its maximum permitted total weight (PTW) only.
- ▶ Pack the pedelec to the pannier rack's (1) maximum load capacity only.
- ▶ Use the original pannier rack only.

6.11 Raising the kickstand

► Use your foot to raise kickstand completely before setting off.

6.12 Using the saddle

- ▶ Do not wear studded jeans as these can damage the saddle covering.
- ▶ Wear dark clothes for your first few rides as new leather saddles can stain clothing.

Riders often experience pain in the sitting bones, especially beginners or at the start of the season, after a longer break. The periosteum around the sitting bones is irritated as it is unaccustomed to the chafing. To reduce chafing:

- wear cycling shorts with shock-absorbing seat padding
- ▶ use a chamois cream or ointment.
- ⇒ The sensation of pain is reduced after five to six rides, although it may increase again after two to three weeks of riding.

6.12.1 Using the leather saddle

Sunlight and UV light tarnish the colour and cause the leather to dry out and fade.

- ▶ Park pedelec in the shade.
- Always use a saddle cover.

Moisture may cause the leather to detach from material beneath and mould may form.

- ▶ If the leather saddle gets wet, dry saddle completely.
- Always use a saddle cover.

6.13 Using the pedals

The ball of the foot is placed on the pedal when riding and pedalling.



Figure 146: Correct (1) and incorrect (2) foot position on the pedal

6.14 Using the bell

- 1 Press the bell button downwards.
- 2 Let button spring back.

6.15 Using the handlebars

- ▶ Wear heavily padded cycling gloves.
- ⇒ This supports sensitive areas of your palms.
- Vary your grip position continuously while riding.
- ➡ This prevents overstraining and fatigue in your hands.

6.15.1 Using multi-position handlebars

Only applies to pedelecs with this equipment

Multi-position handlebars are ideal for dynamic riding. The contoured ends of the handlebars, also known as horn handlebars, provide a variety of grip options. Changing muscle groups reduces strain on the hands, arms and back during longer rides.

- ► Vary your grip position continuously while riding.
- ⇒ This prevents overstraining and fatigue in your hands.



Figure 147: Grip positions on the multi-position handlebars

Grip position 1

The top grip position is suitable for riding slowly.

Straighten your upper body without tensioning in this position.

Grip position 2 and 3

The middle and bottom grip position is suitable for fast rides and riding on inclines.

- ▶ In the middle position, hold the arm and wrist upright and relax tension.
- ▶ In the bottom position, place your upper body slightly lower. Keep your fingers close to the brake handle ready for use.

6.15.2 Using bar ends

Only applies to pedelecs with this equipment

Bar ends can be added to normal handlebars.

Adjustable bar ends feature a ball joint which you can use to choose the optimum position as required.

- ▶ Adjust bar ends correctly. To do so, your hand, elbow and shoulder must be in line with one another when the hand takes hold of the bar ends
- ▶ During the ride, keep varying your grip position between a flat (1) and upright (2) hand position.
- ⇒ This prevents overstraining, fatigue and numbness in your hands and fingers.




Figure 148: Grip positions on a bar end

6.15.3 Using leather handles

Only applies to pedelecs with this equipment

Sweat and grease from the skin are two of the greatest enemies of leather. They penetrate the surface of leather and cause it to disintegrate more quickly, meaning the leather can soften and abrade.

▶ Wear gloves.

Sunlight and UV light damage the colour and can cause the leather to dry out and fade.

▶ Park pedelec in the shade.

Moisture may cause the leather to detach from material beneath and mould may form.

► If the leather handles get wet, dry handles completely.

6.16 Using the battery

✓ Switch off the battery and the drive system before removing or inserting the battery.

6.16.1 Frame battery

Only applies to pedelecs with this equipment

6.16.1.1 Removing the frame battery




Figure 149: Removing and inserting the frame battery

- **1** Open battery lock with battery key (1).
- **2** Tip the battery out of the top section of the frame battery mount.
- **3** Pull from the frame battery mount (2).

6.16.1.2 Inserting the frame battery

- 1 Place the battery on the contacts in the lower section of the frame battery mount (3).
- 2 Remove the battery key from the battery lock (4).
- 3 Tip the battery into the top section of the frame battery mount until it will go no further.
- ⇒ There is an audible clicking noise.
- **4** Check the battery to make sure it is firmly in place.

6.16.2 Pannier rack battery

Only applies to pedelecs with this equipment

6.16.2.1 Removing the pannier rack battery




Figure 150: Removing (2) and inserting (3) the pannier rack battery

- 1 Open battery lock with battery key (1).
- 2 Pull the pannier rack battery backwards and out of its mount (2).
- **3** Remove the battery key from the battery lock (1).

6.16.2.2 Inserting the pannier rack battery

- 1 Insert battery into the pannier rack battery mount with the contacts facing the front until it clicks into place (3).
- **2** Check the battery to make sure it is firmly in place.

6.16.3 Integrated battery

Only applies to pedelecs with this equipment

6.16.3.1 Removing the integrated battery




Figure 151: Removing the integrated battery

- 1 Open battery lock with battery key (1).
- ⇒ The battery is released and falls into the retainer guard (2).
- 2 Hold the battery in your hand from below. Use the other hand to push on the retainer guard from above (3).
- ⇒ The battery is released and falls into the hand (4).
- 3 Remove the battery from the frame.
- 4 Remove the battery key from the battery lock.

6.16.3.2 Inserting the integrated battery




Figure 152: Inserting the integrated battery

- 1 Place the battery into the integrated battery lower mount with the contacts facing the front (1).
- **2** Flip the battery upwards so that the battery is held by the retainer guard (2).
- 3 Push the battery upwards (3).
- ⇒ There is an audible clicking noise.
- 4 Check battery to ensure it is firmly in place.
- **5** Lock the battery with the battery key; otherwise, the battery may fall out of the mount when you open the see (4).
- 6 Remove the battery key from the battery lock.
- 7 Check the battery to ensure it is firmly in place before each ride.

6.16.4 Charging the battery

- ✓ The ambient temperature during the charging process must be within the range from 0 °C to 40 °C.
- ✓ The battery can remain on the pedelec or can be removed for charging.
- ✓ Interrupting the charging process does not damage the battery.
- 1 Remove the cable connection cover if necessary.
- 2 Connect the mains plug of the charger to a normal domestic, grounded socket.

Connection data

230 V, 50 Hz

Notice

- Check that mains voltage! The power source voltage must match the voltage indicated on the charger nameplate. Chargers labelled 230 V may be operated at 220 V.
- 3 Connect the charging cable to the battery's charging port.
- ⇒ The charging process starts automatically.
- ⇒ The battery level indicator shows the charge level during charging. When the drive system is switched on, the *on-board computer* displays the charging process.

Notice

If an error occurs during the charging process, a system message is displayed.

- Remove the charger and battery from operation immediately and follow the instructions.
- ⇒ The charging process is complete when the LEDs on the battery level indicator go out.
- **4** Once charging is complete, disconnect the battery from the charger.
- 5 Disconnect the charger from the mains.

6.16.5 Charging the dual battery

Only applies to pedelecs with this equipment

Notice

- Charge the battery via the accessible charging socket only.
- ▶ Never open a sealed charging socket. Charging via a pre-sealed charging socket can cause irreparable damage.

6.16.5.1 Charging process when two batteries are used

- If two batteries are attached to a pedelec, charge both batteries via the non-sealed socket.
- ➡ The two batteries are charged alternately during charging. Charging switches automatically between the two batteries several times. The charging time is twice as long.
- ⇒ The two batteries are discharged alternately during use.

6.16.5.2 Charging process when one battery is used

- ▶ If only one battery is inserted, only charge the battery with an accessible charging socket.
- ► Charge the battery with the sealed charging socket outside its mount only.

6.16.6 Using double battery model with a single battery only

One of the charging sockets is not accessible or is sealed with an end cap on pedelecs with two batteries.




Figure 153: Covering open contacts with cover cap – example: pannier rack

▶ If you wish to use just one battery on a pedelec which is designed for two batteries, cover the contacts in the free slot with the supplied cover cap (1). otherwise, there is a risk of a short circuit caused by the open contacts.

6.16.7 Waking the battery

- ✓ The battery switches to sleep mode to protect itself when not used for a longer period. The LEDs on the battery level indicator do not light up.
- ▶ Press the On-Off button (battery).
- ⇒ The battery level indicator shows the charge level.

6.17 Using pedelec with the electric drive system

6.17.1 Switching on the electric drive system

! CAUTION

Crash caused by lack of readiness for braking

When it is switched on, the drive system can be activated by the application of force on the pedals. There is a risk of a crash if the drive is activated unintentionally and the brake is not reached.

- Never start the electric drive system, or switch it off immediately, if the brake cannot be reached safely and reliably.
- ✓ A sufficiently charged battery has been inserted into the pedelec.
- ✓ The battery is firmly positioned. The battery key has been removed.

There are three options for switching on the drive system.

On-Off button (battery)

▶ Press the On-Off button (battery) briefly.

On-Off button (on-board computer)

Press the On-Off button (on-board computer) briefly.

Switched-on on-board computer

- ▶ If the on-board computer is already switched on when it is inserted into its mount, the electric drive system is switched on automatically.
- ⇒ After switching on, a speed of 0 KM/H is displayed on the on-board computer. If it is not, check whether the on-board computer is fully engaged into position.
- ⇒ If the drive system is switched on, the drive is activated as soon as the pedals are moved with sufficient force (except if in push assist mode or the level of assistance is "OFF").
- ⇒ The motor power is determined by the level of assistance set on the on-board computer.

6.17.2 Switching off the electric drive system

As soon as the rider stops pushing the pedals in normal mode or reaches a speed of 25 km/h, the drive system switches off the assistance system. The assistance system starts up again when you push the pedals and your speed is less than 25 km/h.

The system switches off automatically ten minutes after the last command. There are three options for switching off the drive system manually.

On-Off button (on-board computer)

Press the On-Off button (on-board computer) briefly.

On-Off button (battery)

▶ Press the On-Off button (battery).

Removing the on-board computer

- ▶ Remove the on-board computer from the mount.
- ⇒ The LEDs on the charge level indicator (battery) go out.

6.18 Using the on-board computer

/! CAUTION

Crash caused by distraction

A lack of concentration while riding increases the risk of an accident. This may cause a crash with serious injuries.

- ► Never allow yourself to be distracted by the on-board computer.
- ➤ Stop pedelec if you want to make inputs on the on-board computer other than change the level of assistance. Only enter data when the bicycle is stationary.

Notice

- ▶ Do not use on-board computer as a handle. The on-board computer may become irreparably damaged if you use it to lift the pedelec.
- ▶ Remove the on-board computer from its mount if the pedelec is not going to be used for several weeks. Store the on-board computer away safely in a dry environment at room temperature.

The internal on-board computer battery discharges when it is not in use. This can cause damage to the internal on-board computer battery.

► Charge internal on-board computer battery every 3 months for at least 1 hour.

6.18.1 Using the USB port

Notice

Any moisture penetrating through the USB port may trigger a short circuit in the on-board computer.

Regularly check the position of the rubber cover on the USB port and adjust it as necessary.

The USB port can be used to operate external devices which can be connected using a standard micro A/micro B USB 2.0 cable.

- 1 Open the protective flap on the USB port.
- 2 Replace the protective flap after using the USB port.
- 6.18.2 Switching on the on-board computer
- ► Press the On-Off button (on-board computer) briefly.
- ⇒ The electric drive system is switched on.
- 6.18.3 Switching off the on-board computer

If the on-board computer is not inserted into its mount, it will switch off automatically after one minute to save energy if no button is pressed.

- ► Press the On-Off button (on-board computer) briefly.
- ⇒ The electric drive system is switched off.

6.18.4 Using the push assist system



Injury from pedals or wheels

The pedals and the drive wheel turn when the push assist system is used. There is a risk of injury if the wheels are not in contact with the ground when the push assist system is used (e.g. when carrying the pedelec up stairs or when loading it on a bicycle rack).

- Only use the push assist mode when pushing the pedelec.
- You must steer the pedelec securely with both hands when using push assist.
- Allow for enough freedom of movement for the pedals

The push assist system helps with pushing the pedelec. The speed can be a maximum of 6 km/h in this case.

- ✓ The tractive power of the push assist and its speed can be influenced by the selection of gear. We recommend using first gear for cycling uphill to protect the drive.
- ✓ The level of assistance OFF must not be selected.
- 1 Press the push assist button briefly.
- 2 Press and hold the plus button within 3 seconds to switch on the push assist.
- 3 Release the plus button to shut off the push assist. The push assist system switches off automatically as soon as the wheels are blocked or the speed exceeds 6 km/h.

6.18.5 Using the riding light

- ✓ The drive system needs to be already switched on to turn on the *riding light*.
- ▶ Press the riding light button.
- ⇒ The riding light is switched on (riding light symbol is displayed) or switched off (riding light symbol is not displayed).

6.18.6 Selecting the level of assistance

- Press the plus button to increase the level of assistance.
- Press the minus button to reduce the level of assistance.

6.18.7 Journey information

The displayed **journey information** can be changed and partially reset.

If the on-board computer is removed from its mount, all function values are saved and can still be displayed.

6.18.7.1 Switching the displayed journey information

Press the on-board computer info button or the operating element info button repeatedly until the required journey information is displayed.

6.18.7.2 Resetting the journey information

- ▶ If you wish to reset the journey information Trip Distance, Trip Time and Avg. Speed, switch to one of these three functions. Press the RESET button until the indicator is set to zero. This will also reset the readings for the other two functions.
- ▶ If you wish to reset the Max. speed journey information, switch to this function. Press the RESET button until the indicator is set to zero.
- ▶ If you wish to reset the Range journey information, switch to this function. Press the RESET button until the indicator is the factory setting value.

6.19 Using the brake

WARNING

Crash caused by brake failure

Oil or lubricant on the brake disc in a disc brake or on the rim of a rim brake can cause the brake to fail completely. This may cause a crash with serious injuries.

- Never allow oil or lubricant to come into contact with the brake disc or brake linings or on the rim of a rim brake.
- ▶ If the brake linings have come into contact with oil or lubricant, contact specialist dealer to have the components cleaned or replaced.

If the brakes are applied continuously for a long time (e.g. while riding downhill for a long time), the fluid in the brake system may heat up. This may create a vapour bubble. This will cause air bubbles or water contained in the brake system to expand. This may suddenly make the lever travel wider. This may cause a crash with serious injuries.

- ► Release the brake regularly when riding downhill for a longer period of time.
- Use the front and rear wheel brakes alternately.

The motor's drive force is switched off during the ride as soon as the pedelec rider is no longer pedalling. The electric drive system does not switch off when braking.

▶ Do not pedal while braking to ensure optimum braking.

6.19.1 Use handbrake

Only applies to pedelecs with this equipment




Figure 154: Handbrake, front (2) and rear (1) – Shimano brake used as an example

- Pull the left handbrake to apply the front wheel brake.
- ▶ Pull the right handbrake to apply the rear wheel brake.

6.19.2 Using the back-pedal brake

Only applies to pedelecs with this equipment

- **1** Move pedals a little beyond the 3 o'clock and 9 o'clock position.
- 2 Pedal in the opposite direction to the direction of travel until the desired speed has been reached.

6.20 Use suspension and damping

Compression adjuster set to hard

- Causes the suspension fork to move higher within the deflection range. This improves efficiency, maintains momentum and makes it easier to ride over uniformly hilly terrain and around bends.
- Deflection may feel somewhat harder on rugged terrain.

Compression adjuster set to soft

- Causes the fork to deflect quickly and easily. This makes it easier to maintain speed and momentum when riding over uneven rugged terrain
- Deflection feels somewhat less hard on rugged terrain.




Figure 155: Optimum ride performance over bumps

When optimally adjusted, the fork deflects quickly and unhindered when the bike hits bumps and absorbs a bump. Traction is retained (blue line).

Threshold

The damping threshold prevents deflection until a medium impact or downward force occurs.

Threshold mode increases drive efficiency over level terrain.

The threshold setting can be used to improve pedalling efficiency over flat or hilly terrain. In threshold mode, higher pedelec speeds lead to greater impact force when a pedelec hits a bump, causing the fork to deflect, and the bump is absorbed.

The fork responds quickly to the bump. The headset and handlebars rise slightly when absorbing a bump (green line).

- When the compression adjuster is in the open position (against the stop in an anti-clockwise direction), the suspension fork deflects quickly and unhindered through its entire deflection range when an impact or downward force occurs.
- When the compression adjuster is in the threshold position, the suspension fork counteracts deflection until a medium impact or downward force occurs.
- When the compression adjuster is in the blocked position (against the stop in a clockwise direction), the suspension fork counteracts deflection throughout its deflection range until a strong impact or downward force occurs.

6.20.1 Adjusting the SR SUNTOUR compression adjuster




Figure 156: SR SUNTOUR compression adjuster in open (1) and closed (2) position

- ► Place compression adjuster in the OPEN position.
- ⇒ The compression adjuster is open.
- ▶ Place **compression adjuster** in the LOCK position.
- ⇒ The compression adjuster is locked.
- ▶ Position compression adjuster between OPEN and LOCK.
- ➡ This position allows you to fine-tune the compression adjuster.

We recommend setting the **compression adjuster** to the OPEN position first.

6.21 Gear shift

The selection of the appropriate gear is a prerequisite for a physically comfortable ride and making sure that the electric drive system functions properly. The ideal pedalling frequency is between 70 and 80 revolutions per minute.

► Stop pedalling briefly when changing gears. This makes it easier to switch gears and reduces Wear on the drive train.

6.21.1 Using the derailleur gears

The speed and range can be increased while applying the same force if you select the right gear.

✓ Stop pedalling briefly when changing gears. This
makes it easier to switch gears and reduces <u>Wear</u>
on the drive train. However, keep the crank
moving while switching gears.




Figure 157: Switching gears with lever A, using gear shift SL-M315 as an example

Lever A switches from a smaller pinion to a larger one. The number of pinions switched depends on the selected position of lever A.

- ▶ Place shifter A in position 1.
- ⇒ System shifts one pinion higher.
- ▶ Place shifter A in position 2.
- ⇒ System shifts two pinions higher.




Figure 158: Switching gears with lever B, using gear shift SL-M315 as an example

Lever B switches from a larger pinion to a smaller one.

- ▶ Place shifter B in position 1.
- ⇒ System shifts one pinion lower.

Switching gears

- Select the appropriate gear with the gear shift unit.
- ⇒ The gear shift switches gear.
- ⇒ The shifter returns to its original position.
- Clean and lubricate the rear derailleur if gear changes block.

6.21.2 Use SHIMANO hub gear

Only applies to pedelecs with this equipment

! CAUTION

Crash caused by incorrect use

If the rider applies too much pressure on the pedals during a gear change and activates the shifter or changes several gears at a time, their feet may slip from the pedals. This may cause a crash or flip-over with injuries.

Switching down several gears to a low gear may cause the twist grip outer sleeve to suddenly come off. This will not have an adverse effect on the twist grip's correct functioning since the outer guide returns to its original position after the gear change is complete.

- Apply little pressure on the pedals while changing gears.
- ▶ Never change more than one gear at a time.

Notice

The interior hub is not completely waterproof. If water gets into the hub, it may rust and the gear switch function may no longer function as a result.

Never use the pedelec in places where water may get into the hub.

In rare cases, noises may be heard from the rear derailleur in the hub interior after a gear change. This is normal when gears are changed.

Never detach the hub yourself. Contact specialist dealer.




Figure 159: Example: use of SHIMANO Nexus gear shift

- ► Turn the twist grip (1) backwards to switch up a gear (4).
- ► Turn the twist grip (1) forwards to switch down a gear (2).
- ⇒ The gear shift switches gear.
- ⇒ The screen display (3) shows the changed gear.

6.21.3 Using eShift

eShift refers to the integration of electronic gear shift systems into the electric drive system.

6.21.3.1 Using eShift with SHIMANO DI2 automatic hub gears

Only applies to pedelecs with this equipment

The automatic SHIMANO DI2 hub gear can be used in manual or automatic mode. Use the shifter to change gears in manual mode. In automatic mode, the shift system changes gear automatically depending on the speed, pedalling power and pedalling frequency. You will find how to switch from automatic to manual mode, depending on the shifter used, described in your operating instructions on the on-board computer. If you use the shifter when in automatic mode, the gear system will change to the next gear and it will remain in automatic mode. Manual gear changes in automatic mode influence shift behaviour in the gear system and adjust gear changes to ride performance. If the system is switched on for the first time when a new, unused wheel is used, the system will learn the gears first. To do so, the automatic system changes to the highest/most difficult gear and then switches through all gears during the first ride. The new gear is shown briefly on the on-board computer each time it is changed.

Since the motor detects the gear shift and consequently reduces motor assistance briefly, it is possible to switch gears under load or on hills. If the pedelec is brought to a halt from a speed greater than 10 km/h, the system can automatically switch back to a pre-set START GEAR.

► Adjust the START GEAR in the system settings if necessary.

6.21.3.2 Using eShift with manual SHIMANO DI2 hub gears

Only applies to pedelecs with this equipment

The new gear is shown briefly on the on-board computer each time it is changed.

Since the motor detects the gear shift and consequently reduces motor assistance briefly, it is possible to switch gears under load or on hills.

If the pedelec is brought to a halt from a speed greater than 10 km/h, the system can automatically switch back to a pre-set START GEAR.

► Adjust the START GEAR in the system settings if necessary.

6.21.3.3 Using eShift with SHIMANO DI2 automatic hub gears

Only applies to pedelecs with this equipment

Since the motor detects the gear shift and consequently reduces motor assistance briefly, it is possible to switch gears under load or on hills.

⇒ The new gear is shown briefly on the on-board computer each time it is changed.

6.22 Parking

Notice

Heat or direct sunlight can cause the *tyre pressure* to increase above the permitted maximum pressure. This can destroy the *tyres*.

- ▶ Never park the pedelec in the sun.
- ➤ On hot days, regularly check the tyre pressure and adjust it as necessary.

Moisture penetrating at low temperatures may impair individual functions due to the open structural design.

- Always keep the pedelec dry and free from frost.
- ▶ If the pedelec is used at temperatures below 3 °C, the specialist dealer must perform maintenance beforehand and prepare it for winter use.

The pedelec's force of weight may cause the kickstand to sink into soft ground, possibly causing the pedelec to topple over as a result.

- ► The pedelec must be parked on firm, level ground only.
- 1 Switch off drive system (see Section 6.17.2).
- 2 After getting off, use your foot to lower the kickstand completely before parking. Ensure that it is stable.
- 3 Park the pedelec carefully and check that it is stable
- 4 Protect saddle with saddle cover if you park the pedelec outside.
- 5 Lock the pedelec with the bicycle lock.
- **6** Remove battery to protect against theft (see Section 6.16.1.1).
- 7 Clean and service pedelec after every ride; see Section 7.2.

Check list after each ride

Cleaning				
	Lights and reflectors	See Section 7.2.5		
	Brake	See Section 7.2.5		
	Suspension fork	See Section 7.2.1		
	Suspension seat post	See Section 7.2.6		
	Rear frame damper	See Section 7.2.7		
	Pedal	See Section 7.2.4		
Care				
	Suspension fork	See Section <u>3</u> .		

6.22.1 Screwing in the quickly adjustable stem

Only applies to pedelecs with this equipment

Screw in the quickly adjustable stem to save space when parking

1 Open stem clamping lever.



Figure 160: Example of All Up with open stem clamping lever

2 Pull handlebars into highest possible position.




Figure 161: Example of All Up pulled into highest possible position

3 Turn handlebars 90° in a clockwise direction.




Figure 162: Example of All Up screwed in

- 4 Place handlebars at required height.
- 5 Close stem clamping lever.

7 Cleaning, servicing and inspection

► Clean, maintain and inspect pedelec as indicated on checklists.

Complying with these cleaning instructions can increase operational reliability, reduce wear on components, extend the service life of components and ensure safety.

Che	cklist: Before each ride	
	Check everything is sufficiently clean	See Section <u>7.2</u> .
	Check guards	See Section 7.1.1.
	Check battery to ensure it is firmly in place	See Section <u>6.17.2</u> .
	Check lights	See Section 7.1.13.
	Check brake	See Section 7.1.14.
	Check suspension seat post	See Section 7.1.9.
	Check pannier rack	See Section 7.1.5.
	Check bell	See Section 7.1.10.
	Check handles	See Section 7.1.11.
	Check rear frame damper	See Section 7.1.4.
	Check wheel concentricity	See Section 7.1.7.
	Check frame	See Section 7.1.2.
	Check quick releases	See Section 7.1.8.
	Check guards	See Section 7.1.6.
	Check USB cover	See Section 7.1.12.

Che	Checklist: After each ride		
	Clean lights	See Section 7.2.1.	
	Clean reflectors	See Section <u>7.2.1</u> .	
	Clean brake	See Section <u>7.2.5</u> .	
	Clean suspension fork	See Section <u>7.2.2</u> .	
	Care for suspension fork	See Section 3.	
	Clean suspension seat post	See Section <u>7.2.6</u> .	
	Clean rear frame damper	See Section 7.2.7.	
	Clean the pedals	See Section <u>7.2.4</u> .	

Che	cklist: weekly tasks	
	Clean chain	See Section <u>7.3.18</u> .
	City, folding, cargo and children's bikes and bicycles for young adults	When dry: every 10 days In wet conditions: every 2–6 days
	Trekking and racing bikes	When dry: every 140 200 km In wet conditions: every 100 km
	Mountain bikes	When dry: every 60 100 km In wet conditions: after every ride
	Belt (every 250-300 km)	See Section <u>7.3.17</u> .
	Care for chain.	see Section <u>7.4.16</u> and <u>7.4.16.1</u>
	City, folding, cargo and children's bikes and bicycles for young adults	When dry: every 10 days In wet conditions: every 2 6 days
	Trekking and racing bikes	When dry: every 140 200 km In wet conditions: every 100 km
	Mountain bikes	When dry: every 60 100 km In wet conditions: maintain all the time
	Maintain all-round chain guard.	See Section <u>7.4.16.1</u> .
	Check tyre pressure (at least once a week)	See Section 7.5.1.1.
	Check tyres (every 10 days)	See Section 7.5.1.2.
	eightpins seat post Refill oil (every 20 hours)	See Section 7.4.19.

Che	cklist: monthly tasks	
	Cleaning the battery	See Section <u>7.3.2</u> .
	Clean control panel	See Section 7.3.1.
	Clean on-board computer	See Section 7.3.1.
0	Check disc brake linings (once a month or after braking 1,000 times)	See Section 7.5.2.6.
_	Check rim brake brake linings (once a month or after braking 3000 times)	See Section 7.5.1.3.
	Check the rim brake surface.	See Section 7.5.2.6.
	Clean handbrake	See Section <u>7.3.15.1</u> .
	Clean brake disc	See Section 7.3.16.
	Check brake disc	See Section 7.5.2.4.
	Check brake Bowden cables.	See Section <u>7.5.2.3</u> .
	Clean pannier rack	See Section <u>7.3.4</u> .
	Clean handles	See Section <u>7.3.7</u> .
	Care for handles	See Section 7.4.8.
	Check handbrake	See Section <u>7.5.2.1</u> .
	Check hydraulic system	See Section <u>7.5.2.2</u> .
	Clean cassette	See Section 7.3.14.
	Clean chain and all-round chain guard	See Section <u>7.3.18.1</u> .
	Clean chain wheels	See Section 7.3.14.
	Clean leather handles	See Section 7.3.7.1.
	Care for leather handles	See Section 7.4.8.2.
	Clean the leather saddle	See Section 7.3.9.1.
	Care for leather saddle	See Section 7.4.11.
	Clean handlebars	See Section 7.3.6.

Che	cklist: monthly tasks	
	Cleaning the motor	See Section 7.3.3.
	Clean hub	See Section 7.3.12.
	Cleaning the frame	See Section <u>7.3.4</u> .
	Clean tyres	See Section <u>7.3.10</u> .
	Check back-pedal brake	See Section <u>7.5.2.5</u> .
	Clean saddle	See Section <u>7.3.9</u> .
	Clean seat post	See Section <u>7.3.8</u> .
	Care for seat post	See Section <u>7.4.9</u> .
	Clean shifter	See Section <u>7.3.13.1</u> .
	Cleaning gear shift	See Section <u>7.3.13</u> .
	Clean shift cables	See Section 7.3.13.
	Check disc brake	See Section 7.5.2.4.
	Clean mudguard	See Section 7.3.4.
	Clean kickstand	See Section 7.3.4.
	Clean spokes and spoke nipples	See Section 7.3.11.
	Care for spoke nipples	See Section 7.4.13.
	Clean rigid fork	See Section 7.3.4.
	Clean transmission	See Section <u>7.3.13</u> .
	Clean front derailleur	See Section 7.3.14.
	Clean stem	See Section <u>7.3.5</u> .

Check list for tasks every three months		
	Check brake pressure point	See Section 7.5.2.1.
	Check rim brake (100 hours trip time or every 2,000 km)	See Section 7.5.2.6.
	Checking the spokes	See Section 7.5.1.3.

Che	cklist: at least every six month	ns (or every 1,000 km)
_	Check Bowden cables gear shift	See Section <u>7.5.15.2</u> .
	Maintain handbrake	See Section <u>7.4.18.1</u> .
	Care for carbon seat post	See Section <u>7.4.9.2</u> .
	Check gear shift electric cables	See Section <u>7.5.15.1</u> .
	Care for suspension seat post	See Section <u>7.4.9.1</u> .
	Care for rims	See Section 7.4.10.
	Check rims	See Section <u>7.5.1.3</u> .
	Check rim hooks	See Section <u>7.5.1.3</u> .
	Care for fork	See Section <u>7.4.2</u> .
	Check gear shift	See Section 7.5.15.
	Care for pannier rack	See Section 7.4.3.
	Check chain	See Section <u>7.5.14.1</u> .
	Check derailleur gears	see Section <u>7.5.14.1</u> and <u>7.5.15.3</u>
	Check chain tension	see Section <u>7.5.4.1</u> and <u>7.5.4.2</u>
	Check wheel	See Section 7.5.1.
	Care for handlebars	See Section 7.4.7.
	Check handlebars	See Section 7.5.12.
	Check light	See Section 7.5.10.
	Care for hub	See Section 7.4.12.
	Check hub	See Section <u>7.5.14.2</u> .
	Check nipple holes	See Section <u>7.5.1.4</u> .
	Care for pedals	See Section 7.4.15.
	Check pedal.	See Section 7.5.14.
	Care for frame	See Section 7.4.1.
	Check belt tension	See Section 7.5.9.
	Check saddle	See Section 7.5.13.
	Care for shifter	See Section <u>7.4.14.2</u> .
	Care for rear derailleur articulated shaft	See Section <u>7.4.14.1</u> .
	Care for rear derailleur jockey wheels	See Section <u>7.4.14.1</u> .
	Care for kickstand	See Section 7.4.5.
	Check kickstand stability	See Section 7.5.19.
		0 0 11 0 5 0

☐ Check steering headset

Checklist: at least every six months (or every 1,000 km)		
	Servicing the stem	See Section <u>7.4.6</u> .
	Checking the stem	See Section 7.5.11.

Checklist: Annual tasks (or every 2000 km)		
	Adjust hub with cone bearing	See Section 8.5.6.
	Check nipple well (every 1,000 hours or every 2,000 km)	See Section 7.5.1.5.

MY22Z01 - 12_1.0_25.07.2022

See Section 8.5.6.

!WARNING

Crash caused by brake failure

Oil or lubricant on the brake disc in a disc brake or on the rim of a rim brake can cause the brake to fail completely. This may cause a crash with serious injuries.

- Never allow oil or lubricant to come into contact with the brake disc or brake linings or on the rim of a rim brake.
- ▶ If the brake linings have come into contact with oil or lubricant, contact specialist dealer to have the components cleaned or replaced.
- ▶ Apply the brakes a few times to test them after cleaning, servicing or repair.

The brake system is not designed for use on a pedelec which is placed on its side or turned upside down. The brake may not function correctly as a result. This can cause a crash, which may result in injuries.

If the pedelec is placed on its side or turned upside down, apply the brakes a couple of times before setting off to ensure they work as normal.

The brake seals are unable to withstand high pressures. Damaged brakes can fail and cause an accident with injury.

Never clean the pedelec with a pressure washer or compressed air.

Take great care when using a hosepipe. Never point the water jet directly at the seal section.



Crash and falling caused by unintentional activation

There is a risk of injury if the electric drive system is activated unintentionally.

▶ Remove the battery before cleaning.

Notice

Water may enter the inside of the bearings if you use a steam jet. This dilutes the lubricant inside, the friction increases and, as a result, the bearings are permanently damaged in the long term. Water may also penetrate the electric components and damage them permanently.

▶ Never clean pedelec with a pressure washer, water jet or compressed air.

Greased parts, such as the seat post, the handlebars or the stem, may no longer be safely and reliably clamped.

 Never apply grease or oil to parts which are clamped

Harsh cleaning agents such as acetone, methylene and trichloroethylene and solvents such as thinners, alcohol and corrosion protection can attack pedelec components and damage them permanently.

Use approved care and cleaning products only.

7.1 Before each ride

Complying with these cleaning instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

7.1.1 Checking the guards

The chain or belt guards, mudguards or the motor cover can break and fall off when the pedelec is transported or parked outside.

- ► Check that all guards are in place.
- ► Take pedelec out of service if a guard is damaged or missing. Contact specialist dealer.

7.1.2 Checking the frame

- Check frame for cracks, warping and damage to the paintwork.
- ▶ If there are any cracks, warping or damage to the paintwork, remove the pedelec from service. Contact specialist dealer.

7.1.3 Checking the fork

- Check fork for cracks, warping, tarnished components, leaked oil and damage to the paintwork. Also look at hidden parts on the underside.
- ➡ If there are any cracks, warping, tarnished components, leaked oil or damage to the paintwork, remove the pedelec from service. Contact specialist dealer.

7.1.4 Checking the rear frame damper

- ► Check rear frame damper for cracks, warping, tarnished components, leaked oil and damage to the paintwork. Also look at hidden parts on the underside.
- ⇒ If there are any cracks, warping, tarnished components, leaked oil or damage to the paintwork, remove the pedelec from service. Contact specialist dealer.

7.1.5 Checking the pannier rack

- 1 Hold onto pedelec by its frame. Hold onto pannier rack with the other hand.
- 2 Move the pannier rack backwards and forwards to check that all screw connections are firmly in place.
- ⇒ Tighten loose screws.
- Attach loose baskets permanently with a basket bracket or cable ties.

7.1.6 Checking the mudguards

- 1 Hold onto pedelec by its frame. Hold onto mudguard rack with the other hand.
- 2 Move the mudguard backwards and forwards to check that all screw connections are firmly in place.
- ⇒ Tighten loose screws.

7.1.7 Check wheel concentricity

- ▶ Lift the front and rear wheels one after the other and spin each wheel when lifted.
- ⇒ If the wheel is loose or crooked when it turns, take pedelec out of service. Contact specialist dealer.

7.1.8 Checking the quick releases

- ► Check quick releases to ensure that all quick releases are firmly in their fully closed end position.
- ➡ If a quick release is not firmly in its closed end position, open quick release and place in its end position.
- ⇒ If the quick release cannot be firmly placed in its end position, take pedelec out of service. Contact specialist dealer.

7.1.9 Checking the suspension seat post

- Deflect and let the suspension seat post rebound.
- ➡ If you hear unusual noises when the suspension seat post deflects and rebounds, or it yields without any resistance, take pedelec out of service. Contact specialist dealer.

7.1.10 Checking the bell

- 1 Press the bell button downwards.
- 2 Let button spring back.
- ⇒ If you do not hear a clear, distinct ring of the bell, replace bell. Contact specialist dealer.

7.1.11 Checking the handles

- ► Check the handles are firmly in place.
- ⇒ Screw loose handles firmly into place.

7.1.12 Checking the USB cover

⇒ If featured, check the position of the cover on the USB port on a regular basis and adjust if necessary.

7.1.13 Checking the riding light

- 1 Switch light on.
- 2 Check that the headlight and rear light come on.
- ⇒ If the headlight and rear lights do not come on, take pedelec out of service. Contact specialist dealer.

7.1.14 Checking the brake

- 1 Pull both handbrakes when stationary.
- 2 Push the pedals.
- ⇒ If no resistance is generated in the handbrake's usual position, take pedelec out of service. Contact specialist dealer.
- ⇒ If the brake is losing fluid, take pedelec out of service. Contact specialist dealer.

7.2 After each ride

Complying with these cleaning instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

The following items should be ready for use to clean the pedelec after each ride:

Tool		Cleaning agent	
Cloth	Bucket	₩	Dish-washing liquid
Brush	Fork oil	Silicone or Teflon oil	Acid-free lubricating grease

Table 50: Required tools and cleaning agents after each ride

7.2.1 Cleaning the riding light and reflectors



1 Clean headlight, rear light and reflectors with a damp cloth.

7.2.2 Cleaning the suspension fork



- 1 Remove dirt and deposits from the stanchions and deflector seals with a damp cloth. Check the stanchions for dents, scratches, staining or leaking oil.
- **2** Lubricate the dust seals and stanchions with a few drops of silicone spray.
- 3 Service the suspension fork after cleaning.

7.2.3 Caring for the suspension fork



► Treat dust seals with fork oil.

7.2.4 Cleaning the pedals



► Clean pedals with a brush and soapy water.

7.2.5 Cleaning the brake



► Clean dirt on the rim and brake components with a slightly dampened cloth.

7.2.6 Cleaning the suspension seat post



► Clean dirt on the articulated joints with a slightly dampened cloth immediately after a ride.

7.2.7 Cleaning the rear frame damper



Clean dirt on the articulated joints with a slightly dampened cloth immediately after a ride.

7.3 Basic cleaning

Complying with these basic cleaning instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

The following are required for basic cleaning:



Table 51: Required tools and cleaning agents for basic cleaning

✓ Remove battery and on-board computer before thorough cleaning.

7.3.1 Clean on-board computer and control panel



Notice

If water enters the on-board computer, it will be permanently damaged.

- ► Never immerse the on-board computer in water
- ▶ Never use a cleaning agent.
- Carefully clean the on-board computer and control panel with a soft, damp cloth.

7.3.2 Cleaning the battery









CAUTION

Risk of fire and explosion due to penetration by water

The battery is only protected from simple spray water. Penetration by water can cause a short circuit. The battery may self-ignite and explode.

- ► Keep contacts dry and clean.
- ▶ Never immerse the battery in water.

Notice

- ▶ Never use a cleaning agent.
- 1 Clean the battery electrical connections with a dry cloth or paintbrush only.
- **2** Wipe off the decorative sides with a damp cloth.

7.3.3 Cleaning the motor







Notice

If water enters the motor, it will be permanently damaged.

- Never open the motor.
- ▶ Never immerse the motor in water.
- ▶ Never use cleaning agents.
- ► Carefully clean the motor on the outside with a soft, damp cloth.

7.3.4 Clean Frame, fork, pannier rack, guards and kickstand



- 1 Soak the components with dish-washing detergent if the dirt is thick and ingrained.
- 2 After leaving it to soak for a short time, remove the dirt and mud with a sponge, brush and toothbrushes.
- **3** Rinse off the components with water from a watering can.
- 4 Wipe away oil stains with a degreaser.

7.3.5 Cleaning the stem



- 1 Clean stem with a cloth and soapy water.
- 2 Rinse off component with water from a watering can.

7.3.6 Cleaning the handlebars



- 1 Clean handlebars, including handles and all gears or twist grips, with a cloth and soapy water.
- 2 Rinse off component with water from a watering can.

7.3.7 Clean handles



- 1 Clean handles with sponge, water and soapy water.
- **2** Rinse off component with water from a watering can.
- **3** Care for rubber handles after cleaning (see Section 7.4.8).

7.3.7.1 Cleaning leather handles



Leather is a natural product and has similar properties to human skin. Regular cleaning and care help to prevent leather dehydrating, fading or becoming brittle or stained.

- 1 Remove dirt with a soft, damp cloth.
- 2 Remove stubborn stains with a leather cleaner.
- **3** Care for leather handles after cleaning (see Section <u>7.4.8.2</u>).

7.3.8 Clean seat post



- 1 Clean seat post with a cloth and soapy water.
- **2** Rinse off component with water from a watering can.
- **3** Wipe away any grease or assembly paste residue with a cloth and degreaser.

7.3.9 Cleaning the saddle









- 1 Clean the saddle with lukewarm water and a cloth dampened with soapy water.
- 2 Rinse off component with water from a watering can.

7.3.9.1 Cleaning the leather saddle



Leather is a natural product and has similar properties to human skin. Regular cleaning and care help to prevent leather dehydrating, fading or becoming brittle or stained.

- 1 Remove dirt with a soft, damp cloth.
- 2 Remove stubborn stains with a leather cleaner.
- **3** Care for leather saddle after cleaning (see Section <u>7.4.11</u>).

7.3.10 Cleaning the tyres









- 1 Clean tyres with a sponge, a brush and soap cleaner.
- 2 Rinse off component with water from a watering can.
- **3** Remove any embedded chips and small stones.

7.3.11 Cleaning the spokes and spoke nipples

- 1 Clean spokes from the inside to the outside with a sponge, brush and soapy water.
- 2 Clean rim with a sponge.
- 3 Rinse off component with water from a watering can.
- **4** Care for spoke nipples after cleaning (see Section <u>7.4.13</u>).

7.3.12 Clean hub













- 1 Put on protective gloves.
- 2 Remove dirt from hub with a sponge and soapy water.
- **3** Rinse off component with water from a watering can.
- 4 Wipe off oily dirt with a degreaser and a cloth.

7.3.13 Cleaning the switching elements









- 1 Clean gear shift and shift cables with water, a brush and dish-washing detergent.
- **2** Rinse off component with water from a watering can.

7.3.13.1 Cleaning the shifter









► Carefully clean shifter with a damp, soft cloth.

7.3.14 Clean cassette, chain wheels and front derailleur













- 1 Put on protective gloves.
- 2 Spray cassette, chain wheels and front derailleur with degreasing agent.
- **3** Clean coarse dirt with a brush after soaking for a short time.
- **4** Wash down all parts with dish-washing detergent and a toothbrush.
- **5** Rinse off component with water from a watering can.

7.3.15 Clean brake

7.3.15.1 Clean handbrake









► Carefully clean the handbrake with a damp, soft cloth.

7.3.16 Cleaning the brake disc







Notice

- Protect brake disc against lubricants and grease from hands.
- 1 Put on protective gloves.
- 2 Spray brake disc with brake disc cleaning spray.
- 3 Wipe with a cloth.

7.3.17 Cleaning the belt















Notice

- ▶ Never use aggressive (acid-based) cleaners, rust removers or degreasers when cleaning the belt.
- 1 Dampen a cloth with soapy water. Place the cloth on the belt.
- 2 Hold and apply slight pressure while slowly turning the rear wheel so that the belt passes through the cloth.

7.3.18 Cleaning the chain















Notice

- ▶ Never use aggressive (acid-based) cleaners, rust removers or degreasers when cleaning the chain.
- ▶ Never use gun oil or rust remover spray.
- ► Never use chain cleaning devices or chain cleaning baths.
- ► Have chain with all-round guard cleaned and cared for during major inspection.
- ✓ Place newspaper or paper towels underneath to collect dirt.
- 1 Slightly dampen a brush with dish-washing liquid. Brush both sides of the chain.
- 2 Dampen a cloth with soapy water. Place the cloth on the chain.
- 3 Hold and apply slight pressure while slowly turning the rear wheel, so the chain passes through the cloth.
- 4 Wipe off oily, dirty chains thoroughly with a cloth and degreaser.
- 5 Care for the chain after cleaning (see Section <u>7.4.16</u>).

7.3.18.1 Clean chain, including all-round chain quard







Notice

The chain guard must be removed before cleaning. Contact specialist dealer.

- ► Clean water hole on the chain guard lower surface.
- ► Care for the chain after cleaning (see Section 7.4.16.1).

7.4 Servicing

Complying with these servicing instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.




Figure 163: Diagram showing wear, operating hours (x) vs. material abrasion (y)

The service life (3) of an optimally serviced drive chain (1) is almost three times as long with lubrication (A) compared to a drive chain (2) lubricated on an irregular basis.

These tools and cleaning agents are required for servicing:

Tool		Cleaning ag	ent
Cloth	Toothbrush	Frame wax spray	Silicone or Teflon oil
		Acid-free lubricating grease	Fork oil
		Teflon spray	Spray oil
		Chain oil	Leather care product

Table 52: Required tools and cleaning agents for servicing




Table 52: Required tools and cleaning agents for servicing

7.4.1 Frame



Notice

- ► Hard wax polish and protection wax are particularly resistant on gloss paintwork. These car accessory retail products are unsuitable for matt paint finishes.
- ► Try wax spray out on a small spot before application.
- 1 Dry frame with a cloth.
- 2 Spray frame with spray wax and leave to dry.
- 3 Wipe away any wax residue with a cloth.

7.4.2 Fork



Notice

- Hard wax polish and protection wax are particularly resistant on gloss paintwork. These car accessory retail products are unsuitable for matt paint finishes.
- ► Try wax spray out on a small spot before application.
- 1 Dry fork with a cloth.
- 2 Spray frame care oil on frame and leave to dry.
- 3 Wipe away any wax residue with a cloth.

7.4.3 Pannier rack



- 1 Dry pannier rack with a cloth.
- 2 Spray pannier rack with spray wax and leave to dry.
- 3 Wipe pannier rack with a cloth.
- 4 Protect chafing points on panniers with adhesive film. Replace worn adhesive film.
- **5** Care for coil springs with silicone spray or wax spray from time to time.

7.4.4 Mudguard



Depending on the requirements for the material in the mudguard, apply hard wax polish, metal polish or a plastic care product as per the product instructions.

7.4.5 Servicing the kickstand



- 1 Dry kickstand with a cloth.
- 2 Spray kickstand rack with spray wax and leave to dry.
- 3 Wipe down kickstand with a cloth.
- 4 Lubricate the kickstand joints with spray oil.

7.4.6 Stem



- 1 Spray painted and polished metal surfaces with wax spray and leave to dry.
- 2 Wipe away any wax residue with a cloth.
- 3 Apply silicone or Teflon oil to the stem shaft tube and the quick release lever pivot point with a cloth.

- 4 If you have a Speedlifter Twist, also apply oil to the unlocking bolt groove in the Speedlifter body.
- 5 Apply a little acid-free lubricant grease between the stem quick release lever and the sliding piece to reduce the quick release lever operating force.
- **6** If you have a stem with a cone clamp, apply a new protective layer of assembly paste onto the stem and fork steerer contact point once a year.

7.4.7 Handlebars



- 1 Spray painted and polished metal surfaces with wax spray and leave to dry.
- 2 Wipe away any wax residue with a cloth.

7.4.8 Handle

7.4.8.1 Rubber handles

1 Apply talcum powder to sticky rubber handles.

Notice

▶ Never apply talcum powder to leather or foam handles.

7.4.8.2 Leather handle



Standard leather care products keep leather smooth and resistant, brighten its appearance and improve or replace stain protection.

- 1 Try leather care product out on a less visible spot before use.
- **2** Care for leather handles with a leather care product.

7.4.9 Seat post

- 1 Carefully preserve screw connections with wax spray. In doing so, ensure that no wax is applied to the metal contact surfaces.
- 2 Replace the assembly paste protective layer on the metal contact surfaces on the seat post and seat tube every year.

7.4.9.1 Suspension seat post







- 1 Lubricate articulated joints with spray oil.
- 2 Deflect and let the suspension seat post rebound five times. Remove any surplus lubricant with a clean cloth.

7.4.9.2 Carbon seat post







Notice

Rain and puddle water can cause contact corrosion if carbon seat posts are used in an aluminium frame without protective assembly paste. It may then take a great deal of force to remove the seat post. The carbon seat post may break as a result.

- 1 Take out the carbon seat post.
- 2 Remove old assembly paste with a cloth.
- 3 Apply new assembly paste with a cloth.
- 4 Re-insert the carbon seat post.

7.4.10 Rim







Care for chrome rims, stainless steel rims and polished aluminium with chrome or metal polish. Never care for the brake surface with polish.

7.4.11 Leather saddle



Standard leather care products keep leather smooth and resistant, brighten its appearance and improve or replace stain protection.

- 1 Try leather care product out on a less visible spot before use.
- 2 Care for leather saddle from below with a leather care product. Only care for the top of leather saddles with a leather care product if they are badly worn and dried-out.
- **3** Avoid wearing light-coloured trousers after care due to staining.

7.4.12 Hub





- Apply wax spray especially around the spoke holes. In doing so, ensure that no wax is applied to brake parts.
- 2 Treat rubber seals with a cloth with one or two drops of silicone spray. Never use oil if you have disc brakes.

7.4.13 Spoke nipples







- 1 Apply wax spray onto the spoke nipples from the rim side.
- 2 Treat heavily corroded spoke nipples with a drop of penetrating of special care oil.

7.4.14 Gear shift

7.4.14.1 Rear derailleur articulated shafts and jockey wheels





► Treat front and rear derailleur articulated shafts and jockey wheels with Teflon spray.

7.4.14.2 Shifter







Notice

- Never treat shifters with degreaser or penetrating oil spray.
- ▶ Lubricate articulated joints and mechanical parts which are accessible from outside with a few drops of spray oil or precision mechanics oil.

7.4.15 Pedal







- 1 Treat pedals with spray oil. In doing so, ensure that no lubricant is applied to the pedal surfaces.
- 2 Lubricate seals and mechanical parts sparingly with a few drops of oil.
- **3** Remove any surplus lubricant with a clean cloth.
- 4 Spray metal foot rests with silicone spray.

7.4.16 Caring for the chain







- ✓ Place newspaper or paper towels underneath to collect chain oil.
- 1 Lift rear wheel.
- 2 Turn the crank briskly in an anti-clockwise direction.
- 3 Use slight finger pressure to the chain oil bottle to apply a wafer-thin thread of oil to the chain links. The faster the crank is turned, the thinner the threads of oil will be.




Figure 164: Lubricating the chain

- 4 Remove excessive chain oil with a cloth. If you apply too much oil, it will make the chain all the dirtier at a later point in time.
- **5** Leave chain oil to penetrate into the chain links for a few hours or overnight.

7.4.16.1 Caring for the chain and all-round chain guard



- ✓ Place newspaper or paper towels underneath to collect chain oil.
- 1 Lift rear wheel.
- 2 Turn the crank briskly in an anti-clockwise direction.
- 3 Use slight finger pressure to the chain oil bottle to apply a wafer-thin thread of oil onto the chain links through the oil hole on the upper surface of the chain guard. The faster the crank is turned, the thinner the threads of oil will be.
- 4 Remove excessive chain oil with a cloth. If you apply too much oil, it will make the chain all the dirtier at a later point in time.
- **5** Leave chain oil to penetrate into the chain links for a few hours or overnight.

7.4.17 Caring for the battery



Grease plug terminals on the battery with terminal grease or contact spray from time to time.

7.4.18 Caring for the brake

7.4.18.1 Caring for handbrake



Notice

- Never treat brake handbrake with degreaser or penetrating oil spray.
- Lubricate articulated joints and mechanical parts which are accessible from outside with a few drops of spray oil or precision mechanics oil.

7.4.19 Lubricating the Eightpins seat post tube

► Use a 2.5 ml syringe to carefully fill Eightpins Fluid V3 very slowly into the lubricating nipple on the outer tube.



Figure 165: Lubricating the eightpins seat post

Notice

► Fill a maximum of 2.5 ml since otherwise the reservoir inside will overflow and the oil will spill into the frame.

7.5 Inspection

The following tools are required for an inspection:

	Gloves
2	Ring spanners 8 mm, 9 mm, 10 mm, 13 mm, 14 mm and 15 mm
	Torque spanner Working range 5–40 Nm
•	by.schulz handlebars: TORX® bits: T50, T55, and T60
0	Hex key 2 mm, 2.5 mm, 3 mm, 4 mm, 5 mm, 6 mm and 8 mm
0	Phillips screwdriver
	Slotted-head screwdriver

Table 53: Tools required for maintenance

7.5.1 Checking the wheel

- 1 Hold pedelec.
- 2 Hold onto the front or rear wheel and try to move the wheel sideways. In doing so, check to see if the wheel nuts or quick releases move.
- ➡ If the wheel moves or the wheel nut or quick release moves sideways, take pedelec out of service. Contact specialist dealer.
- 3 Lift pedelec slightly. Turn front or rear wheel. In doing so, check whether the wheel deflects sideways or outwards.
- ⇒ If the wheel deflects sideways or outwards, take pedelec out of service. Contact specialist dealer.

7.5.1.1 Checking tyre pressure

Notice

If the tyre pressure is too low in the tyre, the tyre does not achieve its load bearing capacity. The tyre is not stable and may come off the rim.

If the tyre pressure is too high, the tyre may burst.

Tyres are wear parts and wear away due to fatigue, storage, environmental influences or mechanical impacts. Only optimum tyre pressure will guarantee greater safety, lower rolling resistance, effective protection against punctures and a longer service life.

Air loss

Even the most airtigfht tube will lose pressure on a continuous basis since the air pressures in a pedelec tyre are significantly higher and the wall thicknesses significantly finer than in a car tyre. Pressure loss of 1 bar per month can be regarded as normal. During this process, the pressure loss is significantly faster at high pressures and significantly slower at low pressures.

Checking tyre pressure

The permitted pressure range is indicated on the side of the tyre.



Figure 166: Tyre pressure in bar (1) and psi (2)

► Verify tyre pressure against the value noted in the pedelec pass every 10 days as a minimum.

Dunlop valve

Only applies to pedelecs with this equipment

The tyre pressure cannot be measured on the simple Dunlop valve. You thus measure the tyre pressure in the filling hose while slowly pumping the bicycle air pump.

- ✓ It is recommendable to use a bicycle air pump with a pressure gauge.
- 1 Unscrew and remove the valve cap.
- 2 Undo the rim nuts.
- 3 Connect the bicycle air pump.
- **4** Pump up the tyre slowly and pay attention to the tyre pressure in the process.
- 5 Correct the tyre pressure to meet the specified value in the Pedelec pass.
- **6** If the tyre pressure is too high, unfasten the union nut, let air out and re-tighten the union nut.
- 7 Remove the bicycle air pump.
- 8 Screw the valve cap tight.
- 9 Screw the rim nut gently against the rim with the tips of your fingers.
- ⇔ Correct tyre pressure if necessary (see section 6.5.7).

Schrader valve

Only applies to pedelecs with this equipment

- ✓ It is recommended to use an air pump at a filling station or a modern bicycle air with a pressure gauge. Older and simple bicycle air pumps are unsuitable for filling tyres via a Schrader valve.
- 1 Unscrew and remove the valve cap.
- 2 Undo the rim nuts.
- 3 Connect the bicycle air pump.
- **4** Pump up the tyre slowly and pay attention to the tyre pressure in the process.
- ⇒ The tyre pressure has been adjusted as per the specifications.

- **5** Remove the bicycle air pump.
- 6 Screw the valve cap tight.
- 7 Screw the rim nut gently against the rim with the tips of your fingers.
- ⇒ Correct tyre pressure if necessary (see section <u>6.5.7</u>).

Presta valve

Only applies to pedelecs with this equipment

- ✓ It is recommendable to use a bicycle air pump with a pressure gauge. You must observe the bicycle air pump operating instructions.
- 1 Unscrew and remove the valve cap.
- 2 Open the knurled nut around four turns.
- **3** Carefully attach the bicycle air pump so that you do not bend the valve insert.
- **4** Pump up the tyre slowly and pay attention to the tyre pressure in the process.
- **5** Correct the tyre pressure as per the specifications on the tyre.
- 6 Remove the bicycle air pump.
- 7 Tighten the knurled nut with your fingers.
- 8 Screw the valve cap tight.
- **9** Screw the knurled nut gently against the rim with the tips of your fingers.
- ⇒ Correct tyre pressure if necessary (see section <u>6.5.7</u>).

7.5.1.2 Checking the tyres

The tread is far less important for bicycle tyres than it is for car tyres, for example. Consequently, tyres can still be used with a worn tread with the exception of tyres on mountain bikes.

1 Check the tread for wear. The tyre is worn if the anti-puncture protection or the carcass cords are visible.

Since resistance to punctures also depends on the thickness of the tread, it may make sense to change the tyre at an earlier stage.





Figure 167: Tyre without tread which can be replaced (1) and tyre with puncture protection showing through (2), which must be replaced

2 Check the side walls for wear. If there are any cracks or tears, the tyre must be replaced.





Figure 168: Examples of fatigue cracks (1) and ageing cracks (2)

⇒ Replacing a wheel requires considerable mechanical expertise. If a tyre is worn, it needs to be replaced at a specialist dealer's.

7.5.1.3 Checking the rims

MARNING

Crash caused by a worn rim

A worn rim can break and block the wheel. This may cause a crash with serious injuries.

- ► Check <u>Wear</u> on rim on a regular basis.
- ► Take pedelec out of service if the rim has any cracks or warping. Contact specialist dealer.

Rims are wear parts and wear away due to fatigue, mechanical impacts, environmental influences or due to braking if rim brakes are used.

- ► Check the rim well for wear.
- ➡ The rims of a rim brake with invisible wear indicator are worn as soon as the wear indicator becomes visible in the area of the rim joint.
- ⇒ The rims with visible wear indicator are worn as soon as the black, all-round groove on the pad friction surface is no longer visible.
- We recommend that you also replace the rims at the same time as every second brake lining replacement.

7.5.1.4 Checking the nipple holes

Nipples cause fatigue and stress on the edge of the nipple hole.

► Check whether there are cracks on the edge of the nipple hole.

If there are cracks on the edge of the nipple hole, contact your specialist dealer.

7.5.1.5 Checking the nipple well

The nipple holes can weaken the tyre bed.

- Check to see if cracks are emerging from the nipple holes.
- ⇒ If there are cracks radiating from the nipple hole, contact your specialist dealer.

7.5.1.6 Checking the rim hooks

Mechanical impacts can warp the rim hooks. There is no longer a guarantee that a tyre can be fitted safely if this is the case.

- ► Check for twisted rim hooks.
- ⇒ Replace rims with twisted rim hooks. Never repair the rim with pliers and bend the hook back.

7.5.1.7 Checking the spokes

- ▶ Press spokes slightly together with your thumb and index finger. Check to ensure that the tension is the same for all spokes.

7.5.2 Checking the brake system

CAUTION

Crash caused by brake failure

Worn brake discs and brake linings and a lack of hydraulic fluid in the brake cable reduce the braking power. This may cause a crash with serious injuries.

Check brake disc, brake linings and the hydraulic brake system regularly. Contact specialist dealer.

The maintenance interval for the brake depends on how often it is used and the weather conditions. If the pedelec is used under extreme conditions such as rain, dirt or high mileage, maintenance must be performed more frequently.

7.5.2.1 Checking the handbrake

- 1 Check that all screws in the handbrake are firmly in place.
- ⇒ Tighten loose screws.
- 2 Check that handbrake is torsionally rigid on the handlebars.
- ⇒ Tighten loose screws.
- 3 Check that there is a gap of at least 1 cm between the handbrake and the handle when the handbrake is fully applied.
- ⇒ Adjust the grip distance if the gap is too narrow (see Section 6.5.9.5, Section 6.5.10.1 or Section 6.5.9.4).
- **4** Check the braking effect by pedalling while pulling the handbrake.
- ⇒ If the braking power is too weak, adjust the brake pressure point (see Section 6.5.9.8).
- ⇔ Contact your specialist dealer if the pressure point cannot be reached.

7.5.2.2 Checking the hydraulic brake system

- 1 Pull on the handbrake and check whether any brake fluid leaks out of the lines, connections or on the brake linings.
- ⇒ If any brake fluid leaks from anywhere, take pedelec out of service. Contact specialist dealer.
- 2 Pull brake handbrake and hold several times.
- ⇒ If you are unable to clearly detect the pressure point and it changes, the brake needs to be bled. Contact specialist dealer.

7.5.2.3 Checking the Bowden cables

- 1 Pull on handbrake several times. Check whether the Bowden cables get stuck or they make scraping noises.
- 2 Check the physical condition of the Bowden cables for visible damage and check to see if wire strands are broken.
- ⇒ Have defective Bowden cables replaced. Contact specialist dealer.

7.5.2.4 Checking the disc brake

Only applies to pedelecs with this equipment

Checking the brake linings

► Check that the brake linings are no less than 1.8 mm wide at any point and there are no less than 2.5 mm between the brake lining and supporting plate.



Figure 169: Checking the brake lining when fitted with the help of the transport safety wear gauge

- 1 Check brake linings for damage and thick dirt.
- ⇒ Have damaged or very dirty brake linings replaced. Contact specialist dealer.
- 2 Pull handbrake and hold.
- 3 In doing so, check whether the transport safety wear gauge can fit between the brake lining supporting plates.
- ➡ If the transport safety wear gauge fits between the supporting plates, the brake linings have not reached their wear limit. Contact your specialist dealer if they are <u>Wear</u>.

Checking the brake discs

- ✓ Put on gloves as the brake disc is very sharp.
- 1 Take hold of brake disc and wiggle it gently to check whether the brake disc is positioned against the wheel free of backlash.
- 2 Check that the brake linings move steadily and symmetrically back towards the brake disc when you pull and release handbrake.
- ⇒ If the brake disc can be moved or the brake linings move erratically, contact your specialist dealer.
- 3 Check that the brake disc is no less than 1.8 mm thick at any point.
- ⇒ If the brake disc is under the wear limit and is less than 1.8 mm thick, the brake disc must be replaced. Contact specialist dealer.

7.5.2.5 Checking the back-pedal brake

Only applies to pedelecs with this equipment

- ✓ There are sharp corners and edges on the backpedal brake. Wear gloves.
- 1 Hold and check counter support to ensure it is firmly attached to rear frame down tube.
- ➡ Tighten screw into the counter support if it is loose.
- 2 Carry out brake test. Listen for noises while doing so.
- ⇒ If braking with the backpedal makes noises, contact specialist dealer.

7.5.2.6 Checking the rim brake

Only applies to pedelecs with this equipment

Checking the brake linings

- We recommend that you also replace the rims at the same time as every second brake lining replacement.
- 1 Check whether the brake linings are worn evenly on both sides of the rim. Check whether the brake linings are worn to one side.
- ⇒ If the brake linings are worn unevenly or worn to one side, contact your specialist dealer.
- 2 Check whether the brake lining wear limit has been reached.
- ⇒ If the brake linings have reached their wear limit, they need to be changed. Contact specialist dealer.
- 3 Check whether the brake linings can be twisted.
- ➡ If the brake linings twist, the brake lining bracket is defective and must be replaced. Contact specialist dealer.
- 4 Check that the brake linings move steadily and symmetrically back towards the rim when you pull and release the handbrake.
- ⇒ If the brake linings move irregularly, contact your specialist dealer.

Checking the rim braking surface for wear

The side wall is more prone to wear in rim brakes. The <u>Wear</u> depends on the stress loads during rides. Dirt between the brake lining and rim and strong braking forces can have an impact on the service life.

The rim must be replaced if the wall is less than 0.9 mm thick. If deep grooves are visible, rim hooks will warp towards the outside or the braking power will change, contact your specialist dealer as soon as possible.

Replacing a rim requires considerable mechanical expertise. Only a specialist dealer should carry out this task.

Adjusting the V-brake

- ► Check that the braking effect initiates after one third of the handbrake distance is reached.
- ⇒ Turn the setting screw on the brake handle to the left and right to adjust the gap between the brake shoes and the rim uniformly to 1-1.5 mm.
- ⇒ If the brake handle has no setting screw or the gap between the brake shoes and the rim can only be set above 1.5 mm, contact your specialist dealer.




Figure 170: Turn setting screw (1) until brakes initiate after $\frac{1}{3}$ of the handbrake distance is reached

7.5.3 Checking the chain

- ► Check chain for rust, damage and chain links that are difficult to move.
- ⇒ Replace rusted, damaged or difficult-to-move chains since they will not withstand the tensile loads from the drive and will soon break. Contact specialist dealer.

7.5.4 Checking the chain tension

Notice

Excessive chain tension increases wear. If the chain tension is too low, there is a risk that the *chain* will slip off the *chain wheels*.

► Check the chain tension once a month.

7.5.4.1 Check tension in derailleur gears

The rear derailleur tensions the chain on pedelecs with derailleur gears.

- 1 Check to see if the chain is sagging.
- 2 Gently press the rear derailleur forwards to check whether it moves and whether it goes back into position by itself.
- ⇒ If the chain is sagging or the rear derailleur does not go back into position by itself, contact your specialist dealer.

7.5.4.2 Check tension in hub gear

Remove the chain guard on pedelecs with a circumferential chain guard.




Figure 171: Checking the chain tension (example): 5 mm upwards, 10 mm downwards = 15 mm deviation

1 Lift chain upwards. Measure the distance to the centre. Press chain downwards. Measure the distance to the centre.

- **2** Add the two values together to calculate the deviation.
- 3 Check the chain tension at three to four points.
- ⇒ If the deviation is greater than 20 mm, tighten chain.
- ⇒ If the deviation is less than 10 mm, Loosen chain.
- ▶ If a hub gear is fitted, the rear wheel must be pushed backwards and forwards to tighten the chain. Contact specialist dealer.
- ▶ In the case of pedelecs with a hub gear or back-pedal brake, the chain is tensioned by an eccentric bearing or movable fork end in the bottom bracket axle. Special tools and specialist knowledge are required to tension the chain. Contact specialist dealer.

7.5.5 Checking the belt for wear

Each chain has a wear limit. If this limited is exceeded, the chain needs to be replaced.

Manufacturer	Wear limits	
SHIMANO	>1%	
KCM	>0.8 mm per link	
SRAM	>0.8%	
ROHLOFF	S: >0.1 mm per link A: >0.075 mm per link	

Table 54: Chain wear limit by manufacturer

7.5.5.1 Rough check

You can perform a rough check on the chain wheel by hand on conventional chains

- 1 Place the chain on the largest chain wheel.
- 2 Lift the chain from the front to the centre of the bike.
- ⇒ If the chain can be lifted more than half a link from the chain wheel, carry out a check or contact your specialist dealer.

7.5.5.2 Check

There is a different wear gauge for each chain, depending on the manufacturer:



Figure 172: Example of a KMC gauge



Figure 173: Example of a SHIMANO gauge



Figure 174: Example of a SRAM gauge



Figure 175: Example of a ROHLOFF gauge



Figure 176: Example of a KMC digital gauge

1 Insert gauge between two chain links on the right-hand side.




Figure 177: Gauge is inserted

2 Lower gauge down to the left-hand side.




Figure 178: Lower gauge to the left

⇒ If the gauge does not fit between the links, the chain is not worn yet.




Figure 179: Gauge does not fit

⇒ If the gauge does not fit between the links, the chain is worn and must be replaced. Contact specialist dealer.




Figure 180: Gauge fits

7.5.6 Checking the belt

7.5.7 Checking the belt for wear

► Check belt for indications of wear:




Figure 181: Indications of wear on a belt

- 1 Carbon tensile fibres are exposed
- 2 Worn webbing with visible polymer
- 3 Missing belt tooth
- 4 Imbalance
- 5 Shark tooth
- 6 Cracks
- ⇒ If there is one or more indications of wear, replace belt. Contact specialist dealer.

7.5.8 Checking the belt sprockets for wear

- ► Check belt sprocket.
- ⇒ The tooth profile is rounded and the teeth are thick. The belt drive sprocket does not need to be replaced.




Figure 182: Optimum tooth profile

⇒ The tooth profile is pointed and teeth have worn thinner. Replace belt sprocket. Contact specialist dealer.




Figure 183: Worn tooth profile




Figure 184: Photo showing example of worn tooth profile

7.5.9 Check belt tension

If the belt tension is too low, this can cause the system to miss out a tooth or slip, i.e. the teeth on the belt slip over the teeth on the rear wheel belt sprocket. Excessive tension can cause damage to the bearings, sluggishness in the system and increased wear on the electric drive system.

The adjustment of the belt tension varies depending on the pedelec. Common tensioning systems include angled or vertical drop-outs, horizontally sliding dropouts and eccentric bottom brackets.

There are three common methods of measuring belt tension:

- Gates Carbon Drive mobile app for iPhone® and Android®,
- · Gates Krikit tension meter and
- · Eco tension tester.

With any of these methods, the tension along the belt may vary slightly, so you should repeat the process several times. Turn the pedal a quarter after each measurement. Measure again.

The tools measure the tension only. They do not provide specifications for the required voltage. The table below contains specifications for the correct tensioning range for Gates Carbon Drive belts.

	Steady pedalling	Sports Use
MTBs* and single- speed bicycles	45– 60 Hz (35– 45 lbs)	60– 75 Hz (45– 53 lbs)
Hub gear/pinion gear	35– 50 Hz (28– 40 lbs)	

Table 55: Specifications for tensioning

* The CDN and SideTrack systems are not permitted for mountain bikes, e-bikes with middrive motor or gears, bikes without a gear shift or for trekking or touring bikes.

These tension specifications are designed as initial guidance and may have to be corrected upwards or downwards depending on the body size, gear ratio and the force applied to the pedals.

7.5.9.1 Gates Carbon Drive mobile app



The Gates Carbon Drive mobile app measures the belt tension based on the belt's natural frequencies (Hz). To do so, the app uses the phone's mic to record the sound of the belt and

determines the main frequency.

- Download Gates Carbon Drive mobile app free of charge from the App Store or Google Play on your mobile phone.
- ✓ Measure in a quiet environment.
- Ensure that the phone microphone is switched on

- 1 Open app.
- 2 Click on the voltage symbol.
- 3 Click on MEASURE.
- 4 Point phone microphone towards the belt.
- 5 Pluck the belt so that the belt vibrates like a guitar string.
- **6** It is recommended to take several measurements for comparison. Turn the crank a quarter. Repeat frequency measurement.
- 7 Check the belt frequency displayed against the specifications for tensions in Table 44.
- ⇒ If the value is higher than the specification, reduce belt tension,
- ⇒ If the value is within the specified range, the belt tension has been correctly adjusted.
- ⇒ If the value is lower than the specification, increase belt tension.

7.5.9.2 Gates Krikit tension meter Not included in price

- ✓ Check that the measurement indicator is at the very bottom.
- 1 Extend index finger into the finger loop. Place on the check gauge.



Figure 185: Index finger in the check gauge

2 Position check gauge on the upper surface of the belt. Position check gauge in the middle of the belt length.



Figure 186: Check gauge on belt

3 Press the check gauge down with just one finger until it clicks into place.




Figure 187: Pressing the check gauge down with one finger

4 Take reading where line A meets line B.




Figure 188: Example of a reading: 20 kg

- 5 Turn the pedal a quarter. Repeat measurement at least three times.
- 6 Convert value read from kg and into pounds and inch per pound.

Example: 20 kg = 44 ln = 44 lbs

- **7** Compare value with Table 44 Tension specification.
- ⇒ If the value is higher than the specification, reduce belt tension,
- ⇒ If the value is within the specified range, the belt tension has been correctly adjusted.
- ⇒ If the value is lower than the specification, increase belt tension.

7.5.9.3 ECO tension tester

Not included in price

1 Attach the measuring stick on the belt.



Figure 189: Attached measuring stick

2 Place the ruler on both belt sprockets.



Figure 190: Ruler in place

⇒ Read tension on the tension indicator.



Figure 191: Example: On yellow along lower edge, so reduce belt tension slightly

Red = increase belt tension

Green = belt tension is set correctly

Yellow = reduce belt tension

7.5.10 Checking the riding light

- 1 Check the cable connections on the headlight and rear light for damage and corrosion and ensure they are firmly in position.
- ⇒ If cable connections are damaged or corroded, or are not firmly in positioned. take pedelec out of service. Contact specialist dealer.
- 2 Switch light on.
- **3** Check that the headlight and rear light come on.
- ⇒ If the headlight or rear lights do not come on, take pedelec out of service. Contact specialist dealer.
- 4 Place pedelec 5 m from the wall.
- 5 Stand the pedelec up straight. Hold the handlebars straight with both hands. Do not use the kickstand.




Figure 192: Light positioned too high (1), correctly (2) and too low (3)

- 6 Check the position of the light beam.
- ⇒ If the light is positioned too high or too low, adjust riding light (see Section <u>6.5.13</u>).

7.5.11 Checking the stem

- ➤ The stem and quick release system must be inspected at regular intervals. The specialist dealer should adjust them if they require adjustment.
- ▶ If the hexagon socket head screw is also loosened, the bearing clearance also needs to be adjusted. Medium-strength thread locker, such as Loctite blue, then needs to be applied to the loosened screws and the screws tightened as per specifications.
- ► Check metal contact surfaces on cone, stem clamping screw and fork steerer for corrosion.
- ⇒ Take pedelec out of service if there is any wear or signs of corrosion. Contact specialist dealer.

7.5.12 Checking the handlebars

- 1 Take hold of handlebars with both hands on the handles.
- 2 Move handlebars up and down and press to tilt.
- ⇒ If the handlebars move, Contact specialist dealer.
- **3** Place front wheel in position where it can't move sideways (e.g. in a bike stand).
- 4 Hold handlebars firmly with both hands.
- 5 Check if the handlebars are able to twist against the front wheel.
- ⇒ If the handlebars can move, contact your specialist dealer.

7.5.13 Checking the saddle

- 1 Hold saddle firmly.
- 2 Check whether the saddle twists, tilts or can be pushed in one direction or other.
- ➡ If the saddle twists, tilts or can be pushed in one direction or other, adjust the saddle (see Section 6.5.4).
- ⇔ Contact your specialist dealer if the saddle cannot be fixed into position.

7.5.14 Checking the seat post

- 1 Take seat post out of the frame.
- 2 Check seat post for cracks and corrosion.
- 3 Reinsert seat post.
- 4 Check pedal.
- 5 Hold pedal and try to move it sideways toward the inside or outside. In doing so, observe whether the crank arm or bearing move sideways.
- ⇒ If the pedal, crank arm or crank bearing moves sideways, fasten screw on the pedal crank rear.
- **6** Hold pedal and try to move it upwards and downwards vertically. In doing so, observe whether the pedal, crank arm or crank bearing moves vertically.
- ⇒ If the pedal, crank arm or crank bearing moves vertically, fasten screw.

7.5.14.1 Checking the derailleur gears

The chain is tensioned by the rear derailleur in pedelecs with derailleur gears.

- 1 Place the pedelec on stand.
- 2 Check to see if the chain is sagging.
- 3 Gently press the rear derailleur forwards to check whether it moves and whether it goes back into position by itself.
- ➡ If the chain is sagging or the rear derailleur does not go back into position by itself, contact your specialist dealer.

7.5.14.2 Checking the hub gear

In the case of pedelecs with a hub gear or backpedal brake, the chain or the belt is tensioned by an eccentric bearing or movable fork end in the bottom bracket axle. Special tools and specialist knowledge are required to tension the chain. Contact specialist dealer.

- Remove the chain guard on pedelecs with a circumferential chain guard.
- 1 Place the pedelec on stand.
- 2 Check the chain or belt tension in three or four positions, turning the crank a full revolution.




Figure 193: Checking the chain tension

- ➡ If the chain or the belt can be pushed more than 2 cm, the chain will need to be re-tensioned. Contact specialist dealer.
- ⇒ If the chain or belt can only be pushed up and down less than 1 cm, you will need to the chain or belt slightly. Contact specialist dealer.
- ➡ The ideal chain and belt tension has been achieved if the chain can be pushed between a maximum of 10 and 15 mm in the middle between the pinion and the toothed wheel. The crank must also turn without resistance.

7.5.15 Check gear shift

- Check that all gear shift components are free of damage.
- **2** Contact your specialist dealer if components are damaged.
- 3 Place the pedelec on stand.
- 4 Turn the pedal crank clockwise.
- 5 Switch through all speeds.
- **6** Check that pedelec can switch through all speeds without making unusual noises.
- 7 Adjust the gear shift if gears cannot be changed correctly.

7.5.15.1 Electric gear shift

- 1 Check the cable connections for damage and corrosion and ensure they are firmly in position.
- ⇒ If cable connections are loose, damaged or corroded, contact your specialist dealer.

7.5.15.2 Mechanical gear shift

- 1 Change gear a number of times. Check whether the Bowden cables get stuck or they make scraping noises.
- 2 Check the physical condition of the Bowden cables for visible damage and check to see if wire strands are broken.
- ⇒ Have defective Bowden cables replaced.
 Contact specialist dealer.

7.5.15.3 Checking the derailleur gears

- 1 Check that there is clearance between the chain tensioner and spokes.
- ➡ If there is no clearance or the chain scrapes against the spokes or tyres, contact your specialist dealer.
- 2 Check that there is clearance between the chain or rear derailleur and spokes.
- ⇒ If there is no clearance or the chain scrapes against the spokes, contact your specialist dealer.

7.5.16 Adjusting gear shift

7.5.16.1 Adjusting the ROHLOFF hub

Only applies to pedelecs with this equipment

- 1 Check whether shift cable tension is set in such a way that there is a perceptible play of around 5 mm when the shift handle is turned.
- **2** Adjust the shift cable tension by turning the tension adjuster.
- ⇒ Unscrew the tension adjuster to increase the shift cable tension.
- ➡ Tighten the tension adjuster to decrease the shift cable tension.




Figure 194: The tension adjuster on ROHLOFF hub versions with internal switch control is located on the tension counter support



Figure 195: The tension adjuster on ROHLOFF hub versions with external switch control is located on the cable box positioned on the left-hand side

3 If the marking and numbers on the shift handle to no longer coincide after the gear shift is adjusted, tighten one of the tension adjusters and screw out the other tension adjuster to the same extent.

7.5.17 Adjusting cable-operated gear shift, dual-cable

Only applies to pedelecs with this equipment

- ► For a smooth gear shift, set the adjusting sleeves underneath the chain stay on the frame.
- ► The shift cable has around 1 mm play when it is pulled out gently.




Figure 196: Adjusting sleeves (2) on two alternative versions (A and B) of a dual-cable, Bowden-cable-operated gear shift on the chain stay (1)

7.5.18 Adjusting Bowden-cable-operated twist grip, dual-cable

Only applies to pedelecs with this equipment

- ► For a smooth gear shift, set the adjusting sleeves on the shifter housing.
- ⇒ There is noticeable play of 2 to 5 mm (1/2 gear) when you turn the twist grip.




Figure 197: Twist grip with adjusting sleeves (1) and play in the gear shift (2) $\frac{1}{2}$

7.5.19 Checking kickstand stability

- 1 Place the pedelec on a slight elevation of 5 cm.
- 2 Extend kickstand.
- 3 Jolt pedelec to check stability.
- ➡ If pedelec topples over, tighten screws or change height of the kickstand.

8 Inspection and maintenance

8.1 Initial inspection

After 200 km or 4 weeks after purchase

Vibrations produced while riding can cause screws and springs that were tightened during pedelec manufacture to settle or come loose.

- Arrange an appointment for the initial inspection directly when purchasing the pedelec.
- ► Have the initial inspection entered and stamped in the maintenance book.



 Carrying out the initial inspection, see Section 8.4.

8.2 Major inspection

every six months

You must have your specialist dealer perform a major inspection every six months as a minimum. This is the only way to ensure that the pedelec remains safe and fully functional.

Tasks require technical expertise, special tools and special lubricants. The pedelec may become damaged if the stipulated major inspection and procedures are not carried out. This is why only specialist dealers may carry out the major inspection.

- ► Contact your specialist dealer and arrange an appointment.
- ► Enter and stamp major inspection tasks in the maintenance book.



Perform major inspection

8.3 Component-specific maintenance

High-quality components require extra maintenance. Tasks require technical expertise, special tools and special lubricants. The pedelec may become damaged if the stipulated maintenance intervals and procedures are not carried out. This is why only specialist dealers may carry out maintenance.

Correct maintenance on the fork not only guarantees a long service life, but also ensures optimal performance.

Each maintenance interval shows the maximum cycling hours for the required type of maintenance that the component manufacturer recommends.

- ➤ Optimise performance with shorter maintenance intervals, depending on use, terrain and environmental conditions.
- ► Enter any components with extra maintenance requirements with their corresponding maintenance intervals into the maintenance book when the pedelec is purchased.
- ► Inform the buyer of the additional maintenance schedule.
- ► Enter and stamp maintenance tasks in the maintenance book.

Insp	Inspection and maintenance intervals for suspension for							
SR	SR SUNTOUR suspension fork							
	Maintenance 1	Every 50 hours						
	Maintenance 2	Every 100 hours						
FOX	(suspension fork							
	Maintenance	Every 125 hours or once a year						
Roc	kShox suspension fork							
0	Maintenance of stanchions for: Paragon™, XC™ 28, XC 30, 30™, Judy®, Recon™, Sektor™, 35™*, Bluto™, REBA®, SID®, RS-1™, Revelation™, PIKE®, Lyrik™, Yari™, BoXXer	Every 50 hours						
0	Maintenance of spring and damper unit for: Paragon, XC 28, XC 30,30 (2015 and earlier), Recon (2015 and earlier), Sektor (2015 and earlier), Bluto (2016 and earlier), Revelation (2017 and earlier), REBA (2016 and earlier), SID (2016 and earlier), RS-1 (2017 and earlier), BoXXer (2018 and earlier)	Every 100 hours						
_	Maintenance of spring and damper unit for: 30 (2016+), Judy (2018+), Recon (2016+), Sektor (2016+), 35 (2020+)*, Revelation (2018+), Bluto (2017+), REBA (2017+), SID (2017+), RS-1 (2018+), PIKE (2014+), Lyrik (2016+), Yari (2016+), BoXXer (2019+)	Every 200 hours						

Insp	ection and maintenance intervals for	seat post
by.s	chulz suspension seat post	
_	Maintenance	After the first 250 km; every 1,500 km after that
SR S	SUNTOUR suspension seat post	
	Maintenance	Every 100 hours or once a year
eigh	tpins suspension seat post	
	Clean wiper	20 hours
	Clean slide bushing	40 hours
	Replace slide bushing, wiper and felt strip	100 hours
	Seal service for gas pressure spring	200 hours
Roc	kShox dropper post	
_	Venting of remote control lever and/or maintenance of lower seat post unit for: Reverb™ A1/A2/B1, Reverb Stealth A1/ A2/B1/C1*	Every 50 hours
_	Detach lower seat post, clean brass pins, check and replace if necessary and apply new grease for Reverb AXS™ A1*	Every 50 hours
_	Venting of remote control lever and/or maintenance of lower seat post unit for: Reverb B1, Reverb Stealth B1/C1*, Reverb AXS™ A1*	Every 200 hours
	Complete maintenance of seat post for: Reverb A1/A2, Reverb Stealth A1/A2	Every 200 hours
	Complete maintenance of seat post for: Reverb B1, Reverb Stealth B1	Every 400 hours
	Complete maintenance of seat post for: Reverb AXS™ A1*, Reverb Stealth C1*	Every 600 hours
FOX	suspension seat post	
	Maintenance	Every 125 hours or once a year
All	other suspension seat posts	
	Maintenance	Every 100 hours

Inspection and maintenance intervals for rear frame damper								
Roc	kShox rear frame damper							
	Service air chamber assembly	Every 50 hours						
	Service damper and spring Every 200 hours							
FOX	rear frame damper							
	Maintenance	Every 125 hours or once a year						
SR S	SR SUNTOUR rear frame damper							
	Complete shock absorber service including damper reassembly and air seal replacement							

Insp	Inspection and maintenance intervals for hub							
SHII	SHIMANO 11-speed hub							
_	Internal oil change and maintenance	1,000 km after start of use, then every 2 years or 2,000 km						
All	other SHIMANO gear hubs							
	Lubricate internal components	Once a year or every 2,000 km						
ROH	ILOFF Speedhub 500/14							
	Clean cable box and grease cable drum interior	Every 500 km						
_	Oil change	Every 5,000 km or at least once a year						
Pini	on							
_	Maintenance 1 Check drive elements and replace if necessary Clean cable pulley, slide surfaces and gear box interior, epicyclic wheels, etc. thoroughly and grease generously	Every 500 km						
	Maintenance 2 Replace chain rings and change oil	Every 10,000 km						

! WARNING

Injury due to damaged brakes

Special tools and specialist knowledge are required to repair the brakes. Incorrect or unauthorised assembly can damage the brakes. This may lead to an accident with serious injuries.

- Only specialist dealers may carry out repairs on brakes.
- ▶ Only carry out work or changes, such as dismantling, sanding or painting, which are permitted and described in the brake operating instructions.

Injury to the eyes

Problems may arise if the settings are not made properly and you may sustain serious injuries as a result.

► Always wear safety glasses during Inspection and maintenance work.

! CAUTION

Crash and falling caused by unintentional activation

There is a risk of injury if the electric drive system is activated unintentionally.

Remove the battery before inspection or maintenance.

Crash caused by material fatigue

If the service life of a component has expired, the component may suddenly fail. This may cause a crash with injuries.

► Have the specialist dealer carry out basic cleaning of the pedelec every six months, preferably at the same time as the required servicing work.

/! CAUTION

Hazard for the environment due to toxic substances

The brake system contains toxic and environmentally harmful oils and lubricants. Such fluids will contaminate if they enter the sewers or groundwater.

▶ Dispose of lubricants and oils left over after repairs in an environmentally responsible way in accordance with statutory regulations.

Notice

The motor is maintenance-free and only qualified specialist personnel may open it.

► Never open the motor.

8.4 Carry out initial inspection

Incorrectly fastened screws may come loose due to impact. The stem may no longer be firmly fixed in its position as a result. This will cause a crash with injuries.

Check the handlebars and the stem quick release system are firmly in position after the first two hours of riding.

Vibrations produced while riding can cause screws and springs that were tightened during manufacture of the pedelec to settle or come loose.

- 1 Check quick release system is fixed in position.
- 2 Check all tightening torques of screws and screw connections.



8.5 Inspection and maintenance instructions

Complying with these inspection and maintenance instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

Diagnosis and documentation of current status

Components	Frequency	Description			Criteria		Measures if rejected					
		Inspection	Tests	Inspection/ maintenance	Accept- ance	Rejection						
	Chassis											
	Once a month	Dirt		Section 7.3.4	O.K.	Dirt	Cleaning					
	6 months	Servicing		Section 7.4.1	O.K.	Untreated	Wax					
Frame	6 months	Check for damage – fracture, scratches	Section 8.6.1		O.K.	Damage detected	Take pedelec out of service, new frame as specified in parts list					
	Once a month	Dirt	Section 7.3.4		O.K.	Dirt	Cleaning					
	6 months	Servicing		Section <u>7.4.1</u>	O.K.	No wax	Wax					
Carbon frame (optional)	6 months	Damage to paint- work	Section 8.6.1.1		O.K.	Damage to paintwork	Apply paint					
	6 months	Damage from impact	Section 8.6.1.1		O.K.	Damage from impact	Take pedelec out of service, new frame as specified in parts list					
ROCKSHOX Rear frame damper (optional)	6 months	Check for damage, corrosion, fracture	See ROCK- SHOX compo- nent maintenance instructions	Maintenance as specified by manufacturer Air chamber assembly group, damper and spring.	O.K.	Damage detected	New rear frame damper as specified in parts list					
FOX Rear frame damper (optional)	6 months	Check for damage, corrosion, fracture		Send to FOX	O.K.	Damage detected	New rear frame damper as specified in parts list					
SR SUNTOUR Rear frame damper (optional)	6 months	Check for damage, corrosion, fracture	See SR SUNTOUR component maintenance instructions	Maintenance as specified by manufacturer Complete shock absorber ser- vice including damper reas- sembly and air	O.K.	Damage detected	New rear frame damper as specified in parts list					
			Steering sy	/stem								
	Once a month	Cleaning		Section 7.3.6	O.K.	Dirt	Cleaning					
	6 months	Wax		Section 7.4.7	O.K.	Untreated	Wax					
Handlebars	6 months	Check mount fastening	Section <u>7.5.12</u>		O.K.	Loose, rust	Retighten screws; new handlebars as specified in parts list if necessary					
	Once a month	Cleaning		Section 7.3.5	O.K.	Dirt	Cleaning					
	6 months	Wax		Section 7.4.6	O.K.	Untreated	Wax					
Stem	6 months	Check mount fas- tening	Section 7.5.11 and Section 8.6.4		O.K.	Loose, rust	Retighten screws; new stem as specified in parts list if necessary					



Components	Frequency		Description		C	riteria	Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
	Once a month	Cleaning		Section <u>7.3.7</u>	O.K.	Dirt	Cleaning
	Once a month	Care	Section <u>7.4.8</u>		O.K.	Untreated	Talcum powder
Handles	before each ride	Wear; check if fas- tened securely	Section <u>7.1.11</u>		O.K.	Missing, wob- bles	Retighten screws, new handles and coverings as speci- fied in parts list
Steering headset	6 months	Clean and check for damage		Clean, lubri- cate and adjust	O.K.	Unclean	Clean and lubricate
Fork (rigid)	6 months	Check for damage, corrosion, fracture		Dismount, check, lubri- cate, refit	O.K.	Damage detected	New fork as speci- fied in the parts list
Carbon fork (optional)	6 months	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer Lubrication, oil	O.K.	Damage detected	New fork as speci- fied in the parts list
(орионат)				change as specified by manufacturer			
SR SUNTOUR suspension fork	6 months	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer Lubrication, oil	O.K.	Damage detected	New fork as speci- fied in the parts list
(optional)				change as specified by manufacturer			
FOX suspension fork (optional)	6 months	Check for damage, corrosion, fracture		Send to FOX	O.K.	Damage detected	New rear frame damper as specified in parts list
RockShox suspension fork	6 months	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer Lubrication, oil	O.K.	Damage detected	New fork as speci- fied in the parts list
(optional)				change as specified by manufacturer			
Spinner _	6 months	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer	O.K.	Damage detected	New fork as speci- fied in the parts list
suspension fork (optional)				Lubrication, oil change as specified by manufacturer			
			Whee	l e			
Wheel	before each ride	Concentricity	Section 7.1.7		O.K.	Not straight	Re-mount wheel
	6 months	Assembly	Section <u>7.5.1</u>		O.K.	Loose	Adjust quick release
	Once a month	Cleaning	Section <u>7.3.10</u>		O.K.	Dirt	Cleaning
Tyres	once a week	Tyre pressure	Section <u>7.5.1.1</u>		O.K.	Tyre pres- sure too low/ too high	Adjust tyre pressure
	10 days	Wear	Section <u>7.3.10</u>		O.K.	Worn profile	New tyre as speci- fied in the parts list



Components	Frequency		Description		С	riteria	Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
	6 months	Wax		Section <u>7.4.10</u>	O.K.	Untreated	Wax
Rims	6 months	Wear	Section <u>7.5.1.3</u>		O.K.	Defective rim	New rim as speci- fied in the parts list
	Once a month	Wear on brake surface	Section <u>7.5.2.6</u>		O.K.	Worn brake surface	New rim as speci- fied in the parts list
	Once a month	Cleaning		Section <u>7.3.11</u>	O.K.	Dirt	Cleaning
Spokes	3 months	Check tension	Section <u>7.5.1.3</u>		O.K.	Loose, ten- sion varies	Re-tension spokes or new spokes as specified in parts list
	6 months	Check rim hooks	Section <u>7.5.1.3</u>		O.K.	Twisted rim hooks	New rim as speci- fied in the parts list
Spoke nipples	Once a month	Cleaning		Section <u>7.3.11</u>	O.K.	Dirt	Cleaning
Spoke Hippies	Once a month	Wax		Section <u>7.4.13</u>	O.K.	Untreated	Wax
Nipple holes	6 months	Check for cracks	Section <u>7.5.1.4</u>		O.K.	Cracks	New rim as speci- fied in the parts list
Nipple well	Once a year	Check for cracks	Section <u>7.5.1.5</u>		O.K.	Cracks	New rim as speci- fied in the parts list
Hub	Once a month	Cleaning		Section <u>7.3.12</u>	O.K.	Dirt	Cleaning
Tido	Once a month	Care		Section <u>7.4.12</u>	O.K.	Untreated	Treat
	Once a month	Cleaning		Section <u>7.3.12</u>	O.K.	Dirt	Cleaning
11 15 20 50 50 50	Once a month	Care		Section <u>7.4.12</u>	O.K.	Untreated	Treat
Hub with cone bearing (optional)	6 months	Check mount fastening			O.K.	Loose, rust	Retighten screws; new handlebars as specified in parts list if necessary
	Once a year	Adjust			O.K.	Not adjusted	New position
	Once a month	Cleaning		Section <u>7.3.12</u>	O.K.	Dirt	Cleaning
	Once a month	Care		Section <u>7.4.12</u>	O.K.	Untreated	Treat
Hub gear (optional)	6 months	Check mount fastening			O.K.	Loose, rust	Retighten screws; new handlebars as specified in parts list if necessary
	6 months	Functional check	Section <u>7.5.14.</u> <u>2</u>			incorrect switching	Readjust hub
		5	Saddle and s	eat post			
	Once a month	Cleaning		Section 7.3.9	O.K.	Dirt	Cleaning
Saddle	6 months	Check mount fastening	Section <u>7.5.13</u>		O.K.	Loose	Retighten screws
Leather	Once a month	Cleaning		Section <u>7.3.9.</u> <u>1</u>	O.K.	Dirt	Cleaning
saddle	6 months	Care		Section <u>7.4.11</u>	O.K.	Untreated	Leather wax
(optional)	6 months	Check mount fastening	Section <u>7.5.13</u>		O.K.	Loose	Retighten screws
	Once a month	Cleaning		Section 7.3.8	O.K.	Dirt	Cleaning
Soot most	6 months	Care			O.K.	Untreated	Leather wax
Seat post	6 months	Complete clean, check fastening and paint protection film		Section 8.6.8	O.K.	Loose	Tighten screws, new paint protection film



Components	Frequency		Description		C	riteria	Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
	Once a month	Cleaning		Section 7.3.8	O.K.	Dirt	Cleaning
Carbon seat	6 months	Care		Section <u>7.4.9.</u> <u>2</u>	O.K.	Untreated	Assembly paste
post (optional)	6 months	Complete clean, check fastening and paint protection film		Section 8.6.8.	O.K.	Loose	Tighten screws, new paint protection film; new seat post as specified in parts list if damaged
	Once a month	Cleaning			O.K.	Dirt	Cleaning
Suspension seat post	6 months	Care		Section <u>7.4.9.</u> <u>1</u>	O.K.	Untreated	Oils
(optional)	100 hours or 6 months	Complete clean, check fastening and paint protection film	Section 8.6.8		O.K.	Loose	Tighten screws, new paint protection film
by.schulz suspension seat post (optional)	After the first 250 km; every 1500 km after that	Complete clean, check fastening and paint protection film, lubricate	Section 8.6.8.2		O.K.	Loose	Tighten screws, new paint protection film; new seat post as specified in parts list if damaged
SR SUNTOUR suspension seat post	Every 100 hours or Once a year	Complete clean, check fastening and paint protection film, lubricate	Section 8.6.8.3		O.K.	Loose	Tighten screws, new paint protection film; new seat post as specified in parts list if damaged
	20 Hours	Refill oil		Section <u>7.4.19</u>	O.K.	No oil	Refill oil
	20 Hours	Clean wiper			O.K.	Dirt	Cleaning
eightpins NGS2	40 Hours	Clean slide bushing			O.K.	Dirt	Cleaning
Suspension seat post	100 Hours	Replace slide bushing, wiper and felt strip			O.K.	No replace- ment	Replace
	200 Hours	Seal service for gas pressure spring			O.K.	No service	Carry out the service
	20 Hours	Refill oil		Section <u>7.4.19</u>	O.K.	No oil	Refill oil
	20 Hours	Clean wiper			O.K.	Dirt	Cleaning
eightpins H01	40 Hours	Clean slide bushing			O.K.	Dirt	Cleaning
Suspension seat post	100 Hours	Replace slide bushing, wiper and felt strip			O.K.	No replace- ment	Replace
	200 Hours	Seal service for gas pressure spring			O.K.	No service	Carry out the service



Components	Frequency		Description		C	riteria	Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
	50 Hours	Venting		See manufac- turer	O.K.		
	50 Hours	Cleaning		See manufac- turer	O.K.		
RockShox	200 Hours	Venting		See manufac- turer	O.K.		
dropper post	200 Hours	Complete mainte- nance		See manufac- turer	O.K.		
	400 Hours	Complete mainte- nance		See manufac- turer	O.K.		
	600 Hours	Complete mainte- nance		See manufac- turer	O.K.		
FOX suspension seat post	125 hours or Once a year	Complete mainte- nance	See manufac- turer	At the manu- facturer FOX			
			Safety gu	ards			
Belt or chain guards	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
Guard	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
Motor cover	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
			Brake sys	stem			
Handbrake	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
Brake fluid	6 months	Check fluid level	Depending on time of year		O.K.	Too little	Top up brake fluid; take Pedelec out of service if dam- aged; new brake hoses
Brake linings	6 months	Brake linings, brake discs and rims	Check for damage		O.K.	Damage detected	New brake linings, brake discs and rims
Back-pedal brake braking armature	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
Brake system	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws
			Lighting sy	/stem			
Light cabling	6 months	Connections, correct wiring	Check		O.K.	Cable defective, no light	New cabling
Rear light	6 months	Side light	Functional check		O.K.	No constant light	New rear light as specified in parts list; replace if nec- essary
Front light	6 months	Side light, daytime riding light	Functional check		O.K.	No constant light	New front light as specified in parts list; replace if nec- essary
Reflectors	6 months	All complete, state, fastening	Check		O.K.	Damaged or not all complete	New reflectors



Components	Frequency		Description		С	riteria	Measures if rejected			
		Inspection	Tests	Maintenance	Accept- ance	Rejection				
Drive/gear shift										
Chain/ cassette/ pinion/ chainring	6 months	Check for damage	Check for damage		O.K.	Damage	Refasten if neces- sary or replace as specified in parts list			
Chain guard/ spoke guard	6 months	Check for damage	Check for damage		O.K.	Damage	Replace as speci- fied in parts list			
Bottom bracket axle/ crank	6 months	Check mount fastening	Check mount fastening		O.K.	Loose	Retighten screws			
Pedals	6 months	Check mount fastening	Check mount fastening		O.K.	Loose	Retighten screws			
Shifter	6 months	Check mount fastening	Check mount fastening		O.K.	Loose	Retighten screws			
Shift cables	6 months	Check for damage	Check for damage		O.K.	Loose and defective	Adjust shift cables; new shift cables if necessary			
Front derailleur	6 months	Check for damage	Check for damage		O.K.	Gear shift difficult or not possible	Adjust			
Rear derailleur	6 months	Check for damage	Check for damage		O.K.	Gear shift difficult or not possible	Adjust			
			Electric drive	system						
On-board computer	6 months	Check for damage	Check for damage		O.K.	No screen, defective screen display	Restart, test battery, new software or new on-board com- puter, decommis- sioning,			
Control panel	6 months	Check control panel for damage	Check for damage		O.K.	No response	Restart; contact control panel manu- facturer, new con- trol panel			
Tachometer	6 months	Calibration	Speed meas- urement		O.K.	Pedelec travelling 10% too fast/ slow	Take pedelec out of service until the source of the error is found			
Cabling	6 months	Visual inspection	Visual inspection		O.K.	Failure in system, damage, kinked cables	New cabling			
Recharge- able battery	6 months	First examination	See Section on Assembly		O.K.	Error message	Contact battery manufacturer; take out of service, new battery			
Battery mount	6 months	Firmly in position, lock, contacts	Check mount fastening		O.K.	Loose; lock doesn't close, no contacts	New battery mount			
Motor	6 months	Visual inspection and mount	Check mount fastening		O.K.	Damage, loose	Refasten motor, contact motor man- ufacturer, new motor; take out of service			
Software	6 months	Check version	Check soft- ware version		In latest version	Not latest version	Import update			



Components	Frequency	Description			Criteria		Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
			Miscellane	eous			
	before each ride	Stability	Section <u>7.1.5</u>		O.K.	Loose	Firm
	Once a month	Dirt		Section <u>7.3.4</u>	O.K.	Dirt	Cleaning
Pannier rack	6 months	Servicing		Section 7.4.3	O.K.	Untreated	Wax
	6 months	Check fastening and paint protection film	Section 8.5.2		O.K.	Loose	Tighten screws, new paint protection film
	Once a month	Dirt		Section <u>7.3.4</u>	O.K.	Dirt	Cleaning
	6 months	Servicing		Section 7.4.5	O.K.	Untreated	Wax
Kickstand	6 months	Attachment	Section <u>7.5.19</u>		O.K.	Loose	Retighten screws
	6 months	Stability	Section <u>7.5.19</u>		O.K.	Tips over	Change kickstand height
Bell	before each ride	Sound	Functional check, Section 7.1.10.		O.K.	No ring, too quiet, missing	New bell as speci- fied in the parts list
Attachments (optional)	6 months	Attachment	Check mount fastening		O.K.	Loose	Retighten screws

Technical inspection, checking safety, test ride

Components	Description		Criteria		Measures if rejected
	Assembly/inspection	Tests	Acceptance	Rejection	
Brake system	6 months	Functional check	O.K.	No full braking; braking distance too long	Locate defective part in brake system and correct
Gear shift under operating load	6 months	Functional check	O.K.	Problems when shifting gear	Readjust gear shift
Suspension components (fork, shock absorber, seat post)	6 months	Functional check	O.K.	Suspension too deep or no longer exists	Locate defective component and correct
Electric drive system	6 months	Functional check	O.K.	Loose connection, problems when riding, accelerate	Locate faulty component in electric drive system and remedy
Lighting system	6 months	Functional check	O.K.	No continuous light, not bright enough	Locate defective part in lighting system and correct
Test ride	6 months	Functional check	No strange noises	Strange noises	Locate source of noise and correct



8.5.1 Inspecting the frame

- 1 Check frame for cracks, warping and damage to the paintwork.
- ➡ If there are any cracks, warping or damage to the paintwork, remove the pedelec from service. New frame as specified in the parts list.

8.5.1.1 Inspect the carbon frame

You need to distinguish between scratches on the paintwork and impacts if the carbon frame paintwork is damaged.

- ▶ Ask customer what caused the damage.
- ► Examine damage with a magnifying glass to see if fibres are permanently damaged or delamination has taken place.

8.5.2 Inspecting the pannier rack

Scratches, cracks and breaks may appear on the pannier rack caused by the panniers and cargo boxes.

- 1 Examine pannier rack for scratches, cracks and breaks.
- ⇒ Replace damaged pannier racks.
- ⇒ If the paint protection film is missing or has worn away, affix a new paint protection film.

8.5.3 Inspect and maintain rear frame damper

Only applies to pedelecs with this equipment

! WARNING

Injury due to explosion

The air chamber is pressurised. If the air system is serviced in a rear frame damper, it can explode and cause serious injury.

- Wear safety goggles, protective gloves and safety clothing when assembling or carrying out maintenance on the bicycle.
- Release the air for the air chambers. Detach all air insert fitments.
- Never service or dismantle a rear frame damper if it has not completely rebounded.

Intoxication from suspension oil

Suspension oil is poisonous to the touch, irritates respiratory tracts and causes cancer, sterility and mutation in germ cells.

- Always wear safety goggles and nitrile gloves when carrying suspension oil.
- Never perform inspection or maintenance when you are pregnant.
- Use an oil catchment tray under the section where the rear frame damper is being serviced.

Intoxication from lubrication oil

The lubrication oil for Eightpins seat posts is toxic if touched or inhaled.

- ► Always wear safety goggles and nitrile gloves when working with lubrication oil.
- Lubricate seat post in the open air or in a wellventilated room only.
- Avoid skin coming into contact with lubrication oil. Wear nitrile gloves when lubricating, cleaning and servicing the vehicle.
- Use an oil catchment tray under the section where the seat post is serviced.



/! CAUTION

Hazard for the environment due to toxic substances

The rear frame damper contains toxic and environmentally harmful oils and lubricants. Such fluids will contaminate if they enter the sewers or groundwater.

- Dispose of lubricants and oils left over after repairs in an environmentally responsible way in accordance with statutory regulations.
- 1 Dismantle the rear frame damper.
- 2 Clean and inspect its interior and exterior.
- 3 Recondition air springs.
- 4 Replace airtight seals on air springs.
- 5 Change oil.
- ⇒ Replace dust wipers.

8.5.4 Inspect gear hub

8.5.4.1 Adjusting the hub with cone bearing

In the case of hubs with a cone bearing, the bearing shell fixed in the hub cone body rotates with its larger ball bearing surfaces around the inner bearing cone resting against the fork end. The outer bearing shell rotating around the stationary bearing cone is subject to considerably more evenly distributed loads thanks to its larger ball running surface.

- 1 Attach a small, red colour marking on the lock
- 2 Turn the wheel axle 40° to 90° every 1,000 to 2,000 km.
- ⇒ The bearing cone is subject to evenly distributed loads.

8.5.5 Inspecting the stem

Incorrectly fastened screws may come loose due to impact. The stem may no longer be firmly fixed in its position as a result. This will cause a crash with injuries.

► Check the handlebars and the stem's quick release are firmly in position.

8.5.6 Inspect and grease steering headset

- 1 Remove fork.
- 2 Clean steering headset. If it is very dirty, flush the bearing with cleaning agents such as WD-40 or Karamba.
- 3 Check steering headset for damage.
- ⇒ If the steering headset is damaged, replace steering headset as specified in the parts list.
- 4 Grease steering headset and bearing seat with highly viscous, water-repellent grease (e.g. Dura Ace special grease by SHIMANO).
- **5** Re-fit fork with steering headset as per fork instructions.



8.5.7 Inspecting axle with quick release

CAUTION

Crash caused by unfastened quick release

A faulty or incorrectly installed quick release may become caught in the brake disc and block the wheel. This will cause a crash.

Install the front wheel quick release lever on the opposite side to the brake disc.

Crash caused by faulty or incorrectly installed quick release

The brake disc becomes very hot during operation. Parts of the quick release may become damaged as a result. The quick release comes loose. This will cause a crash with injuries.

➤ The front wheel quick release lever and the brake disc must be situated on opposite sides.

Crash caused by incorrectly set clamping force

Excessively high clamping force will damage the quick release and cause it to lose its function.

Insufficient clamping force will cause a detrimental transmission of force. The suspension fork or the frame may break. This will cause a crash with serious injuries.

- Never fasten a quick release using a tool (e.g. hammer or pliers).
- Only use the clamping lever with the specified set clamping force.
- 1 Undo quick release.
- 2 Fasten quick release.
- **3** Check the position and clamping force of the quick release lever.

- ⇒ The quick release lever is flush with the lower housing.
- ⇒ You should be able to see slight impression on the palm of your hand when you close the quick release lever.



Figure 198: Adjusting the quick release clamping force

- **4** Use a 4 mm hexagon socket spanner to adjust the clamping lever clamping force if required.
- **5** Check the quick release lever position and clamping force again.




Figure 199: Adjusting the quick release clamping force



8.5.8 Inspecting the fork

WARNING

Injury due to explosion

The air chamber is pressurised. When the air system in a faulty suspension fork is maintained, it may explode and cause serious injury.

- Wear safety goggles, protective gloves and safety clothing when assembling or carrying out maintenance on the bicycle.
- Release the air for the air chambers. Detach all air insert fitments.
- Never service or dismantle a suspension fork if it has not completely rebounded.

CAUTION

Hazard for the environment due to toxic substances

The suspension fork contains toxic and environmentally harmful oils and lubricants. Such fluids will contaminate if they enter the sewers or groundwater.

- Dispose of lubricants and oils left over after repairs in an environmentally responsible way in accordance with statutory regulations.
- 1 Remove fork.
- 2 Check fork for cracks, warping and damage to the paintwork.
- ➡ If there are any cracks, warping or damage to the paintwork, remove the pedelec from service. New fork as specified in the parts list.
- 3 Clean inside and exterior.
- 4 Grease fork.
- 5 Install fork.

8.5.8.1 Inspect the carbon suspension fork

Only applies to pedelecs with this equipment

- 1 Remove fork.
- **2** Check fork for cracks, warping and damage to the paintwork.
- **3** You need to distinguish between scratches on the paintwork and impacts if the carbon suspension fork paintwork is damaged.
- ► Ask customer what caused the damage.
- Examine damage with a magnifying glass to see if fibres are permanently damaged or delamination has taken place.

8.5.8.2 Inspect the suspension fork

Only applies to pedelecs with this equipment

- 1 Remove fork.
- 2 Check fork for cracks, warping and damage to the paintwork.
- ➡ If there are any cracks, warping or damage to the paintwork, remove the pedelec from service. New fork as specified in the parts list.
- 3 Dismantle suspension fork.
- 4 Lubricate dust seals and slide bushings.
- **5** Check torques.
- 6 Clean inside and exterior.
- 7 Grease fork.
- 8 Install fork.
- 9 Adjust suspension fork (see Section 6.3.14).



8.5.9 Inspecting the seat post

WARNING

Intoxication from lubrication oil

The lubrication oil for Eightpins seat posts is toxic if touched or inhaled.

- Always wear safety goggles and nitrile gloves when working with lubrication oil.
- Lubricate seat post in the open air or in a wellventilated room only.
- Avoid skin coming into contact with lubrication oil. Wear nitrile gloves when lubricating, cleaning and servicing the vehicle.
- Use an oil catchment tray under the section where the seat post is serviced.
- 1 Remove seat post from the frame.
- 2 Clean seat post on the inside and outside.
- 3 Examine seat post rack for scratches, cracks and breaks.
- **4** Fit seat post as per height specifications in the pedelec pass.

8.5.9.1 Inspect carbon seat post

Only applies to pedelecs with this equipment

You need to distinguish between scratches on the paintwork and impacts if the carbon seat post paintwork is damaged.

- ► Ask customer what caused the damage.
- ► Examine damage with a magnifying glass to see if fibres are permanently damaged or delamination has taken place.



8.5.9.2 Inspecting and greasing BY.SCHULZ suspension seat post

Only applies to pedelecs with this equipment

- 1 Remove seat post from the frame.
- 2 Remove safety and protective cover.
- 3 Clean seat post on the inside and outside.
- **4** Examine seat post rack for scratches, cracks and breaks.
- ⇒ Replaced damaged seat post as specified in the parts list.
- **5** Lubricate screws in the parallel suspension.
- **6** Reinsert seat post as per height specifications in the pedelec pass. Check screws for correct tightening torques.

Torques G1 M8 seat clamp screw M5 fixing grub screws	20 24 Nm 3 Nm
Torque G2 M6 seat clamp screw M5 fixing grub screws	12 14 Nm 3 Nm

7 Put on safety and protective cover.

8.5.9.3 Inspecting and greasing RS SUNTOUR suspension seat post

Only applies to pedelecs with this equipment

- 1 Remove seat post from the frame.
- 2 Remove safety and protective cover.
- **3** Examine seat post rack for scratches, cracks and breaks.
- ⇒ Replaced damaged seat post as specified in the parts list.
- ⇒ If the paint protection film protecting a child seat is missing or has worn away, affix a new paint protection film.
- **4** Undo pre-tensioning adjuster and take out steel spring.
- 5 Clean seat post on inside and outside.
- **6** Grease seat post on inside with SR SUNTOUR grease no. 9170-001.
- 7 Lubricate pressure roller with bicycle chain oil.
- Lubricate articulated joints in parallel suspension with bike chain oil.



Figure 200: SR SUNTOUR suspension seat post lubrication points

- 8 Reinsert seat post as per height specifications in the pedelec pass.
- 9 Check screws for correct tightening torques.

l,	SR SUNTOUR suspension seat post torques	15–18 Nm
ı	Seat clamp screw M5 fixing grub screws	3 Nm

10 Put on safety and protective cover.

9 Troubleshooting, fault clearance and repair

9.1 Preventing pain

A pedelec is a sports vehicle which promotes health.

After the first few rides, you may experience sore muscles the next day. However, permanent pain should never occur during or after a ride.

Medical problems may be the cause of pain. Any such problems should thus always be discussed openly with a doctor.

In most cases, however, pain after pedelec rides is due to a lack of training and components set incorrectly or components that are not adjusted to the rider's physique.

The most common complaints are:

- 1 Sitting discomfort
- 2 Pain in hips
- 3 Backache
- 4 Pain in shoulders and nape of neck
- 5 Numb or aching hands
- 6 Pain in upper thigh
- 7 Pain in the knee
- 8 Pain in the foot




Figure 201: Known pain due to lack of training and/or incorrect component adjustment

9.1.1 Sitting discomfort

Around 50% of all pedelec riders experience sitting discomfort:

- · Pressure pain in the sitting bones
- · Pain in the lower back
- Pressure pain and numbness in perineal region

Solution

- Adopt an optimal riding position (see Section 6.5.3).
- Adjust the saddle height and tilt (see Section 6.5.4).
- Wear cycling shorts and use chamois cream (see Section 6.12).
- Use an ergonomically adjusted saddle (see Section 6.5.4).
- Ride standing up now and again.



9.1.2 Pain in hips

Lower back pain is often not caused by the back muscles, but by the iliopsoas muscle instead. This muscle is part of the inner hip musculature and flexes the hip. It is attached to the thigh bone and reaches up to the spine. Pain can occur in the back if this muscle is strained too much or shortened.

9.1.3 Backache

Riding a pedelec strengthens the back musculature. The greater the saddle-to-bar drop is, the greater the strain on the back musculature is. At the beginning, a posture where you lean too far forward can lead to pain in the back, arms and wrists. The abdominal muscles are the counterpart to the back muscles and stabilise the pelvis and the back. Back pain is thus often caused by weak abdominal muscles.

Solution



- Strengthening exercises for the iliopsoas
- Stretching exercises for hip flexors and extensors.

Solution

 Contact specialist dealer. You need to adopt a more upright sitting position (see Section 6.5.3).



Stretching exercises for the back and abdominal muscle ligaments and moderate bicycle training will lengthen the tendons and build new back and abdominal muscles.

The desired position can be adopted after a period of training.

9.1.4 Pain in shoulders and nape of neck

The weight of the upper body places a strain on the shoulders due to the bent-forward posture. The more stretched the position is, the more strain there is on the shoulders.

The specific posture adopted is often the source of pain. Pedelec riders often extend their arms. Impacts such as those occurring on bumpy roads are thus transmitted to the shoulders without suspension. This causes severe pain.

Another source of pain is a hunchback. Due to the posture adopted, the neck needs to be extended backwards excessively so that the rider can look forwards. This causes strain in the neck and shoulder muscles.

9.1.5 Numb or aching hands

Your hands are one of the three points of contact when you ride a pedelec. The hands transmit the weight of the upper body to the handlebars. In the upright Holland position, there is almost no weight applied whereas body weight is at its highest in the sports position. The force is applied to a small area on the handle, meaning the pressure load on the hands is very high. Hands are highly sensitive and can bear a maximum of 20% of body weight during prolonged exposure to load.

9.1.6 Pain in upper thigh

Pain in the upper thigh is usually due to muscular problems. A muscular imbalance between the extensors, flexors and adductors can cause this pain.

Solution



- A more upright riding position will immediately reduce pain.
- · Always bend elbows slightly.
- ⇒ The elbow joint will not block. The arms cushion impacts.
- Adjust the handlebars (see Section 6.5.5)
- Always adopt an optimal riding position (see Section 6.5.3).

Solution

- Position handles perfectly (see Section 6.5.5.1, 6.5.5.2 and 6.5.8)
- Move hands and arms while riding (see Section 6.15)
- Use padded cycling gloves (see Section 2.15)
- Optimise handles (see Section 6.5.7).

Solution

 Increasing assistance on the pedelec will bring immediate relief.



- Targeted exercises to correct imbalance and shortening of the thigh muscles.
- · Stretching exercises for the thigh muscles.

9.1.7 Knee pain

Pedelec riding is a sport that is easy on the knee joints and is recommended for beginners. Very powerful forces are transmitted from the thigh to the foot via the knee when pedalling. As a result, the tendons and cartilage in the knee are subjected to great stress.

Pain on the inside and outside of the knee is often caused by incorrect adjustment of the click system and the foot being out of position as a consequence. Pain in the lower part of the knee usually stems from an improper riding position

Cold weather can also cause knee pain. Tendons are less elastic at low temperatures and thus rub against the knee more.

If the knee is out of position, the cartilage becomes very worn. Ligaments that are too short or muscular imbalances can increase this effect. Pain on the top of the kneecap often indicates a muscular imbalance. Pain under the kneecap is usually related to excessive pressure in the knee joint and consequential irritation to the patellar tendon

9.1.8 Pain in the foot

Your feet are one of three points of contact when you ride a pedelec. Feet transmit force from the upper thigh to the pedal, thus driving the pedelec. In the process, your feet are subjected to between 100% and, during jumps, even up to 1,000% of your body weight

Foot pain often arises when the saddle is too low or the foot is placed incorrectly on the pedal.

Unsuitable shoes can also be the cause of pain in the feet.

Solution

- Contact specialist dealer. Have the pedelec adjusted (see Section 6.5). Then measure the wheel.
- Avoid cold.



 Get imbalances under control through stretching exercises, strengthening the muscles and Blackroll training.

Solution

- Wear sturdy shoes which are not too tightly laced. (see Section 2.5)
- Position feet correctly on the pedals (see Section 6.13).
- Adjust the saddle height to an optimum position (see Section 6.5.4).

9 Troubleshooting, fault clearance and repair

9.1 Troubleshooting and fault clearance

The components of the drive system are constantly checked automatically. If an error is detected, an error message appears on the *on-board computer*. The drive may be shut off automatically, depending on the type of error.

9.1.1 Drive system or on-board computer does not start up

If the on-board computer and/or the drive system do not start up, proceed as follows:

- 1 Check whether the battery is switched on. If not, start the battery.
- ⇒ Contact your specialist dealer if the battery level LEDs do not light up.
- 2 If the battery level LEDs light up, but the drive system does not start, remove the battery.
- 3 Insert the battery.
- 4 Start the drive system.
- **5** If the drive system won't start, remove the battery.
- 6 Clean all the contacts with a soft cloth.
- 7 Insert the battery.
- 8 Start the drive system.
- **9** If the drive system won't start, remove the battery.
- 10 Charge battery fully.
- 11 Insert the battery.
- 12 Start the drive system.
- **13** If the drive system does not start up, remove the on-board computer.
- 14 Fasten on-board computer.
- **15** Start the drive system.
- **16** Contact your specialist dealer if the drive system won't start.

9.1.2 Error message

If an error message is displayed, run through the following actions:

- 1 Make a note of the system message. There is a table containing all system messages in Section 6.3.1.
- 2 Shut off and re-start the drive system.
- **3** If the system message is still displayed, remove the battery and then re-insert.
- 4 Re-start the drive system.
- 5 If the system message is still displayed, contact your specialist dealer.

9.1.3 Assistance function errors

Symptom	Cause/possible source	Remedy
	Is the battery charged sufficiently?	1 Check battery is charged.
		2 Recharge the battery if it is almost flat.
	Riding up long inclines in summer	1 Switch off the drive system.
Assistance is not	weather or riding with a heavy load for a long time. The battery may be too hot.	2 Wait a moment and then check again.
available.	The rechargeable battery, the on- board computer or the assistance switch may be connected incorrectly, or one or more of them may have a problem.	► Contact specialist dealer.
	Is the speed too high?	► Check on-board computer indicators. The electronic gear assistance only works up to a maximum speed of 25 km/h.
	Are the pedals being pushed?	► The pedelec is not a motorbike. Push the pedals.
Assistance is not	le the level of encirtaine set to [OFF]2	Set the level of assistance to a different level of assistance than [OFF].
available.	Is the level of assistance set to [OFF]?	Contact your specialist dealer if you still feel that the no assistance is being supplied.
	Is the system switched on?	▶ Press the battery on-off button to switch it on again.
	The journey distance can be shorter	1 Check battery is charged.
	depending on the road conditions, the gear level and the total usage time.	2 Recharge the battery if it is almost flat.
	The battery does not perform as well in winter weather.	This does not indicate a problem.
The assisted journey distance is too short.	The battery is a consumable. Repeated charging and long periods of use cause the battery to degrade (loss of power).	▶ If the distance you can cover with one single charge is very short, replace the battery with a new one.
	Is the battery fully charged?	▶ If the distance covered with a fully charged battery has become shorter, the battery may be affected. Replace the battery with a new one.
	Are the tyres pumped to an adequate pressure?	▶ Pump up tyres.
	Is the level of assistance set to OFF?	1 Set level of assistance to [BOOST].
		Contact your specialist dealer if you still feel that the no assistance is being supplied.
It is difficult to pedal.	The battery charge might be low.	► Check how powerful assistance is again after charging the battery. If there is still no assistance, contact your specialist dealer.
	Have you switched on the system with your foot on the pedal?	Switch system on again without applying pressure to the pedal. If assistance is still not supplied, contact your specialist dealer.

Table 56: Level of assistance error solution

9.1.4 Battery error

Symptom	Cause/possible source	Remedy
The battery discharges quickly.	The battery may be at the end of its useful life.	▶ Replace old battery with new one.
	Is the charger mains plug firmly connected to the socket?	 Disconnect the charger mains plug and plug it in again. Repeat charging process. If the battery still won't recharge, contact your specialist dealer.
	Is the charger plug firmly connected to battery?	 Disconnect the charger mains plug and plug it in again. Repeat charging process. If the battery still won't recharge, contact your specialist dealer.
The battery cannot be recharged.	Is the adapter firmly connected to the charger plug or the battery's charging port?	 Connect the adapter firmly to the charger plug or the battery charging port. Start the charging process again. If the battery still won't recharge, contact your specialist dealer.
	Is the connection terminal for the charger, charger adapter or battery dirty?	 Wipe with a dry cloth to clean the connection terminals. Repeat charging process. If the battery still won't recharge, contact your specialist dealer.
The battery does not start charging when the charger is connected.	The battery may be at the end of its useful life.	▶ Replace old battery with new one.
The battery and charger become hot.	The temperature of the battery or the charger may have exceeded the operating temperature range.	 Interrupt charging process. Wait a moment. Repeat charging process. If the battery is too hot to touch, there might be a problem with the battery. Contact specialist dealer.
The charger is hot.	If the charger is used continuously to charge batteries, it may become hot.	 Wait a moment. Start the charging process again.
	Is the charger plug firmly connected to battery?	 Check connection for any contaminants. Insert charger plug again. Contact your specialist dealer if there is no change.
The LED on the charger does not light up.	Is the battery fully charged?	 The LED on the charger will go out when the battery is fully charged. This is not a malfunction. Disconnect charger mains plug. Insert mains plug again. Repeat charging process. Contact your specialist dealer if the LED on the charger still doesn't light up. Contact specialist dealer.
The battery cannot be removed.		Contact your specialist dealer.
The battery cannot be inserted.		Contact specialist dealer.
Fluid is leaking from the battery.		▶ Observe all the warnings in Section 2 Safety.

Table 57: Error solution for battery

Symptom	Cause/possible source	Remedy
		1 Remove from the battery immediately.
There is an unusual smell.		2 Contact the fire service immediately.
		3 Observe all the warnings in Section 2 Safety.
Fumes are emitted from		1 Remove from the battery immediately.
the battery.		2 Contact the fire service immediately.
		3 Observe all the warnings in Section 2 Safety.

Table 57: Error solution for battery

9.1.5 On-board computer error

Symptom	Cause/possible source	Remedy
	The battery charge level may be insufficient.	 Charge the battery. Switch on the power.
	Is the power switched on?	▶ Press the on-off button to switch the power on.
No data are shown on the monitor when you press the on-off button on the battery.	Is the battery charged?	▶ If the battery is fitted to the pedelec and is being charged, it cannot be switched on. Interrupt charging.
	Is the connector fitted to the power cable correctly?	► Check that the power cable connector has not been disconnected. If this is not the case, contact your specialist dealer.
	A component may be connected which the system is unable to recognise.	Contact specialist dealer.
The gear level is not shown on the on-board computer.	The gear level is only shown if the electronic gear shift is used.	► Check that the power cable connector has not been disconnected. If this is not the case, contact your specialist dealer.
The settings menu cannot be opened while you are pedalling.	The product is designed in such a way that the settings menu cannot be opened if the system detects that someone is riding the pedelec. This is not a malfunction.	▶ Stop pedelec and change settings.
The time display is flashing "0:00".	The on-board computer battery has come to the end of its service life.	► Contact specialist dealer.

Table 58: On-board computer error solution

9.1.6 Lighting does not work

Symptom	Cause/possible source	Remedy
The front light or rear light does not go on, even when the switch is pressed.	The basic settings in the electric drive system have probably been configured incorrectly. The light is defective.	 Take pedelec out of service immediately. Contact specialist dealer.
When the main beam is switched on, the light goes off when the brake is applied.	The motor is wired incorrectly.	 Take pedelec out of service immediately. Contact specialist dealer.

Table 59: Lighting error solution

9.1.7 SR SUNTOUR suspension fork

9.1.7.1 Rebound too fast

The suspension fork rebounds too quickly, producing a "pogo stick" effect, where the wheel lifts from the ground in an uncontrolled way. This impairs traction and control (blue line).

Fork head and handlebars are deflected upwards if the wheel bounces back from the ground. Body weight may be thrown up and back in an uncontrolled way (green line).



Figure 202: Suspension fork rebounding too quickly

Solution



Figure 203: SR SUNTOUR rebound screw (1)

- ▶ Turn **rebound screw** in a clockwise direction.
- ⇒ The rebound speed is decreased (slower return).

9.1.7.2 Rebounding too slowly

The fork does not rebound quickly enough after absorbing a bump. The fork also remains deflected over subsequent bumps, which reduces deflection and increases the hardness of impacts. Available deflection, traction and control decrease (blue line).

The fork remains in a deflected state, causing the headset and handlebars to move to a lower position. Body weight is shifted forward after the impact (green line).




Figure 204: Suspension fork rebounding too slowly

Solution



Figure 205: SR SUNTOUR rebound screw (1)

- ► Turn **rebound screw** in an anti-clockwise direction.
- ⇒ The rebound speed is increased (faster return).

9.1.7.3 Suspension too soft on inclines

The fork deflects at a low point in the terrain. The deflection is quickly used up, body weight shifts forward and the pedelec loses some momentum.



Figure 206: Excessively soft suspension in the suspension fork on hilly terrain

Solution



Figure 207: Changing compression adjuster to a harder setting

- ► Turn compression adjuster in a clockwise direction towards LOCK.
- ⇒ The damping and compression hardness are increased and the deflection stroke speed. Efficiency on hilly and flat terrain is improved.

9.1.7.4 Excessively hard damping on bumps

When the bike hits a bump, the fork deflects too slowly and the wheel lifts up from the bump. Traction decreases when the wheel no longer touches the ground.

The headset and handlebars are deflected upwards significantly, which can impair control.



Figure 208: Excessively hard damping in the suspension fork on bumps

Solution



Figure 209: Changing compression adjuster to a softer setting

- ► Turn compression adjuster in a clockwise direction towards OPEN.
- ⇒ The damping and compression hardness reduces and the deflection stroke speed is reduced. Sensitivity to small bumps is increased.

9.1.8 Problems with freewheel

Symptom	Cause	Remedy
	Cover forgotten after fitting.	Contact specialist dealer. Check installation correct.
Freewheel blocked.	After fitting, socket was compressed by over-tightening the quick-release axle.	➤ Contact specialist dealer. Measure the length of the socket. If the socket is shorter than 15.4 mm, replace socket.
	After maintenance: Too much or wrong grease on the toothed discs.	Contact specialist dealer. Remove hub. Clean and grease toothed disc.
Freewheel does not lock	Toothed discs are worn.	Contact specialist dealer. Replace toothed disc.
into place or slips.	One or both springs were forgotten after fitting.	Contact specialist dealer. Check installation correct.
	One or both toothed discs are fitted the wrong way round after assembly.	Contact specialist dealer. Check installation correct.
	Ball bearings are worn	Contact specialist dealer. Replace ball bearings.
Hub has axial clearance.	One or both toothed discs are fitted the wrong way round after assembly.	Contact specialist dealer. Check installation correct.
	Ball bearings are worn.	Contact specialist dealer. Replace ball bearings.
Hub is stiff when turned.	Ball bearings have been driven in too firmly after assembly	Contact specialist dealer. Check installation correct.
	Installation sequence for ball bearings not observed.	Contact specialist dealer. Check installation correct.
Hub makes noise	Ball bearings are worn	Contact specialist dealer. Replace ball bearings.
Cassette caused notches on the freewheel body.	Steel cassette works its way into the aluminium bar on the freewheel body.	Contact specialist dealer. Remove notches on the cassette surface with a file.
Freewheel body is stiff when turned.	Ball bearings in the freewheel body are worn.	Contact specialist dealer. Replace freewheel body.
Freewheel is too loud or too quiet.	Perception of freewheel noise is subjective. While some pedelec riders prefer loud freewheel noise, others like a quite freewheel more.	➤ This is not a malfunction. The amount of grease between the toothed discs may have an effect on the freewheel noise. Less grease increases freewheel noise but also causes greater wear.

Table 60: Error solution for freewheel

9.1.9 Problems with hub gear

Symptom	Cause	Remedy	
A noise is heard when the pedals are turning.	All gear speeds except 1.		
A noise is heard when the pedelec is pushed backwards.	All gear speeds except 1.		
Noises and vibrations occur on switching on.	All gear speeds.	This is not a malfunction.	
Gear shifting feels different, depending on the gear speed.	All gear speeds.		
A noise is heard whenever the rider isn't pedalling while riding.	All gear speeds.		
The gears are difficult to	The cable has not been installed properly.	Contact specialist dealer.	
engage.	The gear shift unit has been set to the override state.	Contact specialist dealer. (readjust gear shift unit)	
Gears cannot be engaged smoothly.	Shift cable tension setting not correct.	 Carefully pull the adjusting sleeve away from the shifter housing, turning it as you do so. Check the gear shift function after each adjustment. 	
The gear speed cannot be changed.	The cable was not set correctly.	Contact specialist dealer. (Reset gear shift unit; check whether the gear speed can be changed when the wheel is detached from the frame.)	
Strange noises are	When switching gears	Contact aposiglist dealer	
produced	When pedalling	Contact specialist dealer.	
The gear speed shown on the indicator differs from	The cable was not set correctly.	Contact anguiclist dealer	
the speed in the hub.	The internal unit has a defect.	Contact specialist dealer.	
The hub rotates with	The cone is firmly positioned.	Contact specialist dealer.	
difficultly only or does not rotate smoothly.	The internal unit has a defect.	Contact specialist dealer.	
A rattling noise is heard when pedalling.	The section around the cone is damaged.	Contact specialist dealer.	
Free rotation is not smooth if the rider does not pedal.		Contact specialist dealer.	
The brakes are too sensitive.		Contact specialist dealer.	
The brakes are not strong enough.		Contact specialist dealer.	
The rider needs to push the pedals too far back before the brakes engage.		Contact specialist dealer.	
The wheels block if the pedelec is pushed backwards.		Contact specialist dealer.	

Table 61: Error solution for limit stop

Symptom	Cause	Remedy
Strange noises occur when the brakes are applied.		Contact specialist dealer.
Rotation feels stiff during free rotation.		Contact specialist dealer.
Chain jumps between the gearwheels when gear is changed.	Gearwheels and/or chain worn.	Contact specialist dealer. New chain, gearwheels or hub.

Table 61: Error solution for limit stop

9.1.10 Problems with disc brakes

Symptom	Cause	Remedy
Ringing and unusual sounds from disc brakes.	Riding on asphalt with off-road tyres.	Contact specialist dealer. Fit a city or trekking tyre.
Law braking navor from	Dirty or greasy brake disc.	▶ Clean brake disc thoroughly with white spirit or brake cleaner.
Low braking power from the disc brake.	Worn brake disc or brake lining, brake lining vitrified.	Contact specialist dealer.
Metallic noises from disc brake.	Worn brake linings.	▶ Contact specialist dealer. New brake linings and brake disc.
Spongy, soft or poor pressure point in disc brakes.	Brake calliper fitted incorrectly, brake disc loose, brake disc or brake lining worn or brake system leaking.	► Contact specialist dealer.
	Dirt.	 Clean brake disc and brake thoroughly. If the problem is not solved, contact your specialist dealer.
	Worn or wrong brake linings.	► Contact specialist dealer. New brake linings and brake discs.
	Wheel, hub or axle fitted incorrectly.	▶ Contact specialist dealer. Check brake system and wheel
Noises when rim brake is applied.	Brake calliper and/or brake disc fitted incorrectly.	assembly.
	Incorrect torques.	
	Brake disc damaged by side impact.	
	Vitrified brake linings.	
	Brake system leaking.	
Incorrect torques.		
Incorrect brake mount height.		

Table 62: Disc brake error solution

9.1.11 Problems with rim brakes

Symptom	Cause	Remedy
	Break in brakes. A rim brake's full braking power is not produced until the rider has cycled several kilometres.	► This is not a malfunction. During the first 50 km or so after replacing the brake linings, check the rims and brake linings regularly and clean to remove any residues.
Noises when rim brake is	Dirt.	 Clean rim and brake thoroughly. If the problem is not solved, contact your specialist dealer.
applied.	Worn or wrong brake linings.	Contact specialist dealer. New brake linings and rims.
	Wheels, hub or axle fitted incorrectly.	
	Incorrect torques.	Contact specialist dealer. Check brake system and wheel assembly.
	Incorrect brake mount height.	

Table 63: Rim brake error solution

9.1.12 Problems with back-pedal brake

Symptom	Cause	Remedy
Brake is too sensitive.		 Contact specialist dealer. Lubricate brake hub. Replace brake shoe unit.
Brake is too weak.		 Contact specialist dealer. Replace brake shoe unit. If the problem should persist, replace the internal hub unit.
The rider needs to push the pedals too far back before the brakes engage.		 Contact specialist dealer. Replace brake shoe unit. If the problem should persist, replace the internal hub unit.
The wheels block if the pedelec is pushed backwards.		Contact specialist dealer. Replace internal hub unit.
Unusual noises when braking		 Contact specialist dealer. Lubricate brake hub. Replace brake shoe unit.
Rotation feels stiff during free rotation.		Contact specialist dealer. Replace brake shoe unit.

Table 64: Error solution for back-pedal brake

9.1.13 RockShox suspension fork

9.1.13.1 Rebound too fast

The suspension fork rebounds too quickly, producing a "pogo stick" effect, where the wheel lifts from the ground in an uncontrolled way. This impairs traction and control (blue line).

Fork head and handlebars are deflected upwards if the wheel bounces back from the ground. Body weight may be thrown up and backwards in an uncontrolled way (green line).



Figure 210: Suspension fork rebounding too quickly

Solution



Figure 211: Turning the rebound screw damper towards tortoise symbol

- ➤ Turn the rebound screw clockwise towards the tortoise symbol.
- ⇒ The rebound speed is decreased (slower return).

9.1.13.2 Rebounding too slowly

The fork does not rebound quickly enough after absorbing a bump. The fork also remains deflected over subsequent bumps, which reduces deflection and increases the hardness of impacts. Available deflection, traction and control decrease (blue line).

The fork remains in a deflected state, causing the headset and handlebars to move to a lower position. Body weight is shifted forward after the impact (green line).




Figure 212: Suspension fork rebounding too slowly

Solution



Figure 213: Turning the rebound screw damper towards hare symbol

- ► Turn the rebound screw anti-clockwise towards the hare symbol.
- ⇒ The rebound speed is increased (fast return).

9.1.13.3 Suspension too soft on inclines

The fork deflects at a low point in the terrain. The deflection is quickly used up, body weight shifts forward, and the pedelec loses some momentum.



Figure 214: Excessively soft suspension in the suspension fork on hilly terrain

Solution



Figure 215: Changing compression adjuster to a harder setting

- ► Turn compression adjuster clockwise.
- ⇒ The damping and compression hardness is increased, and the deflection stroke speed is reduced. Efficiency on hilly and flat terrain is improved.

9.1.13.4 Excessively hard damping on bumps

When the bike hits a bump, the fork deflects too slowly and the wheel lifts up from the bump. Traction decreases when the wheel no longer touches the ground.

The headset and handlebars are deflected upwards significantly, which can impair control.



Figure 216: Excessively hard damping in the suspension fork on bumps

Solution



Figure 217: Adjust the compression adjuster so that it is

- ► Turn compression adjuster anti-clockwise.
- ⇒ The damping and compression hardness is reduced and the deflection stroke speed is increased. Sensitivity to small bumps is increased.

9.1.14 Other errors

Symptom	Cause	Remedy
Two beeps will sound if a switch is pressed but the switch cannot be operated.	Pressed switch mode has been deactivated.	▶ This is not a malfunction.
Three beeps are sounded.	A fault or warning has occurred.	▶ This occurs when a warning or an error is shown on the onboard computer. Follow the instructions for the code in Section 6.2 System Messages.
If an electronic gear shift is used, pedal assistance becomes less effective when the gear is changed.	This is because the computer sets the pedal assistance to the optimum level.	► This is not a malfunction.
A noise can be heard after switching.		Contact specialist dealer.
It is normal to hear a noise coming from the rear wheel when cycling as normal.	The gear shift setting may not have been made properly.	► Contact specialist dealer.
If the pedelec is brought to a stop the pedelec, the gear transmission does not switch to the position pre-configured in the functional feature.	You may have applied too much pressure on the pedals.	Press on the pedals only gently to make it easier to change the transmission.

Table 65: Other drive system errors

9.2 Repair

Special expertise and tools are required for many repairs. For this reason, repairs may only be carried out at a specialist dealer. These include:

- · Replacing tyre, tube and spokes
- Replace brake linings, rims and brake discs
- Replace and tension the chain.

9.2.1 Original parts and lubricants

The individual pedelec parts have been carefully selected and matched to one other.

Only original parts and lubricants must be used for maintenance and repair.

The constantly updated accessory approval and parts lists are in Section 11, Documents and Drawings.

► Follow the operating instructions for the new components.

9.2.2 Repairing the frame

9.2.2.1 Removing paint damage on frame

- **1** Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.
- 9.2.2.2 Removing damage from impact on the carbon frame

There may be damage to the laminate beneath the paintwork in the case of impact. The frame may break even under light stress.

- 1 Take pedelec out of service.
- 2 Send frame to a fibre composite repair company or purchase new frame as specified in the parts list.

9.2.3 Repairing the suspension fork

9.2.3.1 Removing paint damage on the fork

- **1** Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.
- 9.2.3.2 Removing damage from impact on the carbon frame

There may be damage to the laminate beneath the paintwork in the case of impact. The fork may break even under light stress.

- ▶ Take pedelec out of service. New fork as specified in the parts list.
- ⇒ The fork must be free from any defects.
- 4 Clean inside and exterior.
- 5 Grease fork.
- 6 Install fork.

9.2.3.3 Repairing the seat post

Repairing paint damage on the seat post

- **1** Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.
- 9.2.3.4 Repairing damage from impact on the carbon post seat post

There may be damage to the laminate beneath the paintwork in the case of impact. The carbon seat post may break even under light stress.

- 1 Take pedelec out of service.
- 2 New carbon seat post as specified in parts list.

9.2.4 Replacing the riding light

Only use components in the corresponding power class for replacement.

9.2.5 Adjusting the headlight

► The *headlight* must be positioned so that its light beam shines on the road 10 m in front of the pedelec (see Section 6.4).

9.2.6 Checking suspension fork-tyre clearance

The tyre clearance needs to be checked each time a suspension fork tyre is replaced.

- 1 Release pressure from the fork.
- 2 Press fork together fully.
- 3 Measure the gap between the top of the tyre and the crown's lower surface. The gap must not be less than 10 mm. If the tyre is too large, the tyre will touch the crown's lower surface when the fork is fully pressed together.
- **4** Release pressure on fork and pump it up again if it is an air suspension fork.
- 5 Take into account the fact that the gap will be smaller if there is a guard. Check again to ensure that there is sufficient clearance for the tyre.

10 Recycling and disposal

X

This device is marked according to the European Directive 2012/19/EU on waste electrical and electronic equipment – WEEE and the European Directive 2006/66/EC on accumulators. The directive provides the framework for

the return and recycling of used devices across the EU. Consumers are legally required to return all used batteries of any type. It is forbidden to dispose of batteries in domestic waste.

The battery manufacturer is legally obliged to take back used and old batteries free of charge according to Section 9 German Batteries Act. The pedelec frame, battery, motor, on-board computer and charger are recyclable materials. You must dispose of and recycle them separately from the domestic waste in compliance with applicable statutory regulations. Separate collection and

recycling saves reserves of raw materials and ensures that all the regulations for protection of health and the environment are adhered to when recycling the product and/or the battery.

Never dismantle the pedelec, battery or charger for disposal.

The pedelec, on-board computer, the unopened and undamaged battery and the charger can be returned to any specialist dealer free of charge. Further disposal options may be available, depending on the region.

➤ Store the individual parts of the decommissioned pedelec in a dry place, free from frost, where they are protected from direct sunlight.

10.1 Guidelines on removal of waste

Waste type	Disposal
Non-hazardous waste	
Recycling	
Waste paper, cardboard	Return paper collection bin, paper container, undamaged transport packaging to suppliers
Scrap metal and aluminium	Take to municipal collection points or have collected by waste disposal companies
Tyres, tubes	Tyre manufacturers' collection points, collection forms and fax templates available from tyre manufacturer Otherwise, residual waste bin (grey bin)
Fibre composite components (e.g. carbon, GRP)	Large carbon components such as defective frames and carbon rims can be sent to special collection points for recycling; see www.cfk-recycling.de/index.php?id=57
Dual system sales packaging made of plastic, metal and composite material, lightweight packaging	Collection by waste disposal firm where applicable; return transport packaging to suppliers Plastic waste bin (yellow bin)
CDs, DVDs	Take to municipal collection points since they are made of high-grade plastic and are easy to recycle Otherwise, residual waste bin (grey bin)

Table 66: Removal of waste guidelines

Waste type	Disposal		
Dispose of			
Residual waste	Residual waste bin (grey bin)		
Biodegradable lubricants Biodegradable oils Cleaning cloths covered in biodegradable oil	Residual waste bin (grey bin)		
Filament lamps, halogen lamps	Residual waste bin (grey bin)		
Hazardous waste			
Recycling			
Batteries, rechargeable batteries	Return to the battery manufacturer.		
Electric devices: Motor Display Control panel Wiring	Take to a municipal collection point for electronic waste		
Dispose of			
Waste oil Cleaning cloths daubed in oil Lubrication oil Gear oil Lubricating grease Cleaning fluids Kerosene White spirit Hydraulic fluid Brake fluid	Never mix different oil fluids. Store in original container. Small amounts (mainly <30 kg) Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service) Larger quantities (>30 kg) Collection by waste disposal companies		
Paints Varnishes Thinners	Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service)		
Neon lights, energy-saving lamps	Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service)		

Table 66: Removal of waste guidelines



11 Documents

11.1 Assembly report

Date:

Frame number:

Components	Description		Criteria		Measures if rejected
	Assembly/ inspection	Tests	Accept- ance	Rejection	
Front wheel	Assembly		O.K.	Loose	Adjust quick release
Kickstand	Check mount fastening	Functional check	O.K.	Loose	Retighten screws
Tyres		Tyre pressure check	O.K.	Tyre pressure too low/ too high	Adjust tyre pressure
Frame	Check for damage – fracture, scratches		O.K.	Damage detected	Take out of operation, new frame
Handles, coverings	Check mount fastening		O.K.	Not provided	Retighten screws, new handles and coverings as specified in parts list
Handlebars, stem	Check mount fastening		O.K.	Loose	Retighten screws; new stem as specified in parts list if necessary
Steering headset	Check for damage	Functional check	O.K.	Loose	Retighten screws
Saddle	Check mount fastening		O.K.	Loose	Retighten screws
Seat post	Check mount fastening		O.K.	Loose	Retighten screws
Guard	Check mount fastening		O.K.	Loose	Retighten screws
Pannier rack	Check mount fastening		O.K.	Loose	Retighten screws
Attachments	Check mount fastening		O.K.	Loose	Retighten screws
Bell		Functional check	O.K.	No ring, too quiet, missing	New bell as specified in the parts list
		Suspensi	on elements		
Fork, suspension fork	Check for damage		O.K.	Damage detected	New fork as specified in the parts list
Rear frame damper	Check for damage		O.K.	Damage detected	New fork as specified in the parts list
Suspension seat post	Check for damage		O.K.	Damage detected	New fork as specified in the parts list
		Brake	system		
Handbrake	Check mount fastening		O.K.	Loose	Retighten screws
Brake fluid	Check fluid level		O.K.	Too little	Refill with brake fluid; new brake hoses if damaged
Brake linings	Check brake linings, brake discs and rims for damage		O.K.	Damage detected	New brake linings, brake discs and rims
Back-pedal brake braking armature	Check mount fastening		O.K.	Loose	Retighten screws
		Lightin	ng system		
Rechargeable battery	First examination		O.K.	Error message	Take out of service; contact battery manufacturer, new battery
Light cabling	Connections, correct wiring		O.K.	Cable defective, no light	New cabling
Rear light	Side light	Functional check	O.K.	No constant light	Take out of service; new rear light as specified in parts list; replace if necessary
Front light	Side light, daytime riding light	Functional check	O.K.	No constant light	Take out of service; new front light as specified in parts list; replace if necessary
Reflectors	All complete, state, fastening		O.K.	Damaged or not all complete	New reflectors



Drive/gear shift					
Chain/cassette/ pinion/chainring	Check for damage		O.K.	Damage	Refasten if necessary or replace as specified in parts list
Chain guard/spoke guard	Check for damage		O.K.	Damage	Replace as specified in parts list
Bottom bracket axle/ crank	Check mount fastening		O.K.	Loose	Retighten screws
Pedals	Check mount fastening		O.K.	Loose	Retighten screws
Shifter	Check mount fastening	Functional check	O.K.	Loose	Retighten screws
Shift cables	Check for damage	Functional check	O.K.	Loose and defective	Adjust shift cables; new shift cables if necessary
Front derailleur	Check for damage	Functional check	O.K.	Switching gears difficult or not possible	Adjust
Rear derailleur	Check for damage	Functional check	O.K.	Switching gears difficult or not possible	Adjust
		Elect	ric drive		
On-board computer	Check for damage	Functional check	O.K.	No screen, defective screen display	Restart, test battery, new software or new on-board computer; take out of service.
Control panel	Control panel Check for damage	Functional check	O.K.	No response	Restart; contact control panel manufacturer, new control panel
Control panel Tachometer		Functional check Speed measurement	O.K.	No response Pedelec travelling 10% too fast/slow	Restart; contact control panel
·				Pedelec travelling 10% too	Restart; contact control panel manufacturer, new control panel Take pedelec out of service until
Tachometer	damage		O.K.	Pedelec travelling 10% too fast/slow Failure in system, damage,	Restart; contact control panel manufacturer, new control panel Take pedelec out of service until the source of the error is found
Tachometer Cabling	Visual inspection Firmly in position, lock,	Speed measurement	О.К. О.К.	Pedelec travelling 10% too fast/slow Failure in system, damage, kinked cables Loose; lock doesn't close,	Restart; contact control panel manufacturer, new control panel Take pedelec out of service until the source of the error is found New cabling

Technical inspection, checking safety, test ride

Components	Descrip	otion		Criteria	Measures if rejected
	Assembly/inspection	Tests	Accept- ance	Rejection	
Brake system		Functional check	O.K.	No full braking; braking distance too long	Locate defective part in brake system and correct
Gear shift under operating load		Functional check	O.K.	Problems when shifting gear	Readjust gear shift
Suspension components (fork, shock absorber, seat post)		Functional check	O.K.	Suspension too deep or no longer exists	Locate defective component and correct
Electric drive system		Functional check	O.K.	Loose connection, problems when riding, accelerate	Locate faulty components in electric drive and remedy
Lighting system		Functional check	O.K.	No continuous light, not bright enough	Locate defective part in lighting system and correct
Test ride			No strange noises	Strange noises	Locate source of noise and correct

Date:	
Fitter's name:	
Final inspection by workshop manager:	



11.2 Inspection and maintenance log

Diagnosis and documentation of current status

Date:

Frame number:

Components	Frequency		Description		(Criteria	Measures if rejected
		Inspection	Tests	Inspection/ maintenance	Accept- ance	Rejection	
Front wheel	6 months	Assembly			O.K.	Loose	Adjust quick release
Kickstand	6 months	Check mount fastening	Functional check		O.K.	Loose	Retighten screws
Tyres	6 months		Tyre pressure check		O.K.	Tyre pressure too low/ too high	Adjust tyre pressure
Frame	6 months	Check for damage – fracture, scratches			O.K.	Damage detected	Take pedelec out of service, new frame
Handles, coverings	6 months	Wear; check if fastened securely			O.K.	Not provided	Retighten screws, new handles and coverings as specified in parts list
Handlebars, stem	6 months	Check mount fastening			O.K.	Loose	Retighten screws; new stem as specified in parts list if necessary
Steering headset	6 months	Check for damage	Functional check	Lubricating and adjustment	O.K.	Loose	Retighten screws
Saddle	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Seat post	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Guard	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Pannier rack	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Attachments	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Bell	6 months		Functional check		O.K.	No ring, too quiet, missing	New bell as specified in the parts list
			Suspension e	lements			
Fork, suspension fork	To manufacturer's specifications*	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer Lubrication, oil change as specified by manufacturer	O.K.	Damage detected	New fork as specified in the parts list
Rear frame damper	To manufacturer's specifications*	Check for damage, corrosion, fracture		Maintenance as specified by manufacturer Lubrication, oil change as specified by manufacturer	O.K.	Damage detected	New fork as specified in the parts list
Suspension seat post	To manufacturer's specifications*	Check for damage		Maintenance as specified by manufacturer	O.K.	Damage detected	New fork as specified in the parts list



Components	Frequency		Description		(Criteria	Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
			Brake sys	tem			
Handbrake	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Brake fluid	6 months	Check fluid level		Depending on time of year	O.K.	Too little	Top up brake fluid; take Pedelec out of service if damaged; new brake hoses
Brake linings	6 months	Check brake linings, brake discs and rims for damage			O.K.	Damage detected	New brake linings, brake discs and rims
Back-pedal brake braking armature	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Brake system	6 months	Check mount fastening		Functional check	O.K.	Loose	Retighten screws
			Lighting sy	rstem			
Rechargeable battery	6 months	First examination			O.K.	Error message	Contact battery manufacturer; take battery out of use; new battery
Light cabling	6 months	Connections, correct wiring			O.K.	Cable defective, no light	New cabling
Rear light	6 months	Side light	Functional check		O.K.	No constant light	New rear light as specified in parts list; replace if necessary
Headlight	6 months	Side light, daytime riding light	Functional check		O.K.	No constant light	New headlight light as specified in parts list; replace if necessary
Reflectors	6 months	All complete, state, fastening			O.K.	Damaged or not all complete	New reflectors
			Drive/gear	shift			
Chain/cassette/ pinion/ chainring	6 months	Check for damage			O.K.	Damage	Refasten if neces- sary or replace as specified in parts list
Chain guard/ spoke guard	6 months	Check for damage			O.K.	Damage	Replace as specified in parts list
Bottom bracket axle/crank	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Pedals	6 months	Check mount fastening			O.K.	Loose	Retighten screws
Shifter	6 months	Check mount fastening	Functional check		O.K.	Loose	Retighten screws
Shift cables	6 months	Check for damage	Functional check		O.K.	Loose and defective	Adjust shift cables; new shift cables if necessary
Front derailleur	6 months	Check for damage	Functional check		O.K.	Switching gears difficult or not possible	Adjust
Rear derailleur	6 months	Check for damage	Functional check		O.K.	Switching gears difficult or not possible	Adjust



Components	Frequency		Description		Criteria		Measures if rejected
		Inspection	Tests	Maintenance	Accept- ance	Rejection	
			Electric drive	system			
On-board computer	6 months	Check for damage	Functional check		O.K.	No screen, defective screen display	Restart; test battery; new software or new on-board computer; remove from service,
Control panel	6 months	Control panel Check for damage	Functional check		O.K.	No response	Restart; contact control panel manufacturer, new control panel
Tachometer	6 months		Speed measurement		O.K.	Pedelec travelling 10% too fast/slow	Take pedelec out of service until the source of the error is found
Cabling	6 months	Visual inspection			O.K.	Failure in sys- tem, damage, kinked cables	New cabling
Battery mount	6 months	Firmly in position, lock, contacts	Functional check		O.K.	Loose; lock doesn't close, no contacts	New battery mount
Motor	6 months	Visual inspection and mount			O.K.	Damage, loose	Refasten motor, contact motor manufacturer, new motor; take out of service
Software	6 months	Check version			In lat- est ver- sion	Not latest version	Import update

Technical inspection, checking safety, test ride

Components	Descrip	tion		Criteria	Measures if rejected
	Assembly/inspection	Tests	Accept- ance	Rejection	
Brake system	6 months	Functional check	O.K.	No full braking; braking distance too long	Locate defective part in brake system and correct
Gear shift under operating load	6 months	Functional check	O.K.	Problems when shifting gear	Readjust gear shift
Suspension components (fork, shock absorber, seat post)	6 months	Functional check	O.K.	Suspension too deep or no longer exists	Locate defective component and correct
Electric drive	6 months	Functional check	O.K.	Loose connection, problems when riding, accelerate	Locate faulty component in electric drive and remedy
Lighting system	6 months	Functional check	O.K.	No continuous light, not bright enough	Locate defective part in lighting system and correct
Test ride	6 months	Functional check	No strange noises	Strange noises	Locate source of noise and correct

Date:	
Fitter's name:	
Final inspection by workshop manager:	





Notes	
Notes	

11.3 Parts list

11.3.1 SU-E FS 12

22-15-2061, 22-15-2062

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Aion 35 Evo LO-R AIR	Deflection: 100 mm
Damper	ROCKSHOX, Deluxe Select+	
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GC10	
Stem	BY.SCHULZ, Alpha Pro SDS	Angle-adjustable
Saddle	ERGON, SFC30	Gel
Seat post	BY.SCHULZ D.1	Rhomboid seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals	VP-836	Sand paper
Rear derailleur	SHIMANO, XT	Derailleur gears, 12-speed
Shifter	SHIMANO, XT	Shifter
Front derailleur		
Cassette/cassette sprocket	SHIMANO, CS-M6100-12	10-51T
Chain	KMC X10E	
Toothed belt		
Brake, front/rear	MAGURA, MT4e, MT5e	Hydraulic disc brake
Brake lever, front/rear	MAGURA, MT4e, MT5e	Brake lever with rear light function
Disc, front/rear	Magura, Storm HC	180 mm
Rim, front/rear	RODI, Tryp 30	27.5"
Hub, front	SHIMANO	with E-THRU quick release axle
Hub, rear	SHIMANO,	Freewheel
Spokes	SAPIM	
Nipple	LOCKON	
Wheel set		
Tyres	SCHWALBE, Johnny Watts	65 mm
Tube	SCHWALBE, SV	
Front lamp	LITEMOVE, SE-90	90 lx
Rear lamp	SUPERNOVA, M99	with brake light function
Dynamo		
Pannier rack	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Guards		Aluminium
Chain guard	CURANA	Aluminium
Mudguard	WINGEE	Aluminium, 72 mm

Lock	ABUS, Bordo 6015	
Kickstand	PLETSCHER, Comp40 Flex	
Motor	BOSCH, Performance Line CX, BDU3740	250 Watt, 85 Nm
Rechargeable battery	BOSCH, PowerTube 750, BBP3770	Horizontal, 750 Wh
On-board computer	BOSCH, LED Remote, BHU3600	
Charger	BOSCH, charger, BPC3400	4 A

...not available

11.3.2 ZE 10

22-15-2059, 22-15-2060

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Mobie 45 LOR Air	Deflection: 80 mm
Damper		
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GC10	
Stem	BY.SCHULZ	Angle-adjustable + All-Up height-adjustable + Twist
Saddle	SELLE ROYAL Lookin	Moderate/Relaxed Gel
Seat post		Telescopic suspension seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals		Grip Zone pedals, anti-slip
Rear derailleur	SHIMANO, 10-speed hub Deore	Derailleur gears, 10-speed
Shifter	SHIMANO, Deore	Shifter
Front derailleur		
Cassette/cassette sprocket	SHIMANO, CS-HG500	11-42T
Chain	KMC X10E	
Toothed belt		
Brake, front/rear	MAGURA, MT4e	Hydraulic disc brake
Brake lever, front/rear	MAGURA, MT4e	Brake lever with rear light function
Disc, front/rear	Magura, Storm HC	180 mm
Front rim	180 mm	
Hub, front		
Hub, rear	SHIMANO	with E-THRU quick release axle
Spokes	SHIMANO,	Freewheel
Nipple	SAPIM	
Wheel set	LOCKON	
Tyres		
Tube	SCHWALBE, Marathon E-PLUS Perf	50 mm
Front lamp	SCHWALBE, AV19	
Rear lamp	BUSCH UND MÜLLER, IQ-XS	70 lx
Dynamo	SUPERNOVA, M99	with brake light function
Pannier rack		
Guards	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Chain guard	SKS	
Lock	CURANA	Aluminium
Kickstand	ABUS, Bordo 6015	
Motor	PLETSCHER, Flex	

Rechargeable battery	BOSCH, Performance Line CX	85 Nm
Display	BOSCH, PowerTube 625	625 Wh, vertical
Charger	BOSCH, Intuvia	with Intuvia control panel

...not available

11.3.3 ZE 5F

22-15-2057, 22-15-2058

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Mobie 45 LOR Air	Deflection: 80 mm
Damper		
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GC10	
Stem	BY.SCHULZ	Angle-adjustable + All-Up height-adjustable + Twist
Saddle	SELLE ROYAL Lookin	Moderate/Relaxed Gel
Seat post		Telescopic suspension seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals		Grip Zone pedals, anti-slip
Rear derailleur		
Shifter	SHIMANO, Nexus 5	Twist grip
Front derailleur		
Cassette/cassette sprocket		
Chain		
Toothed belt	GATES	
Brake, front/rear	MAGURA, MT4e	Hydraulic disc brake
Brake lever, front/rear	MAGURA, MT4e	Brake lever with rear light function
Disc, front/rear	Magura, Storm HC	180 mm
Front rim		
Hub, front	SHIMANO	with E-THRU quick release axle
Hub, rear	SHIMANO, Nexus 5	Gear hub, 5-speed
Spokes	SAPIM	
Nipple	LOCKON	
Wheel set		
Tyres	SCHWALBE, Marathon E-PLUS Perf	50 mm
Tube	SCHWALBE, AV19	
Front lamp	BUSCH UND MÜLLER, IQ-XS	70 lx
Rear lamp	SUPERNOVA, M99	with brake light function
Dynamo		
Pannier rack	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Guards	SKS	
Chain guard	CURANA	Aluminium
Lock	ABUS, Bordo 6015	
Kickstand	PLETSCHER, Flex	
Motor	BOSCH, Performance Line CX	85 Nm

Rechargeable battery	BOSCH, PowerTube 625	625 Wh, vertical
Display	BOSCH, Intuvia	with Intuvia control panel
Charger	BOSCH, standard charger	4 A

...not available

11.3.4 ZE 5F Plus

22-15-2057, 22-15-2058

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Mobie 45 LOR Air	Deflection: 80 mm
Damper		
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GP10	
Stem	BY.SCHULZ	Angle-adjustable + All-Up height-adjustable + Twist
Saddle	SELLE ROYAL Lookin	Moderate
Seat post		Telescopic suspension seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals		Grip Zone pedals, anti-slip
Rear derailleur		
Shifter	SHIMANO, Nexus 5	Twist grip
Front derailleur		
Cassette/cassette sprocket		
Chain		
Toothed belt	GATES	
Brake, front/rear	MAGURA, MT4e	Hydraulic disc brake
Brake lever, front/rear	MAGURA, MT4e	Brake lever with rear light function
Disc, front/rear	Magura, Storm HC	180 mm
Front rim	180 mm	
Hub, front		
Hub, rear	SHIMANO	with E-THRU quick release axle
Spokes	SHIMANO, Nexus 5	Gear hub, 5-speed
Nipple	SAPIM	
Wheel set	LOCKON	
Tyres		
Tube	SCHWALBE, Marathon E-PLUS Perf	50 mm
Front lamp	SCHWALBE, AV19	
Rear lamp	ZEMO K-Standard	Aluminium, 110 Lx
Dynamo	SUPERNOVA, M99	with brake light function
Pannier rack		
Guards	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Chain guard	SKS	
Lock	CURANA	Aluminium
Kickstand	ABUS, Bordo 6015	
Motor	PLETSCHER, Flex	

Rechargeable battery	BOSCH, Performance Line CX	85 Nm
Display	BOSCH, PowerTube 625	625 Wh, vertical
Charger	BOSCH, Intuvia	with Intuvia control panel

...not available

11.3.5 ZE 5R

21-17-3236, 21-17-3237

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Mobie 45 LOR Air	Deflection: 80 mm
Damper		
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GP10	
Stem	BY.SCHULZ	Angle-adjustable + All-Up height-adjustable + Twist
Saddle	SELLE ROYAL Lookin	Moderate
Seat post		Telescopic suspension seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals		Grip Zone pedals, anti-slip
Rear derailleur		
Shifter	SHIMANO, Nexus 5	Twist grip
Front derailleur		
Cassette/cassette sprocket		
Chain		
Toothed belt	GATES	
Brake, front/rear	TEKTRO, HD-E395	Hydraulic disc brake
Brake lever, front/rear	TEKTRO, HD-E395	Brake lever with rear light function
Disc, front/rear	TEKTRO	180 mm
Front rim	180 mm	
Hub, front		
Hub, rear	SHIMANO	with E-THRU quick release axle
Spokes	SHIMANO, Nexus 5	Gear hub, 5-speed, back-pedal brake
Nipple	SAPIM	
Wheel set	LOCKON	
Tyres		
Tube	SCHWALBE, Marathon E-PLUS Perf	50 mm
Front lamp	SCHWALBE, AV19	
Rear lamp	ZEMO K-Standard	Aluminium, 110 Lx
Dynamo	SUPERNOVA, M99	with brake light function
Pannier rack		
Guards	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Chain guard	SKS	
Lock	CURANA	Aluminium
Kickstand	ABUS, Bordo 6015	
Motor	PLETSCHER, Flex	

Rechargeable battery	BOSCH, Performance Line CX	85 Nm
Display	BOSCH, PowerTube 625	625 Wh, vertical
Charger	BOSCH, Intuvia	with Intuvia control panel

...not available

11.3.6 ZE 5F Plus

21-17-3234, 21-17-3235

Frame		Aluminium 6061 with fully integrated battery cover and equipped to house dual battery
Fork	SR SUNTOUR, Mobie 45 LOR Air	Deflection: 80 mm
Damper		
Steering headset	FSA, Orbit E 1.5	Aheadset, tapered
Handlebars	BY.SCHULZ, Sport Super Strong	Handlebar width: 680 mm
Handles	ERGON, GP10	
Stem	BY.SCHULZ	Angle-adjustable + All-Up height-adjustable + Twist
Saddle	SELLE ROYAL Lookin	Moderate
Seat post		Telescopic suspension seat post
Saddle clamp	MR CONTROL	
Crank set	FSA, ISIS	Crank length: 170 mm
Pedals		Grip Zone pedals, anti-slip
Rear derailleur		
Shifter	SHIMANO, Nexus 5	Twist grip
Front derailleur		
Cassette/cassette sprocket		
Chain		
Toothed belt	GATES	
Brake, front/rear	TEKTRO, HD-E395	Hydraulic disc brake
Brake lever, front/rear	TEKTRO, HD-E395	Brake lever with rear light function
Disc, front/rear	TEKTRO	180 mm
Front rim	180 mm	
Hub, front		
Hub, rear	SHIMANO	with E-THRU quick release axle
Spokes	SHIMANO, Nexus 5	Gear hub, 5-speed, back-pedal brake
Nipple	SAPIM	
Wheel set	LOCKON	
Tyres		
Tube	SCHWALBE, Marathon E-PLUS Perf	50 mm
Front lamp	SCHWALBE, AV19	
Rear lamp	ZEMO K-Standard	Aluminium, 110 Lx
Dynamo	SUPERNOVA, M99	with brake light function
Pannier rack		
Guards	STANDWELL	with I-Rack and Ortlieb Quick Look 3 mount
Chain guard	SKS	
Lock	CURANA	Aluminium
Kickstand	ABUS, Bordo 6015	
Motor	PLETSCHER, Flex	

Rechargeable battery	BOSCH, Performance Line CX	85 Nm
Display	BOSCH, PowerTube 625	625 Wh, vertical
Charger	BOSCH, Intuvia	with Intuvia control panel


...not available

11.4 Charger operating instructions



Charger


BCS220 | BCS230 | BCS250




- de Originalbetriebsanleitung
- en Original operating instructions
- fr Notice d'utilisation d'origine
- **es** Instrucciones de servicio originales
- pt Manual de instruções original
- it Istruzioni d'uso originali
- nl Oorspronkelijke gebruiksaanwijzing
- da Original brugsanvisning
- sv Originalbruksanvisning
- **no** Original bruksanvisning
- fi Alkuperäinen käyttöopas
- **el** Πρωτότυπες οδηγίες λειτουργίας









0 275 007 XCX | (13.03.2020) Bosch eBike Systems




Bosch eBike Systems 0 275 007 XCX | (13.03.2020)






0 275 007 XCX | (13.03.2020) Bosch eBike Systems



Bosch eBike Systems 0 275 007 XCX | (13.03.2020)



0 275 007 XCX | (13.03.2020) Bosch eBike Systems

English - 1

Safety instructions





Read all the safety and general instructions. Failure to observe the safety and general instructions may result in electric shock,

fire and/or serious injury.

Save all safety warnings and instructions for future reference.

The term **battery** is used in these instructions to mean all original Bosch eBike rechargeable battery packs.



Do not expose the charger to rain or wet conditions. If water enters a charger, there is a risk of electric shock.

- ► Charge only Bosch lithium-ion batteries that are approved for use in eBikes. The battery voltage must match the battery charging voltage of the charger. Otherwise there is a danger of fire and explosion.
- Keep the charger clean. Dirt poses a risk of electric shock.
- Always check the charger, cable and plug before use. Stop using the charger if you discover any damage. Do not open the charger. Damaged chargers, cables and plugs increase the risk of electric shock.
- Do not operate the charger on an easily ignited surface (e.g. paper, textiles, etc.) or in a flammable environment. There is a risk of fire due to the charger heating up during operation.
- ➤ Take care if you touch the charger while it is charging. Wear protective gloves. The charger can get very hot, especially when the ambient temperature is high.
- ➤ The battery may give off fumes if it becomes damaged or is used incorrectly. Ensure the area is well ventilated and seek medical attention should you experience any adverse effects. The fumes may irritate the respiratory system.
- The eBike battery must not be left unattended while charging.
- Supervise children during use, cleaning and maintenance. This will ensure that children do not play with the charger
- ➤ Children or persons who, owing to their physical, sensory or mental limitations or to their lack of experience or knowledge, are not capable of safely operating the charger may only use this charger under supervision or after having been instructed by a responsible person. Otherwise, there is a danger of operating errors and injuries.
- Read and observe the safety warnings and directions contained in all the eBike system operating instructions and in the operating instructions of your eBike.
- ► A sticker in English is adhered to the bottom of the charger (marked (4) in the diagram on the graphics page).

 This says: Use ONLY with BOSCH lithium-ion batteries.

Product description and specifications

Intended Use

In addition to the functions shown here, changes to software relating to troubleshooting and functional modifications may be introduced at any time.

The Bosch eBike chargers are intended exclusively for charging Bosch eBike batteries and must not be used for any other purpose.

Product features

The numbering of the components shown refers to the illustrations on the graphics pages at the beginning of the manual.

Individual illustrations in these operating instructions may differ slightly from the actual conditions depending on the equipment of your eBike.

- (1) Charger
- (2) Device socket
- (3) Device connector
- (4) Charger safety instructions
- (5) Charging connector
- (6) Socket for charging connector
- (7) Charging socket cover
- (8) Rack-mounted battery
- (9) Operation/state of charge indicator
- (10) Battery on/off button
- (11) Standard battery

Bosch eBike Systems 0 275 007 XCX | (13.03.2020)

English - 2

Technical data

Charger		Standard charger (36-4/230)	Compact charger (36-2/100-230)	Fast charger (36-6/230)
Product code		BCS220	BCS230	BCS250
Rated voltage	٧~	207 to 264	90 to 264	207 to 264
Frequency	Hz	47 to 63	47 to 63	47 to 63
Battery charging voltage	V=	36	36	36
Charging current (max.)	Α	4	2	6 ^{A)}
Charging time				
- PowerPack 300, approx.	hrs	2.5	5	2
- PowerPack 400, approx.	hrs	3.5	6.5	2.5
- PowerPack 500, approx.	hrs	4.5	7.5	3
Operating temperature	°C	0 to +40	0 to +40	0 to +40
Storage temperature	°C	+10 to +40	+10 to +40	+10 to +40
Weight, approx.	kg	0.8	0.6	1.0
Protection rating		IP 40	IP 40	IP 40

A) The charging current is limited to 4 A for the PowerPack 300 and for Classic+ Line batteries.

Operation

Start-up

Connecting the charger to the mains (see figure A)

▶ Pay attention to the mains voltage. The voltage of the power source must match the voltage specified on the rating plate of the charger. Chargers marked 230 V can also be operated at 220 V.

Plug the device connector (3) of the power cable into the device socket (2) on the charger.

Connect the power cable (country-specific) to the mains.

Charging the removed battery (see figure B)

Switch the battery off and remove it from its holder on the eBike. When doing so, read and observe the operating instructions of the battery.

Ensure the battery is placed on clean surfaces only. Avoid getting dirt, e.g. sand or soil, in the charging socket and contacts in particular.

Plug the charging connector **(5)** of the charger into the socket **(6)** on the battery.

Charging the battery on the bike (see figures C and D)

Switch the battery off. Clean the cover of the charging socket (7). Avoid getting dirt, e.g. sand or soil, in the charging socket and contacts in particular. Lift the cover of the charging socket (7) and plug the charging connector (5) into the charging socket (6).

➤ There is a risk of fire due to the charger heating up during charging. Ensure the battery on the bike is completely dry and placed on a fireproof surface before charging. If this is not possible, remove the battery from the holder and charge it in a more suitable location. When doing so, read and observe the operating instructions of the battery.

Charging process for two batteries

If two batteries are fitted to an eBike, both batteries can be charged using the uncovered connection. To begin with, both batteries are charged one after the other until they reach approx. $80-90\,\%$ capacity, then they are both fully charged at the same time (the LEDs flash on both batteries). When the bike is in operation, power is drawn from both batteries on an alternating basis.

If you take the batteries out of the holders, you can charge each one individually.

Charging process

The charging process begins as soon as the charger is connected to the battery or charging socket on the bike and to the mains.

Note: The charging process is only possible when the temperature of the eBike battery is within the permitted charging temperature range.

Note: The drive unit is deactivated during the charging process.

The battery can be charged with and without the on-board computer. When charging without the on-board computer, the charging procedure can be observed on the battery charge indicator.

When the on-board computer is connected, a charging notification appears on the display.

The state of charge is displayed by the battery charge indicator (9) on the battery and by the bars on the on-board computer

The LEDs on the battery charge indicator (9) flash during the charging process. Each solid illuminated LED represents ap-

0 275 007 XCX | (13.03.2020) Bosch eBike Systems

The specifications apply to a rated voltage [U] of 230 V. These specifications may vary at different voltages and in country-specific models.

English - 3

proximately 20 % of the charging capacity. The flashing LED indicates the next 20 % currently charging.

Once the eBike battery is fully charged, the LEDs go out immediately and the on-board computer is switched off. The charging process is terminated. The state of charge can be displayed for three seconds by pressing the on/off button (10) on the eBike battery.

Disconnect the charger from the mains and the battery from the charger.

When the battery is disconnected from the charger, the battery is automatically switched off.

Note: If you have charged the battery on the bike, carefully close the charging socket **(6)** with the cover **(7)** after charging, so that no dirt or water can get in.

If the charger is not disconnected from the battery after charging, after a few hours the charger will switch itself back on, check the state of charge of the battery and begin the charging procedure again if necessary.

Errors - causes and corrective measures

Cause	Corrective measures
[[] \\ \ \ \ \ \ \ \ \ \ \ \ \	Two LEDs flash on the battery.
Law Law E	Contact an authorised bike dealership.
Battery defective	
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Three LEDs flash on the battery.
Link I have	Disconnect the battery from the charger until the charging temperature range has been reached.
Battery too warm or too cold	Do not reconnect the battery to the charger until it has reached the correct charging temperature.
**************************************	No LEDs flashing (one or more LEDs will remain permanently lit depending on the state of charge of the eBike battery).
The charger is not charging.	Contact an authorised bike dealership.
Charging not possible (no indicator on battery)	
Connector not attached properly	Check all connections.
Battery contacts dirty	Carefully clean the battery contacts.
Plug socket, cable or charger defective	Check the mains voltage, have the charger checked over by a bike dealership.
Battery defective	Contact an authorised bike dealership.

Maintenance and servicing

Maintenance and cleaning

If the charger fails, please contact an authorised bike dealership

After-sales service and advice on using products

If you have any questions about the charger, contact an authorised bike dealership.

For contact details of authorised bike dealerships, please visit www.bosch-ebike.com.

Disposal

Chargers, accessories and packaging should be recycled in an environmentally friendly manner.

Do not dispose of chargers along with household waste.

Only for EU countries:



According to the European Directive 2012/19/EU on Waste Electrical and Electronic Equipment and its implementation into national law, chargers that are no longer usable must be collected separately and disposed of in an environmentally friendly manner.

Subject to change without notice.

Bosch eBike Systems 0 275 007 XCX | (13.03.2020)

12 Glossary

Bicycle for young adults

Source: ISO 4210-2: pedelec designed for use on public roads by a young adult whose weight is less than 40 kg, with maximum saddle height of 635 mm or more and less than 750 mm. (see ISO 4210).

Brake lever

Source: EN 15194:2017: lever used to apply the brake.

Braking distance

Source: EN 15194:2017: distance travelled by a pedelec between the commencement of braking and the point at which the pedelec comes to rest.

Cargo bike

Source: DIN 79010: pedelec mainly designed to carry goods.

CE marking

Source: Directive on Machinery: the manufacturer uses the CE marking to declare that the pedelec complies with the applicable requirements.

City and trekking bicycles

Source: EN-ISO 4210 - 2: pedelec designed for use on public roads primarily for means of transportation or leisure.

Consumables

Source: EN 82079-1: any part or material that is needed to continue using or maintain the product.

Continuous power rating

Source: ISO 15194:2017, output power specified by the manufacturer at which the motor reaches its thermal equilibrium under the specified ambient conditions.

Decommissioning

Source: DIN 31051: intentional, unlimited interruption in an object's functional capability.

Disc brake

Source: EN 15194:2017: brake in which brake pads are used to grip the lateral faces of a thin disc attached to or incorporated into the wheel hub.

Drive belt

Source: EN 15194:2017: seamless ring belt which is used as a means of transmitting drive force.

Electrical control system

Source: EN 15194:2017: electronic and/or electrical component or an assembly of components provided for installation into a vehicle, together with all electrical connections and associated wiring for the motor electrical power assistance.

Electrically power assisted cycle, bicycle

Source: EN 15194:2017: electrically power assisted cycle pedelec EPAC bicycles, equipped with pedals and an auxiliary electric motor, which cannot be propelled exclusively by means of the auxiliary electric motor, except in start-up assistance mode.

Emergency stop

Source: ISO 13850:2015, function or signal, designed: — to avert arising or reduce existing hazards to persons, damage to machinery or to work in progress; – to be initiated by a single human action.

Fault

Source: EN 13306:2018-02, 6.1: state of an item (4.2.1) characterized by its inability to perform a required function (4.5.1), excluding such inability during preventive maintenance or other scheduled actions or due to lack of external resources.

Folding bicycle

Source: ISO 4210-2: pedelec designed to fold into a compact form, making it easy to transport and store.

Fork steerer

Source: EN 15194:2017: part of a fork that rotates around the steering axis of a pedelec frame head tube. It is normally connected to the fork crown or directly to the fork legs, and is normally the point of connection between the fork and the handlebar stem.

Fracture

Source: EN 15194:2017: unintentional separation into two or more parts.

Maintenance

Source: DIN 31051: maintenance is generally performed at regular intervals and often carried out by trained technical staff. This ensures a maximum service life and low wear and tear for the maintained items. Proper maintenance is often also a pre-requisite for providing a warranty.

Manufacturer

Source: Directive 2006/42/EC on Machinery, 17.05.2006 Any natural or legal person who designs and/or manufactures machinery or partly completed machinery covered by this Directive and is responsible for the conformity of the machinery or the partly completed machinery with this Directive with a view to its being placed on the market, under his own name or trademark or for his own use.

Maximum continuous power rating

Source: ZEG: the maximum continuous power rating is the maximum power for the electric motor output shaft during 30 minutes.

Maximum permitted total weight

Source: EN 15194:2017: weight of the fully assembled pedelec plus the rider and baggage, as specified by the manufacturer.

Maximum saddle height

Source: EN 15194:2017: vertical distance from the ground to the point where the top of the seat surface is intersected by the seat-post axis, measured with the saddle in a horizontal position and with the seat-post set to the minimum insertion-depth mark.

Maximum tyre pressure

Source: EN 15194:2017: maximum tyre pressure recommended by the tyre or rim manufacturer for a safe and efficient performance. If the rim and tyre both indicate a maximum tyre pressure, the maximum inflation pressure is the lower of the two pressures indicated.

Minimum insertion depth

Source: EN 15194:2017: mark indicating the minimum insertion depth of handlebar stem into fork steerer (fork stem) or seat post into frame.

Model year

Source: ZEG: the model year refers to the first production year that the series-manufactured pedelec was manufactured in the version in question and is not always identical with the year of manufacture. The year of manufacture may be before the model year in some cases. If no technical modifications are introduced to the series, production may continue of pedelecs from a previous model year.

Mountain bike, MTB

Source: ISO 4210 - 2: pedelec designed for use off-road on rough terrain, on public roads, and on public pathways, equipped with a suitably strengthened frame and other components, and, typically, with wide-section tyres with coarse tread patterns and a wide range of transmission gears.

Negative deflection

Negative deflection or sag is fork compression caused by body weight and gear (e.g. a backpack), the rider's position and the frame geometry.

Off-road rough terrain

Source: EN 15194:2017: rough gravel tracks, forest trails and other generally off-road tracks where tree roots and rocks are likely to be encountered.

Operating instructions

Source: ISO/DIS 20607:2018: part of the user information that machine manufacturers provide to machine operators; it contains guidance, instructions and tips related to the use of the machine in all its life cycle phases.

Placing on the market

Source: Directive 2006/42/EC on Machinery, 17.05.2006, Making available for the first time in the Community machinery or partly completed machinery with a view to distribution or use, whether for reward or free of charge.

Pressure point

Source: ZEG: the pressure point on a brake is the point on the brake lever where the brake disc and brake pads respond and the braking process is initiated.

Quick-release device, quick release

Source: EN 15194:2017: lever actuated mechanism that connects, retains or secures a wheel or any other component.

Racing bicycle

Source: ISO 4210-2: bicycle intended for highspeed amateur use on public roads and having a steering assembly with multiple grip positions (allowing for an aerodynamic posture), a multispeed transmission system, tyre width not greater than 28 mm and a maximum mass of 12 kg for the fully assembled bicycle.

Rebound

The rebound defines the speed at which the fork rebounds after being loaded.

Rechargeable battery, battery

Source: DIN 40729:1985-05: a rechargeable battery is an energy storage device that can store supplied electrical energy as chemical energy (charging) and release it as electrical energy when required (discharging).

Seat post

Source: EN 15194:2017: component that clamps the saddle (with a bolt or assembly) and connects it to the frame.

Shut-off speed

Source: EN 15194:2017: speed reached, by the pedelec, at the moment the current has dropped to zero or to the no load current value.

Slippage

Source: DIN 75204-1:1992-05: the difference in relation to vehicle speed between the vehicle speed and the speed of its wheels at their circumference.

Spare part

Source: EN 13306:2018-02, 3.5: item intended to replace a corresponding item in order to retain or maintain the original required function of the item.

Suspension fork

Source: EN 15194:2017: front fork incorporating controlled, axial flexibility to reduce the transmission of road-shocks to the rider.

Suspension frame

Source: EN 15194:2017: frame incorporating controlled, vertical flexibility to reduce the transmission of road-shocks to the rider.

Total deflection

Source: Benny Wilbers, Werner Koch: Neue Fahrwerkstechnik im Detail (New chassis technology in detail): the distance that the wheel travels between an unloaded and a loaded position is called total deflection. When at rest, the vehicle's mass is applied to the springs and reduces the total deflection by the negative deflection to the positive deflection.

Wear

Source: DIN 31051: reduction in useful life (4.3.4), caused by chemical and/or physical processes.

Weight of the ready-to-ride pedelec

Source: ZEG: the indicated weight for a ready-toride pedelec refers to the weight of a pedelec at the time of sale. The weight of each additional accessory must be added to this weight

Wheel

Source: ISO 4210 - 2: unit or combination of hub, rim and spokes or disc, but excluding tyre assembly.

Work environment

Source: ISO 9000:2015: set of conditions under which work is performed.

Year of manufacture

Source: ZEG: the year of manufacture is the year in which the pedelec was manufactured. The production period is always from May to July the following year.

12.1 Abbreviations

Abbreviation	Meaning/derivation
ABS	Anti-blocking system
EPAC	Electric power assisted cycle
PTW	permitted total weight

Table 67: Table of abbreviations

12.2 Simplified terms

The following terms are used for better legibility:

Term	Meaning
Operating instructions	Original operating instructions
Damper	Rear frame damper
Specialist dealer	Bicycle specialist dealer
Motor	Drive motor, sub-system
Belt drive	Toothed belt drive

Table 68: Table of simplified terms

13 Appendix

I. Translation of the original EC/EU Declaration of Conformity

Manufacturer Authorised representative for documentation* ZEG Zweirad-Einkaufs-Genossenschaft eG Janine Otto Longericher Str. 2 c/o ZEG Zweirad-Einkaufs-Genossenschaft eG 50739 Köln, Germany Longericher Str. 2 50739 Köln, Germany The machine, pedelec types: 21-17-3236 ZE 5R, Diamant City and trekking bicycle 21-17-3237 ZE 5R, Wave City and trekking bicycle 21-17-3234 ZE 5R Plus, Diamant City and trekking bicycle 21-17-3235 ZE 5R Plus, Wave City and trekking bicycle ZE 5F, Diamant 22-15-2057 City and trekking bicycle 22-15-2058 ZE 5F. Wave City and trekking bicycle 22-15-2057 ZE 5F Plus, Diamant City and trekking bicycle ZE 5F Plus, Wave 22-15-2058 City and trekking bicycle ZE 10, Diamant City and trekking bicycle 22-15-2059 ZE 10, Wave City and trekking bicycle 22-15-2060

Year of manufacture 2021 and year of manufacture 2022, complies with the following applicable EU provisions:

City and trekking bicycle

City and trekking bicycle

- · Machinery Directive 2006/42/EC
- · RoHS Directive 2011/65/EU

22-15-2061

22-15-2062

Electromagnetic Compatibility Directive 2014/30/EU.

SU-E FS 12, Diamant

SU-E FS 12, Wave

The safety objectives in the Low Voltage Directive 2014/35/EU have been met in compliance with Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC.

The following harmonised standards have been applied:

- ISO 20607:2018 Safety machinery Instruction handbook General drafting principles
- EN 15194:2017, Cycles Electrically power assisted cycles EPAC Bicycles

The following other technical standards have been applied:

EN 11243:2016: Cycles – Pannier racks for bicycles – Requirements and test methods



Cologne, 19/04/2021

.....

Egbert Hageböck, Chairman, ZEG Zweirad-Einkaufs-Genossenschaft eG

^{*} Community member who is authorised to compile the technical documentation

II. Declaration of conformity for incomplete machine

eBike Systems



Assembly confirmation

Declaration of the manufacturer for the partly completed machinery

Manufacturer:

Robert Bosch GmbH Gerhard-Kindler-Straße 3 72770 Reutlingen GERMANY

List of valid Drive Unit numbers:

CISCOL AGIIG DILAC	OTHER HUMBORS.		
0275 007 020	0275 007 030	0275 007 040	0275 007 049
0275 007 022	0275 007 032	0275 007 041	0275 007 060
0275 007 023	0275 007 033	0275 007 042	0275 007 063
0275 007 024	0275 007 034	0275 007 043	0275 007 062
0275 007 025	0275 007 035	0275 007 045	0275 007 065
0275 007 027	0275 007 037	0275 007 046	0275 007 071
0275 007 028	0275 007 038	0275 007 047	0275 007 072
0275 007 029	0275 007 039	0275 007 048	0275 007 074
			0275 007 075

List of the applied and observed basic requirements of the "Declaration of Incorporation to appendix I, Machinery Directive 2006/42/EC" (OJ L 157, 09.06.2006, p.24):

No.	Essential Requirements
1.1	GENERAL REMARKS
1.1.2	Principles of safety integration
1.1.3	Materials and products
1.1.5	Design of machinery to facilitate its handling
1.1.6	Ergonomics
1.2	CONTROL SYSTEMS
1.2.1	Safety and reliability of control systems
1.2.3	Starting
1.2.4	Stopping
1.2.4.1	Normal stop
1.2.4.2	Operational stop
1.2.5	Selection of control or operating modes
1.2.6	Failure of the power supply
1.3	PROTECTION AGAINST MECHANICAL HAZARDS
1.3.2	Risk of break-up during operation
1.3.4	Risks due to surfaces, edges or angles
1.3.7	Risks related to moving parts
1.3.9	Risks of uncontrolled movements

Robert Bosch GmbH Bosch eBike Systems Postfach 1342 72703 Reutlingen www.bosch-ebike.de

eBike Systems



Page 2 of 3

No.	Essential Requirements	
1.5	RISKS DUE TO OTHER HAZARDS	
1.5.1	Electricity supply	
1.5.2	Static electricity	
1.5.4	Errors of fitting	
1.5.5	Extreme temperatures	
1.5.6	Fire	
1.5.8	Noise	
1.5.9	Vibrations	
1.5.10	Radiation	
1.5.11	External radiation	
1.6	MAINTENANCE	_
1.6.2	Access to operating positions and servicing points	
1.6.3	Isolations of energy sources	
1.6.4	Operator intervention	
1.7	INFORMATION	
1.7.1	Information and warnings on the machinery	
1.7.1.1	Information and information devices	
1.7.2	Warning of residual risks	
1.7.3	Marking of machinery	
1.7.4	Instructions	
1.7.4.1	General principles for the drafting of instructions	
1.7.4.2	Contents of the instructions	
1.7.4.3	Sales literature	

The technical documents are generated as required in appendix VII B.

We undertake to transmit relevant information of the partly completed machinery in response to a reasoned request by the appropriate national authorities.

REACH POP RoHS II EMC

The technical documents may be reviewed at the following contact:

Robert Bosch GmbH EB/ECA Gerhard-Kindler-Straße 3 72770 Reutlingen GERMANY

The product conforms to the following regulations:

Regulation (EC) No 1907/2006, (OJ L 396, 30.12.2006, p.1) Regulation (EC) No 850/2004, (OJ L 158, 30.04.2004, p.7) Directive 2011/65/EU, (OJ L 174, 01.07.2011, p.88) Directive 2014/30/EU, (OJ L 96, 29.03.2014, p.79) eBike Systems



Page 3 of 3

The machinery is incomplete and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the directive.

Bosch eBike Systems Reutlingen, 26.03.2020

Gunter Flinspach (EB/NE) Vice President

Thomas Raica (EB/ECA)

Director

14 Keyword index

A	арр 172	Carbon seat post,
Air valve, 33	Bicycle for young adults, 250	- care for, 158
position, 33	Bike headset, see steering	Carbon suspension fork,
Articulated shaft,	headset	- inspect, 193
- care for 159	Bowden cable, 37	Carcass, 35
Axle, 33	- check, 165	position, 34
position, 33	Brake cable, 37	Cargo bike, 250
torque, 59	torque, 61	Cassette,
В	Brake calliper, 38	- clean 154
Back-pedal brake,	position, 38	CE marking, 250
- brake, 137	torque, 61	Chain guard 18
- check 167	Brake disc, 38	Chain guard,
Basic cleaning 152	- check, 166	- clean, 155
Battery housing, 43, 44	- clean 155	torques 63
Battery key, 43	- replace, 219	Chain wheel, 41
	position, 38	Chain wheels,
Battery level indicator (battery),	Brake lever, 38	- clean 154
43, 44 Rettery level indicator (diapley)	- adjust pressure point, 110	Chain, 27, 41
Battery level indicator (display	- clean 155	- care for 159
screen), 47	- service, 160	- check 169
Battery level indicator, 56	Brake linings, 38	- check for wear 169
Battery lock, 43	- check, 166	- check tension 169
Battery,	- replace, 111, 219	- clean, 155
- charge, 132	- retract, 111	- replace, 219
- check, 69	position, 38	- service, 196
- clean, 152	torque, 61	- tension, 219
- dispose, 221	Brake, 37	position, 41
- insert, 130	- check 150	Chainring brake,
- remove, 130, 131, 132	- check brake disc, 166	torque, 62
- ship, 66	- check brake linings, 166	Charger, 44
- transport, 66	- check pressure point, 165	- dispose, 221
- wake, 133	- check, 165	Charging port cover, 43
frame battery, 43	- clean, 151	Charging port, 43
integrated battery, 44	- secure during transport 66	Chassis, 28
pannier rack battery, 43	cable clip, 37	Child seat, 122
position, 27	cover cap, 37	
technical data 57	hydraulic, 37	Clamping force
torques, 63	insert pin, 37	Clamping force, - adjust quick release 80
Battery, see rechargeable		- check quick release 80
battery	knob, 37	•
Bead core, 36	mechanical, 37	Compression damper, 33
position, 34	union nut, 37	position, 33
Bell,	Brake,- use, 137	Compression damping, 32
- check 150	Brakes,-	Consumables, 250
- use 128	replace, 111	Continuous power rating 250
position 46	Braking distance, 250	Control panel, 45
Belt guard 18	Break in operation, 67	- clean, 152
Belt sprocket, 41	- carry out 67	position 46
Belt, 41	- prepare 67	Crank bearing/crank set,
- check belt for wear 171	Button,	torque, 62
- check tension 171	On-Off (battery) 43, 44	Crown, 33
- clean, 155	C	position, 33
- Gates Carbon Drive mobile	Cantilever brake,	D
	torque, 62	Decommissioning, 250

Derailleur gears,	Frame,- care for, 156	Headset, see steering headset
- check 175	Freewheel,	Hub gear,
- use, 140	torque, 59	- check 176
Dimensions, 65	Front derailleur,	Hub,
Disc brake, 250	- clean, 154	- adjust ROHLOFF 177
torque, 61	torque, 59	- care for 158
Display 47	Front lamp,	- clean, 154
Display battery, 45	position 46	position, 34
Display,	Front light, 42	torque, 58
- attach, 120	Front wheel brake,	Hydraulic brake system,
- charge battery, 120, 135	- brake, 137	- check 165
- remove, 120	Front wheel, see Wheel	Hydraulic lockout 55
Drive belt, 250	Function display, 47	I
Drive system, 41	G	Info button (control panel), 52
- switch off, 134	Gear hub,	Info button (display), 47
- switch on, 134	- inspect, 191	Initial commissioning, 69
electric, 42	·	_
Dual pivot rim brake,	Gear recommendation, 47, 48	
torque, 61	Gear shift twist grip, 47	Jockey wheel,
Dust seal, 33	Gear shift,	- care for 159
position, 33	- adjust Bowden-cable-oper-	Journey information, 49
E	ated twist grip, dual-	- reset, 136
	cable 178	Avg. speed, 49
Electrical control system, 250	- check 176	clock, 49
Emergency stop 250	- check electric gear shift,	maximum, 49
Emergency stop system 19	176	Odometer, 49
F	- switch gears, 143	Range, 49
Fault, 250	- use, 140	-switch, 136
Folding bicycle, 250	Guards,	Trip distance, 49
Fork end, 29, 33	- check 149	Trip time, 49
position, 29, 33	Н	K
Fork leg,	Handbrake, 250	Kickstand,
position, 29	position 46	- care for, 157
Fork lock, 55	torque, 60	- clean, 153
position 46	Handlebars, $29,46$	- stability 178
Fork steerer, 29, 33, 251	- care for, 157	L
position, 29, 33	- check 175	Leather handles,
Fork, 29	- check, 85	- care for, 157
- care for, 151, 156	- clean, 153	- clean 153
- check 149	- use 129	Leather saddle,
- clean, 153	- use bar ends 129	- care for, 158
position, 27	 use multi-position handle- 	- clean, 154
rigid, 30	bars 129	Level of assistance, 47, 56
SR SUNTOUR structure, 33	position, 27	- select, 136
suspended, 252	torque, 60	ECO, 47
suspension fork, 30	Handles,	eMTB, 47
Fracture, 251	- care for, 157	OFF, 47
Frame battery,	- check 150	SPORT, 47
- insert, 130	- clean 153	TOUR, 47
Frame, 28	- use leather handles 129	•
- care for, 151	position, 46	TURBO, 47
- check 149	Headlight,	LIMOTEC seat post,
- clean, 153	- adjust, 119	- fit 83
- inspect for, 190	- check, 174	Lockout, 55
position, 27	- clean 151	position 46
suspended, 252	torque, 64	
	·-· ¬-· ·	

- clean 151	M	- clean, 153	Rear light, 42
Mechanical, — gear shift 176 Minimum insertion depth marking, 96 Minimum insertion depth, 251 Model year, 251 Model year, 251 Motor cover 18 Mofor cover 18 Motor cover 18 Motor cover 18 Motor cover, 251 Motor power used, 47 Hotor cover, 252 Hotor cover, 251 Motor power used, 47 Motor year, 25 Motor power used, 47 Motor, 42 — clean, 152 — clean, 153 Motor power used, 47 Motor year, 251 Motor cover 18 — clean 152 — clean 152 — septition 179 — inspect (specialist dealer) To position, 47 — edigust, 179 — echeck, 164 — uspacking 68	Maintenance, 251	·	
- gear shift 176 marking, 96 marking, 96 minimum insertion depth, 251 minus button, 52 motor cover 18 motor cover 19 motor each ride 126, 149 minispection 179 major inspection 179 major inspect 199 major inspect 199 major inspect 197 maj	Manufacturer, 251		·
Minimum insertion depth marking, 96 Minimum insertion depth, 251 Minus button, 52 Minus button, 52 Model year, 251 Motor cover I8 Motor cover I8 Motor power used, 47 Motor, 42 — clean, 152 — position, 27 technical data 57 torques, 63 Moutain bike, 251 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard I8 — care for, 159 — check, 149 N Nameplate, 26 — position, 27 Nogative deflection, 251 Nipple holes, — check, 164 Nipple well, — check, 164 O Off-road tyres, 35 Off-road tyres, 35 Off-road tyres, 35 Off-road tyres, 35 On-Orb dutton (display), 47 On-orscreen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack — care 157 — change, 128 — care tor, 159 — clean, 151 — asemble 68 Torque, 60 — each ride, 151 — assemble 68 — before each ride, 151 — assemble 75 — check, 161 — clean 152 — check, 161 — clean 152 — sem ove, 164 — unpacking 68 — unpacking 6	Mechanical,	Patent seat post, 39	*
marking, 96 Minimum insertion depth, 251 Minimum insertion depth, 251 Minus button, 52 Model year, 251 Motor cover 18 Motor cover, torques, 63 Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mudguard 18 Mudguard 18 Mudguard 18 Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Regative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 Off-froad tyres, 35 Off-froad tyres, 35 On-Off button (display), 47 On-Serven indicator, 47 Operating instructions, 252 Operating status indicator, 56 Panier rack - care 157 - change, 128 - clean, 157 - change, 128 - clean, 157 - change, 128 - clean, 151 - adjust, 151 - adjust, 151 - adjust, 151 - adjust, 161 - assemble 68 - before each ride, 151 - assemble 68 - before each ride, 151 - assemble 68 - before each ride 126, 149 - check, 161 - position, 27 - clean, 152 - commission 69 - initial inspection 179 - inspect (specialist dealer) 179 - sell, 85 - service 156 - ship, 66 - transport, 66 - unpacking 68 - use 127 - prosition, 34 - care for, 158 - check, 164 - position, 34 - care for, 158 - check, 164 - position, 33 - check, 164 - position, 34 - care for, 158 - check, 164 - position, 33 - check, 164 - position, 34 - check, 164 - position, 34 - check, 164 - position, 34 - check, 164 - position, 35 - check, 164 - position, 33 - check, 164 - position, 33 - check, 164 - positio	- gear shift 176	•	·
Minimum insertion depth, 251 Minus button, 25 Model year, 251 Motor cover I8 Motor cover, torques, 63 Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mudguard, semountain bike, see MTB MTB, see mountain bike, see MTB Mudguard 18 Mudguard, clean, 153 Mudguards, check, 149 N Nameplate, 26 position, 27 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, check, 164 O O O Off-road lyres, 35 On-board computer, 45 clean 152 -check, 164 O O OFf-road lyres, 35 On-board computer, 45 clean 152 -check 164 O O O OFf-road lyres, 35 On-board computer, 47 Operating instructions, 252 Operating instructions, 252 Operating instructions, 252 Operating instructions, 252 Operating status indicator, 56 P Pannier rack -care 157 -check, 149 Pannier rack -ca	Minimum insertion depth		
Minus button, 52 Model year, 251 Model year, 251 Motor cover 18 Motor cover 18 Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, 251 Mountain bike, 251 Mouguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 Off-froad tyres, 35 Off-froad tyres, 35 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack - care 157 - change, 128 torque, 60 Pedelec, 250 Padelec, 250 Padelec, 250 - adjust 92 - after each ride, 151 - assemble 68 - before each ride 126, 149 - check, 161 - clean 152 - chean is 12 - check, 164 - ship, 66 - ship, 60 - ship, 60 - ship, 61 - check, 161 - chean is 2 - check, 164 - ship, 64 - ship	marking, 96		
Model year, 251 Motor cover I8 Motor cover, torques, 63 Motor power used, 47 Motor, 42 - clean, 152	Minimum insertion depth, 251		
Motor cover 18 Motor cover 18 Motor cover 18 Motor cover 18 Motor cover, torques, 63 Motor power used, 47 Motor, 42 — clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard 18 Mudguard, — care for, 157 — clean, 153 Mudguards, — check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, — check, 164 Nipple well, — check, 164 Nipple well, — check, 164 Nipple well, — check, 164 O Off-road tyres, 35 On-board computer, 45 — clean 152 — store 67 position, 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, — remove, 130, 131, 132 Pannier rack — care 157 — change, 128 Motor cover, torques, 63 Adotr power used, 47 Hotor, 42 — clean, 152 — clean, 152 — clean, 152 — clean, 152 — store 67 position, 27 Position, 179 — initial inspection 179 — inspect (specialist dealer) 179 — inspect (specialist dealer	Minus button, 52	•	
Motor cover, torques, 63 Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - cheack, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - clean 152 - clean 152 - clean 152 - clean, 153 Non-fl button (battery), 43 On-off button (battery), 47 On-screen indicator, 77 Operating instructions, 252 Operating instructions, 252 Pannier rack battery, - remove, 130, 131, 132 Pannier rack - care 157 - change, 128 Motor power used, 47 Motor, 42 - assemble 68 - before each ride 126, 149 - check, 161 - clean, 152 - clean, 153 - change the seat length, 98 - check 149 - position, 34 - remove, 130, 131, 132 - pannier rack - care 157 - change, 128 - after each ride, 151 - assemble 68 - before each ride 126, 149 - check, 161 - clean, 152 - clean, 153 - clean 150 - mitial inspection 179 - check, 161 - major inspection 179 - sell, 85 - service 156 - ship, 66 - transport, 65 - service 156 - ship, 66 - transport, 66 - transport, 65 - unpacking 68 - unpackin	Model year, 251	·	
torques, 63 Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - cheap, 128 - clean, 153 - check, 199 Pannier rack battery, - cheap, 128 - clean, 157 - change, 128 - assemble 68 - before each ride 126, 149 - check, 161 - clean 152 - clean 152 - clean 152 - clean 152 - store 67 - position, 27 Negative deflection, 251 Nipple well, - check, 164 O O O O O O O O O O O O O O O O O O O	Motor cover 18		
Motor power used, 47 Motor, 42 - clean, 152 position, 27 technical data 57 torques 63 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N N N N N N N N N N N N N N N N N N N	Motor cover,		
- cheax, 152 - clean, 152 - position, 27 - technical data 57 - torques 63 - Mountain bike, 251 - Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 - position, 27 Negative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean, 152 - store 67 - position, 46 - torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - check, 149 - check, 164 - clean 151 - clean 151 RESET button, 47 Restainer guard, 44 Riding light, 47 - adjust, 119 - check, 156 - ship, 66 - unpacking 68 - use 125 - shore, 67 - position, 34 - rore tore to belt, 36 - position, 34 - protective cap 47 - check 149 - check 149 - check 175 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - clean 151 - check, 156 - ship, 66 - ship, 66 - ship, 66 - ship, 66 - ship, 68 - ship, 66 - ship, 68 - ship, 69 - ship, 61 - ship, 47 - check, 168 - ship, 61 - ship, 67 - check 168 - ship, 61	torques, 63		
- clean, 152 position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 1, - clean, 153 Mudguard, - clean, 153 Mudguard, - clean, 153 Mudguards, - check, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 On-Dord tyres, 35 On-Dorf button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - chean, 152 - clean 152 - major inspection 179 - check, 156 - ship, 66 - unpacking 68 - use 127 Placing on the market, 252 Plus button, 52 Pressure point, 252 Pressure point, 252 Pressure point, 252 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Q Q-Loc, 33 position, 33 position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 posit	Motor power used, 47		·
position, 27 technical data 57 torques 63 Mountain bike, 251 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 Nipple well, - check, 164 O O O O O O O O O O O O O O O O O O O	Motor, 42		
technical data 57 torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 O Off-road tyres, 35 Off-road tyres, 35 Off-road tyres, 63 On-Off button (battery), 43 On-	- clean, 152		
torques 63 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (battery), 43 On-off button (battery), 43 On-off button (battery), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - inspect (specialist dealer) 179 - adjust, 119 - adjust, 119 - adjust, 119 - check, 156 Rim brake, - check, 150 Rim brake, - check, 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rim brake, - check 168 Rim, - replace, 219 position, 34 Rims brake, - check 168 Rim, - replace, 219 position, 34 Rims brake, - check 168 Rim, - replace, 219 position, 34 Rims brake, - check 168 Rim, - replace, 219 position, 37 Road tyres, 35 Roller brake, - brake, 175 Road tyres, 35 Roller brake, - check 169 Road tyres, 35 Roller brake, - check 169 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - check 149 - position, 34 Rims prake locking lever 37 Rim brake care for,	position, 27		•
Mountain bike, 251 Mountain bike, 251 Mountain bike, 251 Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 179 - major inspection 179 - sell, 85 - major inspection 179 - sell, 85 - service 156 - ship, 66 - transport, 66 - transport, 66 - unpacking 68 - check 168 Rim Rim brake locking lever 37 Rim brake locking lever 3		•	
Mountain bike, see MTB MTB, see mountain bike Mudguard 18 Mudguard,	torques 63		
MTB, see mountain bike Mudguard 18 Mudguard,	Mountain bike, 251		
Mudguard 18 Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 Mamplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 Nipple well, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - service 156 - ship, 66 - ship, 66 - ship, 66 - unpacking 68 - use 127 - position 34 Rims, - check 168 Rim, - replace, 219 position, 34 Rims, - check 168 Rim, - replace, 219 position, 34 Rims, - check 168 Rim, - replace, 219 position, 34 Rims, - check 125 Road tyres, 35 Roller brake, - brake, 137 S Saddle, 128 - change the seat length, 98 - check 175 - chean 152 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 149 - position, 33 - determine saddle height, 96, 98 - use, 128 - check 175 - check 149 - setting wheel, 33 - position, 27 Safety guards, 18 Sag setting wheel, 33 - position, 33 Seat post remote control, position, 46 - care for, 159 - position 41 - replace, 168 Rim, - replace, 219 position, 34 Rims, - chack 149 - care for, 158 Road tyres, 35 Roller brake, - chack 175 - change, 128 Rim brake, - check 168 Rim, - replace, 199 position, 34 Rims, - check 175 - change, 137 - change, 128 Rim brake, - check 168 Rim, - replace, 199 position, 34 Rims, - check 175 - change, 137 - startle deflection 251 Road tyres, 35 Roller brake, - change the seat length, 98 - check 175 - change, 128 Rim brake, - check 168 Rim brake, - check 175 - change 128 Road tyres, 35 Roller brake, - change the seat length, 98 - check 175 - clean, 153 - safety guards, 18 - sagetting wheel, 33 - sagetting wheel, 3	Mountain bike, see MTB		· · · · · · · · · · · · · · · · · · ·
Mudguard, - care for, 157 - clean, 153 Mudguards, - check, 149 N Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - ship, 66 - transport, 66 - unpacking 68 - check 158 Rim, - replace, 219 position, 34 Rims, - care for, 158 Saddle, 128 - cheak 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 175 - clean, 153 - setting wheel, 33 Seat post remote control, position, 34 Sag, setting wheel, 33 Seat post gost remote control, position, 34 Sims, - care for, 158 - clean, 153 - setting wheel, 33 Seat post gost remote control, position, 34 - check 175 - clean, 153 - cl	MTB, see mountain bike		<u> </u>
- care for, 157 - clean, 153 Mudguards, - check, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - transport, 66 - unpacking 68 - inpack, 252 Roller brake, - brake, 137 S Saddle, 128 - chang the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - ohange the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - position, 33 - safety guards, 18 - sagetting wheel, 33 - position, 33 - setting wheel position 46 - seat post, 39, 252 - care for, 158 - clean, 153	Mudguard 18		•
- clean, 153 Mudguards, - check, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - unpacking 68 - use 127 Placing on the market, 252 Pressure point, 252 Preside and tyres, 35 Roller brake, - brake, 137 Saddle, 128 - chang the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 Position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protective ap 47 Puncture protection belt, 36 position, 34 Protective cap 47 Puncture protection belt, 36 Position, 34 Protective cap 47 Puncture protection belt, 36 Posadle, 128 Prish (all pressure, 158 Road tyres, 35 Roller brake,	Mudguard,		
Mudguards, - check, 149 Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-screen indicator, 47 Operating instructions, 252 Operating instructions, 252 Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - use 127 Placing on the market, 252 Plas button, 52 Pressure point, 252 Profile, position, 34 Protective cap 47 Protective cap 47 Puncture protection belt, 36 Position, 34 Protective cap 47 Puncture protection belt, 36 Position, 34 Protective cap 47 Puncture protection belt, 36 Position, 34 Protective cap 47 Puncture protection belt, 36 Push assist button, 52 Push assist button, 52 Push assist, - use, 136 Q-Loc, 33 position, 33 Quick release, 252 - inspect, 192 Quick releases, - check 149 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Position, 34 Rims, - care for, 158 Road tyres, 35 Roller brake, - brake, 137 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - clean, 153 - setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 Road tyres, 35 Roller brake, - brake, 137 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - clean, 153 - setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - inspect, 190 - inspect	- care for, 157	·	
N Placing on the market, 252 Plus button, 52 Pressure point, 252 Profile, position, 27 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Push assist, - use, 136 Push assist, - use, 136 Position, 34 Position, 34 Position, 34 Push assist, - use, 136 Push assist, - use, 137 Push assist, - use, 136 Push assist, -	- clean, 153	·	
N Nameplate, 26 position, 27 Pressure point, 252 Pressure point, 252 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Push torques, 63 On-Off button (battery), 43 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Profile, position, 32 Pressure point, 252 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Push assist, - use, 128 Position, 33 Position, 34 Push assist, - use, 136 Push assist, - clean, 153 Position, 34 Push assist, - use, 136	Mudguards,		
Nameplate, 26 position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pressure point, 252 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Q Q-Loc, 33 position, 33 Q-Loc, 33 position, 33 Quick release, 252 - inspect, 192 Quick releases, - check 149 Pannier rack battery, - remove, 130, 131, 132 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Q Q-Loc, 33 position, 33 Quick release, 252 - inspect, 192 Quick releases, - check 149 Position 41 Torque, 59 Rear derailleur, - care for, 159 - position 41 Torque, 59 Rear frame damper, - check 149 - inspect, 190 - position, 27 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 Sage position, 27 Safety guards, 18 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 194 - inspect, 190 - position, 140 - inspect, 190 - position, 252 - brake, 137 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - safety guards, 18 Sag setting wheel, 33 Seat post remote control, position, 46 - setting wheel, 33 - care for, 158 - check 150, 175 - clean, 153 -	- check, 149		
Profile, position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Profile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Protective cap 47 S Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 position, 27 Safety guards, 18 Sag setting wheel, 33 Sag, setting wheel, 33 Sag, setting wheel position 46 setting wheel position, 46 Seat post, 39, 252 - care for, 158 - check 149 - position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - position, 34 Protective cap 47 S Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - store 67 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - safety guards, 18 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - position, 34 - brake, 177 - chack, 128 - change the seat length, 98 - check 175 - clean, 153 - clean, 153 - clean, 153 - inspect, 190 - position, 34 - chack 175 - clean, 153 - clean, 154 - clean,	N		
Profile, position, 27 Negative deflection, 251 Nipple holes, - check, 164 Nipple well, - check, 164 Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Profetile, position, 34 Protective cap 47 Puncture protection belt, 36 position, 34 Push assist button, 52 Push assist, - use, 136 Q Q-Loc, 33 Position, 33 Quick release, 252 Position, 33 Quick releases, - check 149 Racing bicycle, 252 Rear derailleur, - care for, 159 Position, 41 torque, 59 Rear frame damper, - check 149 Protective cap 47 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 Safety guards, 18 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel position 46 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - check 149 Saddle, 128 - change the seat length, 98 - check 175 - clean, 153 - safety guards, 18 Sag setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - clean, 1	Nameplate, 26		
Negative deflection, 251 Nipple holes,	•		·
Nipple holes,	·	•	
- check, 164 Nipple well, - check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 - position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Puncture protection belt, 36 position, 34 - use, 136 - check 175 - clean, 153 - safety guards, 18 Sag setting wheel, 33 position, 33 Sag, R Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 - position, 46 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - clean, 153 - clean, 153 - clean, 153 - setting wheel position 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - position, 34 - change the seat length, 98 - check 175 - clean, 153 - clean, 153 - safety guards, 18 Sag setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 Safety guards, 18 Sag setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - position, 34 - check 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 149 - safety guards, 18 Sag setting wheel, 33 - setting wheel, 33 - check 150, 175 - clean, 153 - determine saddle height, 96, 98 - use, 128 - check 149 - safety guards, 18 - safety guards, 19 - safety guards, 18 - safety guards, 18 - safety guards, 18 - safety guards, 18 - safety guards, 19 - safety guards, 19 - safe	_		S
- check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Push assist button, 52 Push assist buton, 52 Passicularies and begin, determine saddle height, Position, 33 Safety guards, 18 Sag setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - care for, 159 - check 149 - check	• •		Saddle, 128
- check, 164 O Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Push assist button, 52 Push assist, - use, 136 Q Q-Loc, 33 position, 33 Quick release, 252 Safety guards, 18 Sag setting wheel, 33 Sag, setting wheel, 33 Seat position, 33 Seat position, 33 Seat position, 33 Seat position, 46 Seat post, 39, 252 - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 - inspect, 190 - inspect, 190 - parents in 100 - check 175 - clean, 153 - safety guards, 18 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - inspect, 190 - parents seat post, 39 - check 150 - clean, 153 - determine saddle height, - clean, 153 - determine saddle height, - safety guards, 18 - sag setting wheel, 33 - check 149 - setting wheel, 33 - check 150, 175 - clean, 153 - clean, 153 - clean, 153 - clean, 153 - determine saddle height, - safety guards, 18 - check 149 - setting wheel, 33 - check 149 - care for, 159 - care for, 158 - check 150, 175 - clean, 153 - clean, 150 - clean, 153 - clean, 154 - clean, 155 - clean, 155 - clean, 155 - clean, 156 - clean, 156 - clean, 157 - clea	Nipple well,	·	- change the seat length, 98
Off-road tyres, 35 On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - use, 128 position, 33 - use, 128 position, 27 Safety guards, 18 Sag setting wheel, 33 position, 33 Sag, setting wheel position 46 setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - inspect, 190 - inspect, 190 - position, 46 - care 157 - change, 128			- check 175
On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Q-Loc, 33 position, 33 Quick release, 252 position, 192 Quick releases, - inspect, 192 Quick releases, - check 149 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - inspect, 190 - position, 190 - position, 46 - care 157 - check 149 - inspect, 190 - patent seat post 39	0		- clean, 153
On-board computer, 45 - clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Q-Loc, 33 position, 33 Quick release, 252 - inspect, 192 Quick releases, - check 149 Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - check 149 - inspect, 190 - patent seat post 39	Off-road tyres, 35		•
- clean 152 - store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Q-Loc, 33 position, 33 Quick release, 252 - inspect, 192 Quick releases, - check 149 Sag setting wheel, 33 Sag, Setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 159 - check 149 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - inspect, 190 - inspect, 190 - patent seat post 39		Q	96, 98
- store 67 position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Quick release, 252 - inspect, 192 Quick releases, - check 149 Quick releases, - check 149 Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 Safety guards, 18 Sag setting wheel, 33 Sag, Setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 Position, 27 Safety guards, 18 Sag setting wheel, 33 Sag, Setting wheel position 46 Seat post 79, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 194 - patent seat post 39	-		
position, 46 torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Quick release, 252 - inspect, 192 Safety guards, 18 Sag setting wheel, 33 Sag, Setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 - inspect, 190 - position, 153 - inspect, 190 - patent seat post 39			
torques, 63 On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - inspect, 192 Sag setting wheel, 33 position, 33 Sag, Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 Sag setting wheel, 33 Sag, setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 194 - patent seat post 39			
On-Off button (battery), 43 On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Quick releases, - check 149 Sag, Setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 149 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 Panier rack, - care 157 - check 149 - patent seat post 39	•	•	Sag setting wheel, 33
On-off button (display), 47 On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - check 149 Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 - check 149 Sag, setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - patent seat post 39		·	position, 33
On-screen indicator, 47 Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 - inspect, 190 setting wheel position 46 setting wheel position 46 setting wheel, 33 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - patent seat post 39	• • • • • • • • • • • • • • • • • • • •	- check 149	Sag,
Operating instructions, 252 Operating status indicator, 56 P Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Racing bicycle, 252 Rear derailleur, - care for, 159 - position 41 torque, 59 Rear frame damper, - check 149 - inspect, 190 Racing bicycle, 252 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 Pannier rack, - check 149 - patent seat post 39		R	
Operating status indicator, 56 Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 Rear derailleur, - care for, 159 - position 41 south torque, 59 Rear frame damper, - check 149 - inspect, 190 - patent seat post 39 Seat post remote control, position, 46 Seat post, 39, 252 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - patent seat post 39		Racing bicycle, 252	setting wheel, 33
Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - care for, 159 - position, 46 Seat post, 39, 252 - care for, 158 - care for, 158 - care for, 158 - care for, 158 - check 150, 175 - check 149 - inspect, 190 - position, 46 Seat post, 39, 252 - care for, 158 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - patent seat post 39	· · · · · · · · · · · · · · · · · · ·	Rear derailleur,	•
Pannier rack battery, - remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 - position 41 torque, 59 Rear frame damper, - check 149 - inspect, 190 - change, 128 - position 41 torque, 59 - care for, 158 - check 150, 175 - clean, 153 - inspect, 190 - patent seat post 39	, -	- care for, 159	•
- remove, 130, 131, 132 Pannier rack, - care 157 - change, 128 torque, 59 Rear frame damper, - check 150, 175 - check 149 - inspect, 190 - inspect, 194 - patent seat post 39	•	- position 41	
Pannier rack, - care 157 - change, 128 Rear frame damper, - check 150, 175 - check 149 - inspect, 190 - inspect, 194 - natent seat post 39		•	
- care 157 - change, 128 - inspect, 190 - natent seat nost 39		•	The state of the s
- change, 128 - inspect, 190 - inspect, 194 - natent seat nost 39		·	
maintain 100 - naight seal nost 19		- inspect, 190	-
		- maintain, 190	- patent seat post 39

- suspension seat post 40	Total deflection 252
position, 27	Total journey duration, 50
remote control torque, 60	Trailer, 123
torque, 60	Transportation, 65
Securing hook, 44	Transporting, see Transporta-
Shift indicator,	tion
position 46	Tread, 35
Shifter,	position, 34
- care for, 159	Tube,
- clean 154	- replace, 219
position, 46	Tyre design types, 34
torque, 58	Tyre pressure, 34
Shut-off speed, 252	- change, 161
Slicks, 35	- check, 161
Slippage, 252	Tyre size, 34
Spare part, 252	Tyre,
Spoke nipples,	position, 34
- care for, 158	Tyres, 34
position, 34	- check, 163
Spokes,	- clean 154
- check, 164	- convert 124
- replace 219	airless 124
position, 34	tubeless 124
Stanchion, 33	Tyres,- Tube-type tyres 34
position, 33	U
Steering headset 28	
Steering headset,	USB cover,
- grease, 191	- check 150
- inspect, 191	USB port, 45, 47
	- use, 135
Steering system, 28	V
Stem, 28	V- Brake brake,
- adjust 127	torque, 61
- care for, 157	Valve, 34
- check 175	position, 34
- check, 85	V-brake,
- clean, 153	- adjust 168
- inspect, 191	Vehicle,
position, 27	technical data, 57
torque, 60	W
Suspension fork, 252	Wear, 252
- clean 151	Weight,
- inspect, 193	- shipping weight, 65
- service, 151	- weight, 65
Suspension seat post, 40	Wheel, 34, 253
- care for, 158	- check concentricity 149
- clean, 151	- check, 161
Switching element,	- fit 78, 79, 82
- clean 154	Winter break, see Break in oper-
System message, 51, 89	ation
System setting, 50	Work environment, 253
changeable, 49, 50, 51,	Υ
121	Year of manufacture, 253
T	roar or manaracture, 233
Tachometer, 47	
Torques, 58	